

Edition B 2019

#### Digital - in the vehicle

Familiarize yourself with the contents of the Operator's Manual directly via the vehicle's multimedia system (menu item "Vehicle"). Start with the quick guide, discover your vehicle's highlights or broaden your knowledge with useful tips.



#### Vehicle document wallet

Here you can find comprehensive information about operating your vehicle and about services and warranties in printed form.



#### Digital - on the Internet

You can find the Operator's Manual on the Mercedes-Benz home-



#### Digital - as an App

The Mercedes-Benz Guides App is available free-of-charge in familiar App stores.







Order no. P217 0232 13 Part no. 217 584 26 06







# S-Class Coupe

Operator's Manual





DEALER ePROCESS

#### Front passenger airbag warning



#### Example

**WARNING** Risk of injury or fatal injuries if the front-passenger airbag is enabled

If the front-passenger front airbag is enabled, a child on the front-passenger seat may be struck by the front-passenger airbag during an accident.

NEVER use a rearward-facing child restraint system on a seat with an ENABLED FRONT AIRBAG, DEATH or SERIOUS INJURY to the CHILD can occur.

Observe the chapter "Children in the vehicle".

#### **Publication details**

#### Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

http://www.mbusa.com (USA only)

http://www.mercedes-benz.ca (Canada only)

#### Documentation team

<sup>®</sup>Daimler AG: not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Daimler AG.

#### Vehicle manufacturer

Daimler AG

Mercedesstrasse 137

70327 Stuttgart

Germany



#### Welcome to the world of Mercedes-Benz

Before you first drive off, read this Operator's Manual carefully and familiarize yourself with your vehicle. For your own safety and a longer operating lifespan, follow the instructions and warning notices in this Operator's Manual. Disregarding them may lead to damage to the vehicle or personal injury.

Vehicle damage resulting from the disregard of the instructions is not covered by the Mercedes-Benz Limited Warranty.

The equipment or model designation of your vehicle may vary according to:

- Model
- Order
- · National version
- Availability

Mercedes-Benz reserves the right to introduce changes in the following areas:

- design
- equipment
- technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The following are integral parts of the vehicle:

- · Digital Operator's Manual
- · Printed Operator's Manual
- · Maintenance Booklet
- Equipment-dependent Supplements

Keep these documents in the vehicle at all times. If you sell the vehicle, always pass all of the documents on to the new owner.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company





Symbols	5
At a glance Cockpit Warning and indicator lamps Overhead control panel Control settings in the rear passenger compartment Emergencies and breakdowns	6 8 10 12 14
<b>Digital Operator's Manual</b> Calling up the Digital Operator's Manual	<b>16</b> 16
General notes Protecting the environment Genuine Mercedes-Benz parts Operator's Manual Service and vehicle operation Operating safety Declaration of conformity for wireless vehicle components Diagnostics connection Qualified specialist workshop	17 17 17 18 19 20 21 21 21 22

Correct use of the vehicle	2 2 2 2 2 2 2
Occupant safety Restraint system Seat belts Airbags PRE-SAFE® system Safely transporting children in the vehicle Notes on pets in the vehicle	2 3 3 4 4 5
Opening and closing SmartKey Doors Trunk Roller sun blinds Side windows Panoramic roof  DEALER @PROCESS	5 5 6 6 7 7

Anti-theft protection	77
Refrigerator box	79 80 88 89 91 92 98 99 100 101
<b>3</b> • • • • • • • • • • • • • • • • • • •	106 106 111 112 114

Operating the sun visors	117	Overview of the buttons on the steering wheel	213	Online and Internet functions	31 32
Climate control	119	Overview of displays on the multifunction display		Maintenance and care	33
Driving and parking  Driving  DYNAMIC SELECT switch  Automatic transmission  Function of the 4MATIC  Refueling  Parking  Driving and driving safety systems	126 134 135 139 139 141 150	Voice Control System  Notes on operating safety  Operation  Using the Voice Control System effectively  Essential voice commands	222 222 222 224 224	Breakdown assistance  Emergency  Flat tire  Battery (vehicle)  Tow starting or towing away  Electrical fuses	35 35 35
Vehicle towing instructions	209	Multimedia system	237	Wheels and tires	37
Instrument Display and on-board computer		Overview and operation		acteristics	37 37 37

#### 4 Contents

Tire pressure  Loading the vehicle  Tire labeling  Definition of terms for tires and loading  Changing a wheel	375 382 386 392 394
Technical data  Notes on technical data  Vehicle electronics  Vehicle identification plate, VIN and engine number overview  Operating fluids  Vehicle data	404 404 404 408 414
Display messages and warning/indicator lamps	<b>416</b> 416 462
Index	476



In this Operator's Manual, you will find the following symbols:

**DANGER** Danger due to not observing the warning notices

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

Observe the warning notices.

**ENVIRONMENTAL NOTE** Environmental damage due to failure to observe environmental notes

Environmental notes include information on environmentally responsible behavior or environmentally responsible disposal.

Observe environmental notes.

**NOTE** Damage to property due to failure to observe notes on material damage

Notes on material damage inform you of risks which may lead to your vehicle being damaged.

- Observe notes on material damage.
- Useful instructions or further information that could be helpful to you.

Instruction

 $\rightarrow$  page) Display

Further information on a topic

Information on the multifunction display/media display




Highest menu level, which is to be selected in the multimedia system



Corresponding submenus, which are to be selected in the multimedia system


Marks a cause





DEALER ePROCESS


Steering wheel paddle shifter	$\rightarrow$	137	ECO start/stop function	$\rightarrow$	133
Combination switch	$\rightarrow$	107	Control panel for the multimedia system	$\rightarrow$	211
3 DIRECT SELECT lever	$\rightarrow$	135	Adjusts the steering wheel	$\rightarrow$	88
<ul> <li>PASSENGER AIRBAG indicator lamps</li> </ul>	$\rightarrow$	40	Control panel for:		
⑤ Display (multimedia system)	$\rightarrow$	237	On-board computer	$\rightarrow$	211
Start/stop button	$\rightarrow$	127	Operates cruise control	$\rightarrow$	160
Climate control systems	$\rightarrow$	119	Operates Active Distance Assist DISTRONIC	$\rightarrow$	163
Glove box	$\rightarrow$	94	Unlocks the hood	$\rightarrow$	338
Stowage compartment	$\rightarrow$	94	Electric parking brake	$\rightarrow$	147
© Cup holder	$\rightarrow$	98	20 Light switch	$\rightarrow$	106
<ul><li>Hazard warning lights</li></ul>	$\rightarrow$	108	Control panel for:		
Extends the rear seat head restraints	$\rightarrow$	83	Active Steering Assist	$\rightarrow$	169
Parking Assist PARKTRONIC	$\rightarrow$	184	Active Lane Keeping Assist	$\rightarrow$	208
Control elements for the multimedia system	$\rightarrow$	238	Night View Assist	$\rightarrow$	201
Active Parking Assist	$\rightarrow$	192	Head-up Display	$\rightarrow$	221
Sets the vehicle level	$\rightarrow$	175	Rear window roller sunblind	$\rightarrow$	69
DYNAMIC SELECT switch	<b>→</b>	134	Seat belt extender	$\rightarrow$	33



DEALER ePROCESS

Instrument Display

→ 469
→ 469
→ 470
→ 107
→ 29
→ 47C
→ 464
→ 473
→ 464
→ 464




DEALER EPROCESS

Sun visors	$\rightarrow$	117
② [Yang Switches the left-hand reading lamp on/off	$\rightarrow$	111
Switches automatic lighting control on/off	$\rightarrow$	111
(Mercedes-Benz emergency call system)	$\rightarrow$	304
Switches the front interior lighting on/off	$\rightarrow$	111
<ul><li>Switches the rear interior lighting on/off</li></ul>	$\rightarrow$	111

Switches the right-hand reading lamp on/off	$\rightarrow$	111
<ul><li>Service call button (Mercedes me connect)</li></ul>	$\rightarrow$	301
<ul><li>Eyeglasses compartment</li></ul>	$\rightarrow$	95
Operates the roller sunblind	$\rightarrow$	74
Operates MAGIC SKY CONTROL	$\rightarrow$	76
Inside rearview mirror	$\rightarrow$	115






Stowage compartment in the center console	$\rightarrow$	95
Socket	$\rightarrow$	100
Cup holder	$\rightarrow$	99
Stowage compartment in the rear armrest	$\rightarrow$	95

4	Stowage box in the seat backrest	$\rightarrow$	95
	Refrigerator box	$\rightarrow$	101
5	Switches the rear seat heating on/off	$\rightarrow$	86





What to do in the event of an accident		
<ul> <li>QR codes for accessing the rescue card</li> </ul>	$\rightarrow$	23
Safety vests	$\rightarrow$	353
Button for the SOS emergency call system	$\rightarrow$	304
<ul> <li>Checking and topping up operating fluids</li> </ul>	$\rightarrow$	408
Tow-starting and towing away	$\rightarrow$	366
6 Flat tire	$\rightarrow$	353

Starting assistance	$\rightarrow$	363
• Hazard warning lights	$\rightarrow$	108
<ul> <li>Fuel filler flap with instruction labels for tire pressure, fuel type and QR codes for access- ing the rescue card</li> </ul>	$\rightarrow$	139
Tow-starting and towing away	$\rightarrow$	366
TIREFIT kit	$\rightarrow$	355



#### Calling up the Digital Operator's Manual

Multimedia system:

→ Vehicle **>>** (i) Operator's Manual

Select a menu item.

In addition, you can also call up the Operator's Manual within a main function (e.g. via Media Info).


The Digital Operator's Manual describes the function and operation of the vehicle and the multimedia system.

For safety reasons, the Digital Operator's Manual is deactivated while driving.



The Digital Operator's Manual contains the following menu items:

- Search: allows you to search precisely for keywords.
- Quick start: provides you with important information so that you can start using your vehicle immediately.
- Tips: provides tips on how to use your vehicle in certain situations.
- Messages: provides you with further information about the messages in the instrument cluster.
- Bookmarks: provides you with a list of all the bookmarks you have stored yourself.



- Picture
- Menu
- Navigation window

Some sections of the Digital Operator's Manual, such as warnings, can be made visible by highlighting and pressing them.

 The Operator's Manual can also be found in the Mercedes-Benz Guides app in all common app stores.



#### **Protecting the environment**



**ENVIRONMENTAL NOTE** Environmental damage due to operating conditions and personal driving style

The pollutant emission of your vehicle is directly related to the way you operate your vehicle.

Help to protect the environment by operating your vehicle in an environmentally responsible manner. Please observe the following recommendations on operating conditions and personal driving style.

#### Operating conditions:

- Make sure that the tire pressure is correct.
- Do not carry any unnecessary weight (e.g. roof luggage racks once you no longer need them).
- Adhere to the service intervals. A regularly serviced vehicle will contribute to environmental protection.

Always have maintenance work carried out at a qualified specialist workshop.

#### Personal driving style:

- Do not depress the accelerator pedal when starting the engine.
- ▶ Do not warm up the engine while the vehicle is stationary.
- Drive carefully and maintain a suitable distance from the vehicle in front.
- Avoid frequent, sudden acceleration and braking.
- Change gear in good time and use each gear only up to <sup>2</sup>/<sub>3</sub> of its maximum engine speed.
- Switch off the engine in stationary traffic, e.g. by using the ECO start/stop function.
- Drive fuel-efficiently. Observe the ECO display for a fuel-efficient driving style.



#### **Environmental issues and recommendations:**

It is recommended that you re-use or recycle materials instead of just disposing of them.

The relevant environmental guidelines and regulations serve to protect the environment and must be strictly observed.

#### **Genuine Mercedes-Benz parts**



**ENVIRONMENTAL NOTE** Environmental damage caused by not using recycled reconditioned components

Daimler AG offers recycled reconditioned components and parts with the same quality as new parts. The same entitlement from the Limited Warranty is valid as for new parts.

Use recycled reconditioned components and parts from Daimler AG.

NOTE Impairment of the operating efficiency of the restraint systems from installing accessory parts or from repairs or welding

Airbags and Emergency Tensioning Devices, as well as control units and sensors for the restraint systems, may be installed in the following areas of your vehicle:

- Doors
- Door pillars
- Door sills
- Seats
- Cockpit
- Instrument cluster
- · Center console
- Lateral roof frame
- Do not install accessory parts such as audio systems in these areas.
- Do not carry out repairs or welding.

Have aftermarket installation of accessories carried out at a qualified specialist workshop.

You could jeopardize the operating safety of your vehicle if you use parts, tires and wheels as well as accessories relevant to safety which have not been approved by Mercedes-Benz. Safety-relevant systems, e.g. the brake system, may malfunction. Only use Mercedes-Benz Genuine Parts or parts of equal quality. Only use tires, wheels and accessories that have been specifically approved for your vehicle model.

Mercedes-Benz Genuine Parts are subject to strict quality control. Each part has been specially developed, manufactured or selected for Mercedes-Benz vehicles and fine-tuned for them. Therefore, only Mercedes-Benz Genuine Parts should be used.

More than 300,000 different Mercedes-Benz Genuine Parts are available for Mercedes-Benz models.

All authorized Mercedes-Benz Centers maintain a supply of Mercedes-Benz Genuine Parts for

DEALER ePROCESS

necessary service and repair work. In addition, strategically located parts delivery centers provide for quick and reliable parts service.

#### Operator's Manual

This Operator's Manual describes all models and all standard and optional equipment available for your vehicle at the time of this Operator's Manual going to press. Country-specific differences are possible. Note that your vehicle may not be equipped with all features described. This is also the case for systems and functions relevant to safety. Therefore, the equipment on your vehicle may differ from that in the descriptions and illustrations.

The original purchase agreement for your vehicle contains a list of all of the systems in your vehicle.

Should you have any questions concerning equipment and operation, please consult an authorized Mercedes-Benz Center.

The Operator's Manual and Maintenance Booklet are important documents and should be kept in the vehicle.

#### Service and vehicle operation

#### Vehicle operation outside the USA or Canada

When you are abroad with your vehicle, observe the following points:

- service points or replacement parts may not be available immediately.
- unleaded fuel may not be available for vehicles with a catalytic converter. Leaded fuel may cause damage to the catalytic converter.
- the fuel may have an extremely low octane number. Unsuitable fuel can cause engine damage.

Some Mercedes-Benz models are available in Europe through our European Delivery Program. For more information, please consult an authorized Mercedes-Benz service center, or write to one of the following address:

in the USA:

Mercedes-Benz USA, LLC European Delivery Department One Mercedes-Benz Drive Sandy Springs, GA 30328

#### in Canada:

Mercedes-Benz Canada, Inc. European Delivery Department 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

#### Maintenance

Your customer advisor confirms the service in the service report.

#### Roadside Assistance

The Mercedes-Benz Roadside Assistance Program offers technical help in the case of a breakdown. Your calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

1-800-FOR-MERCedes (1-800-367-6372) (USA)

DEALER ePROCESS

1-800-387-0100 (Canada)

You can find further information in the Mercedes-Benz Roadside Assistance Program brochure (USA) or the "Roadside Assistance" section in the maintenance and warranty information booklet (Canada). You will find both in the vehicle document wallet.

#### Change of address or change of ownership

In the event of a change of address, please send us the "Notification of address change" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) on the hotline number

1-800-FOR-MERCedes (1-800-367-6372) or Customer Service (Canada) on 1-800-387-0100. We can then reach you in a timely fashion, if necessary.

If you sell your Mercedes, please leave all literature in the vehicle so that it is available to the next owner. If you have purchased a used vehicle, please send us the "Notice of Purchase of Used Car" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer

Assistance Center (USA) at the hotline number 1-800-FOR-MERCedes (1-800-367-6372) or Customer Service (Canada) at 1-800-387-0100.

#### Operating safety

WARNING Risk of accident due to malfunctions or system failures

If you do not have the prescribed service/ maintenance work or any required repairs carried out, this could result in malfunctions or system failures.

- Always have the prescribed service/ maintenance work as well any required repairs carried out at a qualified specialist workshop.
- **WARNING** Risk of accident or injury due to incorrect modification of electronic components and parts

Modification to electronic components, their software or wiring could impair their function

and/or the function of other networked component parts. In particular, systems relevant to safety could also be affected.

As a result, these may no longer function properly and/or jeopardize the operating safety of the vehicle.

- Never tamper with the vehicle's wiring, electronic components or software.
- You should have all work on electrical and electronic components carried out at a qualified specialist workshop.
- WARNING Risk of fire due to flammable materials on hot parts of the exhaust system

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system.

 When driving on unpaved roads or offroad, regularly check the vehicle underside.

DEALER EPROCESS

- Remove trapped plants or other flammable material.
  - If there is damage, consult a qualified specialist workshop immediately.
- NOTE Damage to the vehicle

In the following situations, in particular, there is a risk of damage to the vehicle:

- The vehicle becomes grounded, e.g. on a high curb or an unpaved road
- The vehicle is driven too fast over an obstacle, e.g. a curb, speed bump or pothole
- A heavy object strikes the underbody or chassis components

In situations such as this, the body, the underbody, chassis components, wheels or tires could be damaged without the damage being visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, may not absorb the loads that arise as intended.

If the underbody paneling is damaged, flammable materials such as leaves, grass or twigs can collect between the underbody and the underbody paneling. These materials may ignite if they come into contact with hot parts on the exhaust system.

Have the vehicle checked and repaired immediately at a qualified specialist workshop.

or

If driving safety is impaired while continuing your journey, pull over and stop the vehicle immediately in accordance with the traffic conditions, and contact a qualified specialist workshop.

## Declaration of conformity for wireless vehicle components

**USA:** "The wireless devices of this vehicle comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) These devices may not cause harmful interference, and 2) These devices must accept any interference

received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

Canada: "The wireless devices of this vehicle comply with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) These devices may not cause interference, and (2) These devices must accept any interference, including interference that may cause undesired operation of the device."

**USA:** "Wireless charging system for mobile devices (Model: D-WMI2015A): this device complies with Part 18 of the FCC Rules."

The name and address of the responsible party is:

Continental Automotive Systems US Inc.

2400 Executive Hills Drive

Auburn Hills, MI 48326-2980

United States of America

# DEALER ePROCESS

#### Diagnostics connection

The diagnostics connection is only intended for the connection of diagnostic devices at a qualified specialist workshop.

A

WARNING Risk of accident due to connecting devices to the diagnostics connection

If you connect equipment to a diagnostics connection in the vehicle, it may affect the operation of vehicle systems.

As a result, the operating safety of the vehicle could be affected.

 Only connect equipment to a diagnostics connection in the vehicle which is approved for your vehicle by Mercedes-Benz.

A

**WARNING** Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardizes the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always install the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.
- NOTE Battery discharging from using devices connected to the diagnostics connection

Using devices at the diagnostics connection drains the battery.

- Check the charge level of the battery.
- If the charge level is low, charge the battery, e.g. by driving a considerable distance.

Connecting equipment to the diagnostics connection can lead to emissions monitoring information being reset, for example. This may lead to the vehicle failing to meet the requirements of the next emissions inspection during the main inspection.

#### Qualified specialist workshop

An authorized Mercedes-Benz Center is a qualified specialist workshop. It has the necessary special skills, tools and qualifications to correctly carry out the work required on your vehicle. This particularly applies to safety-relevant works.

For the following, always have your vehicle checked at an authorized Mercedes-Benz Center:

- · safety-relevant works
- service and maintenance work
- · repair work
- modifications as well as installations and conversions
- · work on electronic components

DEALER ePROCESS

Mercedes-Benz recommends a Mercedes-Benz service center.

#### Correct use of the vehicle

If you remove any warning stickers, you or others could fail to recognize certain dangers. Leave warning stickers in position.

Observe the following information in particular when driving your vehicle:

- the safety notes in this manual
- technical data for the vehicle
- · traffic rules and regulations
- laws and safety standards pertaining to motor vehicles

#### Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified. If the problem is not resolved to your satis-

faction, please discuss the problem again with an authorized Mercedes-Benz Center or, if necessary, contact us at one of the following addresses:

#### In the USA:

Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes-Benz Drive Sandy Springs, GA 30328

#### In Canada:

Mercedes-Benz Canada, Inc.
Customer Relations Department
98 Vanderhoof Avenue
Toronto, Ontario M4G 4C9

#### Reporting safety defects

#### USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the

"National Traffic and Motor Vehicle Safety Act of 1966".

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153) (inside the USA); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590, USA.

Further information on vehicle safety can be found at: http://www.safercar.gov



DEALER ePROCESS

#### Limited Warranty

NOTE Damage to the vehicle arising from violation of these operating instructions.

Damage to the vehicle can arise from violation of these operating instructions.

This damage is not covered either by the Mercedes-Benz implied warranty or by the New- or Used-Vehicle Warranty.

Follow the instructions in these operating instructions on proper operation of your vehicle as well as on possible vehicle damage.

#### QR code for rescue card

The QR code is secured in the fuel filler flap and on the opposite side on the B-pillar. In the event of an accident, rescue services can use the QR code to quickly find the appropriate rescue card for your vehicle. The current rescue card contains the most important information about your

vehicle in a compact form, e.g. the routing of the electric lines.

Further information can be obtained at http://www.mercedes-benz.de/gr-code.

#### Data storage

#### **Electronic control units**

Electronic control units are installed in your vehicle. Some of these are necessary for the safe operation of your vehicle, while some assist you when driving (driver assistance systems). In addition, your vehicle provides comfort and entertainment functions, which are also made possible by electronic control units.

Electronic control units contain data memories which can temporarily or permanently store technical information about the vehicle's operating state, component loads, maintenance requirements and technical events or malfunctions.

In general, this information documents the state of a component part, a module, a system or the surroundings such as:

- operating status of system components (e.g. fill levels, battery status, tire pressure)
- status messages concerning the vehicle or its individual components (e.g. number of wheel revolutions/speed, longitudinal acceleration, lateral acceleration, display of fastened seat belts)
- malfunctions or faults in important system components (e.g. lights, brakes)
- information on events leading to vehicle damage
- system reactions in special driving situations (e.g. airbag deployment, intervention of stability control systems)
- ambient conditions (e.g. temperature, rain sensor)

In addition to providing the actual control unit function, this data assists the manufacturer in detecting and rectifying malfunctions and optimizing vehicle functions. The majority of this data is temporary and is only processed in the vehicle itself. Only a small portion of the data is stored in the event or malfunction memory.

When your vehicle is serviced, technical data from the vehicle can be read out by service network employees (e.g. workshops, manufacturers) or third parties (e.g. breakdown services). Services include repair services, maintenance processes, warranty claims and quality assurance measures, for example. The read out is performed via the legally prescribed port for the diagnostics connection in the vehicle. The respective service network locations or third parties collect, process and use the data. They document technical statuses of the vehicle. assist in finding malfunctions and improving quality and are transmitted to the manufacturer, if necessary. Furthermore, the manufacturer is subject to product liability. For this, the manufacturer requires technical data from vehicles.

Fault memories in the vehicle can be reset by a service outlet as part of repair or maintenance work.



Depending on the selected equipment, you can import data into the vehicle's comfort and infotainment functions yourself.

This includes, for example:

- multimedia data such as music, films or photos for playback in an integrated multimedia system
- address book data for use in connection with an integrated hands-free system or an integrated navigation system
- · entered navigation destinations
- · data about the use of Internet services

This data can be saved locally in the vehicle or it is located on a device which you have connected to the vehicle (e.g. smartphone, USB flash drive or MP3 player). If this data is stored in the vehicle, you can delete it at any time. This data is sent to third parties only at your request, particularly when you use online services in accordance with the settings that you have selected.

You can store or change convenience settings/individualization in the vehicle at any time.

Depending on the equipment, this includes, for example:

- settings for the seat and steering wheel positions
- suspension and climate control settings
- customizations such as interior lighting

If your vehicle is accordingly equipped, you can connect your smartphone or another mobile end device to the vehicle. You can control this by means of the control elements integrated in the vehicle. Images and audio from the smartphone can be output via the multimedia system. Certain information is simultaneously transferred to your smartphone.

Depending on the type of integration, this can include:

- general vehicle data
- position data

This allows you to use selected apps on your smartphone, such as navigation or music playback. There is no further interaction between the smartphone and the vehicle; in particular, vehicle data is not directly accessible. Which type of

DEALER ePROCESS

further data processing occurs is determined by the provider of the specific app used. Which settings you can make, if any, depends on the specific app and the operating system of your smartphone.

#### Online services

#### Wireless network connection

If your vehicle has a wireless network connection, it enables data to be exchanged between your vehicle and additional systems. The wireless network connection is enabled via the vehicle's transmission and reception unit or via connected mobile end devices (e.g. smartphones). Online functions can be used via the wireless network connection. This includes online services and applications/apps provided by the manufacturer or other providers.

#### Manufacturer's services

Regarding online services of the manufacturer, the individual functions are described by the manufacturer in a suitable place (e.g. Operator's Manual, website of the manufacturer) along with the relevant data protection information. Per-

sonal data may be used for the provision of online services. Data is exchanged via a secure connection, e.g. the manufacturer's designated IT systems. Personal data is collected, processed and used via the provision of services exclusively on the basis of legal permissions or with prior consent.

The services and functions (sometimes subject to a fee) can usually be activated or deactivated. In some cases, this also applies to the entire vehicle's data connection. This excludes, in particular, legally prescribed functions and services.

#### Third party services

If it is possible to use online services from other providers, these services are subject to the data protection and terms of use of the responsible provider. The manufacturer has no influence on the content exchanged.

Please inquire, therefore, about the type, scope and purpose of the collection and use of personal data as part of third party services from their respective provider.

#### COMAND/mbrace

If the vehicle is equipped with COMAND or mbrace, additional data about the vehicle's operation, the use of the vehicle in certain situations, and the location of the vehicle may be compiled through COMAND or the mbrace system.

For additional information please refer to the chapter Multimedia system and/or the mbrace Terms and Conditions.

#### **Event data recorders**

#### USA only:

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an airbag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.



The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating
- Whether or not the driver and front passenger seat belts were buckled/fastened
- How far (if at all) the driver was depressing the accelerator and/or brake pedal and
- · How fast the vehicle was traveling

This data can help provide a better understanding of the circumstances in which accidents and injuries occur. NOTE: EDR data is recorded by your vehicle only if a non-trivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data (e.g. name, gender, age and accident location) is recorded. However, other parties, such as law enforcement, could combine EDR data with the type of personally identifying data routinely acquired during a crash investigation.

Access to the vehicle and/or the EDR is needed to read data that is recorded by the EDR, and special equipment is required. In addition to the vehicle manufacturer, other parties that have the

special equipment, such as law enforcement, can read the information by accessing the vehicle or the EDR.

EDR data may be used in civil and criminal matters as a tool in accident reconstruction, accident claims and vehicle safety. Since the Crash Data Retrieval (CDR) tool that is used to extract data from the EDR is commercially available, Mercedes-Benz USA, LLC ("MBUSA") expressly disclaims any and all liability arising from the extraction of this information by unauthorized Mercedes-Benz personnel.

MBUSA will not share EDR data with others without the consent of the vehicle owner or, if the vehicle is leased, without the consent of the lessee. Exceptions to this representation include responses to subpoenas by law enforcement; by federal, state or local government; in connection with or arising out of litigation involving MBUSA or its subsidiaries and affiliates; or, as required by law.

Warning: the EDR is a component of the Restraint System Module. Tampering with, altering, modifying or removing the EDR component may result in a malfunction of the Restraint System Module and other systems.

State laws or regulations regarding EDRs that conflict with federal regulation are pre-empted. This means that in the event of such conflict, the federal regulation governs. As of December 2016, 17 states have enacted laws relating to EDRs.

#### Copyright

#### Free and open source software

Information on free and open source software licenses for your vehicle's software can be found on the data storage medium in your vehicle document wallet and on the Internet together with updates:

http://www.mercedes-benz.com/opensource

#### Registered trademarks

- Bluetooth<sup>®</sup> is a registered trademark of Bluetooth SIG Inc.
- DTS<sup>™</sup> is a registered trademark of DTS, Inc.

DEALER ePROCESS

- Dolby<sup>®</sup> and MLP<sup>TM</sup> are registered trademarks of DOLBY Laboratories.
- BabySmart™, ESP® and PRE-SAFE® are registered trademarks of Daimler AG.
- HomeLink<sup>®</sup> is a registered trademark of Johnson Controls.
- iPod<sup>®</sup> and iTunes<sup>®</sup> are registered trademarks of Apple Inc.
- Burmester<sup>®</sup> is a registered trademark of Burmester Audiosysteme GmbH.
- Microsoft<sup>®</sup> and Windows Media<sup>®</sup> are registered trademarks of Microsoft Corporation.
- SIRIUS<sup>®</sup> is a registered trademark of Sirius XM Radio Inc.
- HD Radio™ is a registered trademark of iBiquity Digital Corporation.
- Gracenote<sup>®</sup> is a registered trademark of Gracenote, Inc.
- ZAGATSurvey<sup>®</sup> and related brands are registered trademarks of ZagatSurvey, LLC.

#### **Restraint system**

#### Protection by the restraint system

The restraint system includes the following components:

- · Seat belt system
- Airbags
- · Child restraint system
- · Child seat securing system

The restraint system can reduce the risk of vehicle occupants coming into contact with parts of the vehicle's interior in the event of an accident. The restraint system can also reduce the forces to which vehicle occupants are subjected in the event of an accident.

Only a seat belt which is worn correctly can provide the intended level of protection. Depending on the detected accident situation, Emergency Tensioning Devices and/or airbags supplement a correctly worn seat belt. Emergency Tensioning Devices and/or airbags are not deployed in every accident.

For the restraint system to provide its full protection, each occupant must observe the following:

- · Fasten the seat belt correctly.
- Be in an almost upright position with their back against the seat backrest.
- Sit with their feet resting on the floor, if possible.
- Always secure persons under 5 ft (1.50 m) tall in an additional restraint system suitable for Mercedes-Benz vehicles.

However, no system available today can completely eliminate injuries and fatalities in every accident situation. In particular, the seat belt and airbag generally do not protect against objects penetrating the vehicle from the outside. The risk of an injury resulting from airbag deployment also cannot be ruled out entirely.



#### Reduced restraint system protection



**WARNING** Risk of injury or death from modifications to the restraint system

The restraint system can no longer function correctly after alterations have been made.

The restraint system may then not protect the vehicle occupants as intended by failing in an accident or triggering unexpectedly, for example

- Never alter the parts of the restraint system.
- Never tamper with the wiring or any electronic component parts or their software.

If it is necessary to modify the vehicle to accommodate a person with disabilities, contact an authorized Mercedes-Benz Center for details.

USA only: for details, contact our Customer Assistance Center on 1-800-FOR-MERCedes (1-800-367-6372).

#### Restraint system functionality

When the ignition is switched on, a self-test is performed, during which the restraint system warning lamp lights up. It goes out no later than a few seconds after the vehicle is started. The components of the restraint system are then functional.

#### Malfunctioning restraint system

A malfunction has occurred in the restraint system if:

- the restraint system warning lamp does not light up when the ignition is switched on
- the prestraint system warning lamp lights up continuously or repeatedly during a journey

▲ WARNING Risk of injury or fatal injury due to a malfunction in the restraint system

If the restraint system is malfunctioning, restraint system components may be trig-

gered unintentionally or might not be triggered at all in the event of an accident. This may affect the Emergency Tensioning Device or airbag, for example.

Have the restraint system checked and repaired immediately at a qualified specialist workshop.

### Function of the restraint system in an accident

How the restraint system works is determined by the severity of the impact detected and the type of accident anticipated:

- Frontal impact
- Rear impact
- Side impact
- Rollover

The activation thresholds for the components of the restraint system are determined based on the evaluation of the sensor values measured at various points in the vehicle. This process is preemptive in nature. The triggering/deployment of

DEALER ePROCESS

the components of the restraint system must take place in good time at the start of the collision.

Factors which can only be seen and measured after a collision has occurred do not play a decisive role in the deployment of an airbag. Nor do they provide an indication of airbag deployment.

The vehicle may be deformed significantly without an airbag being deployed. This is the case if only parts which are relatively easily deformed are affected and the rate of vehicle deceleration is not high. Conversely, an airbag may be deployed even though the vehicle suffers only minor deformation. If very rigid vehicle parts such as longitudinal members are hit, for example, this may result in sufficiently high levels of vehicle deceleration.

## The components of the restraint system can be activated or deployed independently of each other:

Component	Detected deploy- ment situation
Emergency Tension- ing Devices	Frontal impact, rear impact, side impact, rollover
Driver's airbag, front passenger front air- bag	Frontal impact
Knee airbag	Frontal impact
Side airbag	Side impact
Window curtain air- bag	Side impact, rollover, frontal impact

The front passenger front airbag can only be deployed in an accident if the PASSENGER AIR BAG OFF indicator lamp is off. If the front passenger seat is occupied, make sure, both before and during the journey, that the status of

A

**WARNING** Risk of burns from hot air bag components

The air bag parts are hot after an air bag has been deployed.

- Do not touch the air bag parts.
- Have a deployed air bag replaced at a qualified specialist workshop as soon as possible.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident. Take this into account, particularly if an Emergency Tensioning Device is triggered or an airbag deployed.

If the Emergency Tensioning Devices are triggered or an airbag is deployed, you will hear a bang, and a small amount of powder may also be released:

The bang will not generally affect your hearing.

DEALER ePROCESS

In general, the powder released is not hazardous to health but may cause short-term breathing difficulties to persons suffering from asthma or other pulmonary conditions. Provided it is safe to do so, leave the vehicle immediately or open the window in order to prevent breathing difficulties.

Airbags and pyrotechnic Emergency Tensioning Devices contain perchlorate material, which may require special handling or environmental protection measures. National guidelines regarding waste disposal must be observed. In California, see http://www.dtsc.ca.gov/HazardousWaste/Perchlorate/index.cfm.

#### Seat belts

#### Protection provided by the seat belt

Always fasten your seat belt correctly before starting a journey. A seat belt can only provide the best level of protection if it is worn correctly.

## **WARNING** Risk of injury or death due to incorrectly fastened seat belt

If the seat belt is not worn correctly, it cannot perform its intended protective function. In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly.

Always observe the instructions about the correct driver's seat position and adjusting the seat (—— page 79).

In order for the correctly worn seat belt to provide the intended level of protection, each vehicle occupant must observe the following information:

 The seat belt must not be twisted and must fit tightly and snugly across the body.

- The seat belt must be routed across the center of the shoulder and as low down across the hips as possible.
- The shoulder section of the seat belt should not touch your neck nor be routed under your arm or behind your back.
- Avoid wearing bulky clothing, e.g. a winter coat.
- Push the lap belt down as far as possible across your hips and pull tight with the shoulder section of the belt. Never route the lap belt across your abdomen.
- Never route the seat belt across sharp, pointed, abrasive or fragile objects.
- Only one person should use each seat belt at any one time. Never allow babies and children to travel sitting on the lap of another vehicle occupant.

DEALER ePROCESS

Also ensure that no objects, e.g. a cushion, are ever placed between a person and the seat.

The seat belts on the following seats are equipped with a special seat belt retractor:

- front-passenger seat
- Rear seats

Activate or deactivate the special seatbelt retractor ( page 49).

#### Reduced seat belt protection

A

**WARNING** Risk of injury or death due to incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.

When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdominal or neck injuries, for example.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.

WARNING Risk of injury or death due to an extended seat belt extender while the vehicle is in motion

If the seat belt extender is extended while the vehicle is in motion, the seat belt will not fit correctly to the body.

The seat belt may not then provide the proper protection.

Always ensure that the seat belt extender is retracted while the vehicle is in motion. If the seat belt extender does not retract automatically, it can be retracted manually. To do so, press the seat belt extender back as far as it will go before starting the vehicle. Pressing the seat belt extender back into place requires force.

**WARNING** Risk of injury or death when additional restraint systems are not used for persons with a smaller build

Persons under 5 ft (1.50 m) tall cannot wear the seat belt correctly without a suitable additional restraint system.

If the seat belt is not worn correctly, it cannot perform its intended protective function. In addition, an incorrectly fastened seat belt can also cause injuries, for example, in the event of an accident or when braking or changing direction suddenly.

 Always secure persons under 5 ft (1.50 m) tall in a suitable restraint system.



**WARNING** Risk of injury or death due to damaged or modified seat belts

Seat belts cannot provide protection in the following situations:

- If the seat belts are damaged, modified, extremely dirty, bleached or dyed
- If the seat belt buckle is damaged or extremely dirty
- If the Emergency Tensioning Devices, seat belt anchorages or seat belt retractors have been modified

Seat belts may be damaged in an accident, although the damage may not be visible, e.g. due to splinters of glass.

Modified or damaged seat belts may tear or fail, e.g. in an accident.

Modified Emergency Tensioning Devices can accidentally trigger or fail to function as intended.

Never modify the seat belts, Emergency Tensioning Devices, seat belt anchorages or seat belt retractors.

- Make sure that the seat belts are undamaged, not worn and clean.
- Always have the seat belts checked immediately after an accident at a qualified specialist workshop.

Only use seat belts which have been approved for your vehicle by Mercedes-Benz.

▲ WARNING Risk of injury or death from deployed pyrotechnic Emergency Tensioning Devices

Pyrotechnic Emergency Tensioning Devices that have been deployed are no longer operational and are unable to perform their intended protective function.

 Therefore, have deployed pyrotechnic Emergency Tensioning Devices immediately replaced at a qualified specialist workshop.

Mercedes-Benz recommends that you have the vehicle towed to a qualified specialist workshop after an accident.

NOTE Damage caused by trapping the seat belt

If an unused seat belt is not fully retracted, it may become trapped in the door or in the seat mechanism.

Always ensure that an unused seat belt is fully retracted.


#### Extending/retracting the seat belt extender

The seat belt extender for the front seat helps you fasten your seat belt. When the door is closed, the seat belt extender extends.

Mercedes-AMG vehicles: observe the notes in the Supplement. Otherwise, you may fail to recognize dangers. The seat belt extender button is not available in Mercedes-AMG vehicles.

You can also extend the seat belt extender using the seat belt extender button.





- Switch on the ignition.
- Press seat belt extender button ①. The seat belt extender extends.

The seat belt extender retracts again in the following cases:


 The seat belt tongue is engaged in the seat belt buckle

- The seat belt tongue is not engaged in the seat belt buckle within 60 seconds
   If you press seat belt extender button again in this case, the seat belt extender will extend again.
- The respective door is opened
- · You fold the seat backrest forwards
- Nobody is sitting in the front passenger seat
  If you press seat belt extender button
  again in this case, the seat belt extender will
  no longer extend.

The seat belt extender must always be retracted while the vehicle is in motion.

#### **Fastening seat belts**

If the seat belt is pulled quickly or sharply, the seat belt retractor locks. The seat belt strap cannot be pulled out any further.



Always engage seat belt tongue ② of the seat belt into seat belt buckle ③ of the corresponding seat.

Vehicles with automatic front passenger front airbag shutoff:



I NOTE Deployment of the Emergency Tensioning Device and side air bag when the front passenger seat is unoccupied

If the seat belt tongue is engaged in the seat belt buckle of the unoccupied front passenger seat, the Emergency Tensioning Device and the side air bag may also deploy in the event of an accident along with other systems.

Only one person should use each seat belt at any one time.

Vehicles without automatic front passenger front airbag shutoff:

NOTE Deployment of the Emergency Tensioning Device when the frontpassenger seat is unoccupied

If the seat belt tongue is engaged in the seat belt buckle of the unoccupied frontpassenger seat, the Emergency Tensioning Device may also deploy in the event of an accident along with other systems. Only one person should use each seat belt at any one time.

### Seat belt adjustment function

Vehicles with PRE-SAFE®: If the front seat belt is not pulled tight across your body, the seat belt adjustment may automatically apply a certain tightening force. Do not hold the seat belt tightly while it is adjusting.

#### Releasing seat belts

Press the release button in the seat belt buckle and guide the seat belt back with the seat belt tongue.

# Activating/deactivating seat belt adjustment via the multimedia system

Multimedia system:

- → Vehicle → 😝 Vehicle Settings
- ▶ Belt Adjustment
- ▶ Activate or deactivate the function.

# Seat belt warning function for the driver and front passenger

The <u>\*</u> seat belt warning lamp in the Instrument Display is a reminder that all vehicle occupants must wear their seat belts correctly.

The seat belt warning lamp lights up for six seconds every time the vehicle is started.

In addition, a warning tone may sound.

When the driver's and front passenger's doors are closed and the driver and front passenger have fastened their seat belts, the seat belt warning goes out.




In the following cases, the seat belt warning lights up during a journey if:

- The vehicle speed exceeds 15 mph (25 km/h) and the driver's or front passenger seat belt is not fastened.
- The driver or front passenger unfastens their seat belt while the vehicle is in motion.

### Airbags

### Overview of airbags



- Driver's knee bag
- Oriver's airbag

- Front passenger front airbagFront passenger knee airbag
- Window curtain airbag
- Side impact airbag

The installation location of an airbag is identified by the airbag symbol.

When activated, an airbag can provide additional protection for the respective vehicle occupant.

#### Potential protection from each airbag:

Airbag	Potential protection for
Knee airbag	Thigh, knee and lower leg
Driver's airbag, front passenger front airbag	Head and ribcage
Window curtain airbag	Head
Side impact air- bag	Ribcage, also pelvis for front seat occupants

I NOTE Important points to remember if the front passenger seat is unoccupied

In an accident, the components of the restraint system may deploy unnecessarily on the front passenger side if:

- There are heavy objects on the front passenger seat.
- The seat belt tongue is engaged in the seat belt buckle of the front passenger seat and the front passenger seat is unoccupied.
- Stow objects in a suitable place.
- Only one person should use each seat belt at any one time.

### Protection by the airbags

Depending on the accident situation, an airbag may supplement the protection offered by a correctly fastened seat belt.

# WARNING Risk of injury or death due to incorrect seat position

If you deviate from the correct seat position, the air bag cannot perform its intended protective function and deployment may even cause further injuries.

To avoid hazardous situations, always make sure that all vehicle occupants:

- Have their seat belt fastened correctly, including pregnant women.
- Are seated properly and that distance to the air bags is as large as possible.
- Observe the following information.
- Always make sure that there are no objects between the air bag and the vehicle occupant.



To avoid the risks resulting from the deployment of an airbag, each vehicle occupant must observe the following information:

- Before starting your journey, adjust your seat correctly; the driver's seat and frontpassenger seat should be moved as far back as possible.
  - When doing so, always observe the information on the correct driver's seat position  $(\longrightarrow)$  page 79).
- Only hold the steering wheel by the steering wheel rim. This allows the airbag to be fully deployed.
- Always lean against the seat backrest when the vehicle is in motion. Do not lean forwards or against the door or side window. You may otherwise be in the deployment area of the airbags.
- Always keep your feet on the floor. Do not put your feet on the cockpit, for example. Your feet may otherwise be in the deployment area of the airbag.

- If children are traveling in the vehicle, observe the additional notes.  $(\longrightarrow)$  page 45).
- · Always stow and secure objects correctly.

Objects in the vehicle interior may prevent an airbag from functioning correctly. Each vehicle occupant must always make sure of the following:

- There are no people, animals or objects between the vehicle occupants and an airbag.
- There are no objects between the seat, door and door pillar (B-pillar).
- There are no hard objects, e.g. coat hangers, hanging on the grab handles or coat hooks.
- There are no accessory parts, such as PNDs (Personal Navigation Devices), mobile phones or cup holders attached to the vehicle within the deployment area of an airbag, e.g. on the cockpit, on doors, side windows or side paneling.

In addition, no connecting cable, tensioning

strap or retaining strap may be routed

through or attached in the deployment area of an airbag. Always observe the accessory manufacturer's installation instructions. in particular the information on suitable places for installation.

There are no heavy, sharp-edged or fragile objects in the pockets of your clothing. Store such objects in a suitable place.

### Limited protection from airbags



WARNING Risk of injury due to modifications to the airbag cover

If you modify the cover of an airbag or affix objects such as stickers to it, the airbag may no longer function correctly.

Never modify the cover of an airbag and do not affix objects to it.

The installation location of an airbag is identified by the AIRBAG symbol ( page 35).



# **WARNING** Risk of injury or death due to the use of unsuitable seat covers

Unsuitable seat covers can obstruct or prevent the deployment of air bags integrated into the seats.

Consequently, the air bags cannot protect vehicle occupants as they are designed to do. In addition, operation of the automatic front passenger air bag shutoff may be restricted.

You should only use seat covers that have been approved for the corresponding seats by Mercedes-Benz.

# **WARNING** Risk of injury due to malfunctions of the sensors in the door paneling

Sensors to control the airbags are located in the doors. Modifications or work not performed correctly to the doors or door paneling, as well as damaged doors, can lead to the function of the sensors being impaired. The airbags might therefore not function properly any more.

Consequently, the airbags cannot protect vehicle occupants as they are designed to do.

- Never modify the doors or parts of the doors.
- Always have work on the doors or door paneling carried out at a qualified specialist workshop.

# **WARNING** Risk of injury due to deployed airbag

A deployed airbag no longer has a protective function and cannot protect as intended in the event of an accident.

Have the vehicle towed to a qualified specialist workshop in order to have the deployed airbag replaced.

Have deployed airbags replaced immediately.



### Status of the front passenger front airbag

# Function of the automatic front passenger front airbag shutoff

The automatic front passenger front airbag shutoff is able to detect whether the front passenger seat is occupied by a person or a child restraint system. The front passenger front airbag and front passenger knee airbag are enabled or disabled accordingly.

When installing a child restraint system on the front passenger seat, always make sure of the following:

- Ensure that the child restraint system is positioned correctly ( page 44).
- Always observe the child restraint system manufacturer's installation instructions.
- Never place objects, e.g. cushions, under or behind the child restraint system.
- Fully retract the seat cushion length adjustment.
- The entire base of the child restraint system must always rest on the seat cushion of the front passenger seat.

- The backrest of the forward-facing child restraint system must lie as flat as possible against the backrest of the front passenger seat.
- The child restraint system must not touch the roof or be put under strain by the head restraints. Adjust the seat backrest inclination and the head restraint setting accordingly.

▲ WARNING Risk of injury or death due to objects between the sitting surface and the child restraint system

Objects between the sitting surface and the child restraint system could affect the function of the automatic front passenger airbag shutoff.

This could result in the front passenger airbag not functioning as intended during an accident.

Do not place any objects between the sitting surface and the child restraint system.

- The entire base of the child restraint system must always rest on the sitting surface of the front passenger seat.
- The backrest of the forward-facing child restraint system must, as far as possible, be resting on the seat backrest of the front passenger seat.
- Always comply with the child restraint system manufacturer's installation instructions.

A person on the front passenger seat must observe the following information:

- Fasten seat belts correctly ( page 30).
- Sit in an almost upright seat position with their back against the seat backrest.
- Sit with their feet resting on the floor, if possible.

The front passenger front airbag may otherwise be disabled by mistake, for example in the following situations:

 The front passenger transfers their weight by supporting themselves on a vehicle armrest.  The front passenger sits in such a way that their weight is raised from the sitting surface.

**WARNING** Risk of injury or death due to deactivated front passenger airbag

If the PASSENGER AIR BAG OFF indicator lamp is lit, the front passenger airbag is disabled. It will not be deployed in the event of an accident and cannot perform its intended protective function.

A person in the front passenger seat could then, for example, come into contact with the vehicle interior, especially if the person is sitting too close to the cockpit.

If the front passenger seat is occupied, always ensure that:


 The classification of the person in the front passenger seat is correct and the front passenger airbag is enabled or disabled in accordance with the person in the front passenger seat.



- The front passenger seat has been moved as far back as possible.
- · The person is seated correctly.
- Ensure, both before and during the journey, that the status of the front passenger airbag is correct.

If the front passenger seat is occupied, the classification of the person or child restraint system on the front passenger seat takes place after the front passenger front airbag shutoff self-test. The PASSENGER AIR BAG indicator lamps display the status of the front passenger front airbag.

# Function of the PASSENGER AIR BAG indicator lamps



# Self-test of automatic front passenger front airbag shutoff

When the ignition is switched on, a self-test is performed during which the two PASSENGER AIR BAG ON and OFF indicator lamps light up simultaneously.

DEALER ePROCESS

The status of the front passenger front airbag is displayed after the self-test:

- PASSENGER AIR BAG ON lights up for 60 seconds, subsequently both indicator lamps are off (PASSENGER AIR BAG ON and OFF): the front passenger front airbag is able to deploy in the event of an accident.
- PASSENGER AIR BAG OFF lights up continuously: the front passenger front airbag is disabled. It will then not be deployed in the event of an accident.

If the PASSENGER AIR BAG ON indicator lamp is off, only the PASSENGER AIR BAG OFF indicator lamp shows the status of the front passenger front airbag. The PASSENGER AIR BAG OFF indicator lamp may be lit continuously or be off.

If the PASSENGER AIR BAG OFF indicator lamp and the prestraint system warning lamp light up simultaneously, the front passenger seat may not be used. Also in this case, do not install a child restraint system on the front passenger seat. Have automatic front passenger front airbag shutoff checked and repaired immediately at a qualified specialist workshop.

#### Status display

If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger front airbag is correct for the current situation.

After installing a rearward-facing child restraint system on the front passenger seat: PASSENGER AIR BAG OFF must be lit continuously.

A

**WARNING** Risk of injury or death from using a rearward-facing child restraint system when the front passenger front airbag is enabled

If you secure a child in a rearward-facing child restraint system on the front passenger seat and the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag can deploy in the event of an accident.

The child could be struck by the airbag.

Always ensure that the front passenger airbag is deactivated. The PASSENGER AIR BAG OFF indicator lamp must be lit.

NEVER use a rearward-facing child restraint system on a seat protected by an ENABLED FRONT AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

When installing a child restraint system on the front passenger seat, observe the vehicle-specific information (———> page 53).

Depending on the child restraint system and the stature of the child, the PASSENGER AIR BAG OFF indicator lamp may be off. In this case, do not install the rearward-facing child restraint system on the front passenger seat.

Instead, install the rearward-facing child restraint system on a suitable rear seat.

After installing a forward-facing child restraint system on the front passenger seat: depending on the child restraint system and the stature of the child, PASSENGER AIR BAG OFF may be lit continuously or be off. Always observe the following information.



WARNING Risk of injury or death due to incorrect positioning of the forward-facing child restraint system

If you secure a child in a forward-facing child restraint system on the front passenger seat and you position the front passenger seat too close to the dashboard, in the event of an accident, the child could:

- come into contact with parts of the vehicle interior if the PASSENGER AIR BAG OFF indicator lamp is lit, for example
- be struck by the airbag if the PASSENGER AIR BAG OFF indicator lamp is off
- Always move the front passenger seat as far back as possible and fully retract the seat cushion length adjustment. Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet on the vehicle to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from

- the seat belt outlet. If necessary, adjust the front passenger seat accordingly.
- Always observe the child restraint system manufacturer's installation instructions.

If a person is sitting on the front passenger seat: PASSENGER AIR BAG OFF may be lit continuously or be off, depending on the person's stature.

A person on the front passenger seat must always observe the following information:

- If the front passenger seat is occupied by an adult or a person with a stature corresponding to that of an adult, the PASSENGER AIR BAG OFF indicator lamp must be off. This indicates that the front passenger front airbag is enabled.
  - If the PASSENGER AIR BAG OFF indicator lamp is lit continuously, an adult or person with a build corresponding to that of an adult

- should not use the front passenger seat. Instead, they should use a rear seat.
- If the front passenger seat is occupied by a person of smaller stature (e.g. a teenager or small adult), the PASSENGER AIR BAG OFF indicator lamp either lights up continuously or remains off, depending on the result of the classification.
  - If the PASSENGER AIRBAG OFF indicator lamp is off: move the front passenger seat as far back as possible or the person of smaller stature should use a rear seat.
  - If the PASSENGER AIRBAG OFF indicator lamp is lit continuously: the person of smaller stature should not use the front passenger seat.
- WARNING Risk of injury or death when the PASSENGER AIR BAG OFF indicator lamp is lit

If the PASSENGER AIR BAG OFF indicator lamp remains lit after the system self-test, the front passenger air bag is deactivated. It will not be deployed in the event of an acci-

DEALER ePROCESS

dent. In this case, the front passenger air bag cannot perform its intended protective function, e.g. when a person is seated in the front passenger seat.

That person could, for example, come into contact with the vehicle interior, especially if the person is sitting too close to the cockpit. If the front passenger seat is occupied, always ensure that:

- The classification of the person in the front passenger seat is correct and the front passenger air bag is enabled or deactivated in accordance with the person in the front passenger seat.
- The person is seated properly with a correctly fastened seat belt.
- The front passenger seat has been moved as far back as possible.

# Be sure to also observe the following further related subjects:

 Child restraint system on the front passenger seat ( page 53).

#### PRE-SAFE® system

# PRE-SAFE® (anticipatory occupant protection)

PRE-SAFE® is able to detect certain critical driving situations and implement pre-emptive measures to protect the vehicle occupants.

PRE-SAFE® can implement the following measures independently of each other:

- Tightening the seat belts on the driver's seat and front passenger seat.
- · Closing the side windows.
- Vehicles with sliding sunroof: Closing the sliding sunroof.
- Vehicles with memory function: Moving the front passenger seat to a more favorable seat position.
- Vehicles with multicontour seat: Increasing the air pressure in the seat side bolsters of the seat backrest.
- PRE-SAFE<sup>®</sup> Sound: provided that the multimedia system is switched on, generates a

brief noise signal to stimulate the innate protective mechanism of a person's hearing.



**NOTE** Damage caused by objects in the footwell or behind the seat

The automatic adjustment of the seat position may result in damage to the seat and/or the object.

Stow objects in a suitable place.

### Reversing the PRE-SAFE® system measures

If an accident did not occur, the pre-emptive measures that were taken are reversed.

You will need to perform certain settings yourself.

If the seat belt pre-tensioning is not reduced, move the seat backrest back slightly. The locking mechanism releases.



# Function of PRE-SAFE® PLUS (anticipatory occupant protection plus)

PRE-SAFE® PLUS can detect certain impacts, particularly an imminent rear impact, and take pre-emptive measures to protect the vehicle occupants. These measures cannot necessarily prevent an imminent impact.

PRE-SAFE® PLUS can implement the following measures independently of each other:

- Tightening the seat belts on the driver's seat and front passenger seat.
- Increasing brake pressure when the vehicle is stationary. This brake application is canceled automatically when the vehicle pulls away.

If an accident did not occur, the pre-emptive measures that were taken are reversed.

#### **System limitations**

The system will not initiate any action in the following situations:

· when backing up

The system will not initiate any braking application in the following situations:

- whilst driving or
- · when entering or exiting a parking space while using Active Parking Assist

# Safely transporting children in the vehicle

### Always observe when children are traveling in the vehicle

Also strictly observe the safety notes for the specific situation. In this way you can recognize potential risks and avoid dangers if children are traveling in the vehicle  $(\longrightarrow)$  page 45).

#### Be diligent

Bear in mind that neglecting to secure a child in the child restraint system may have serious consequences. Always be diligent in securing a child carefully before every journey.

To improve protection for children younger than 12 years old or under 5 ft (1.50 m) in height, Mercedes-Benz recommends you observe the following information:

- Always secure the child in a child restraint system suitable for this Mercedes-Benz vehicle.
- The child restraint system must be appropriate to the age, weight and size of the child.
- The vehicle seat must be suitable for installing a child restraint system.

Accident statistics show that children secured in the rear seats are generally safer than children secured in the front seats. For this reason. Mercedes-Benz strongly advises that you install a child restraint system on a rear seat.

#### Generic term "child restraint system"

The generic term child restraint system is used in this Operator's Manual. A child restraint system is, for example:

- a baby car seat
- · a rearward-facing child seat



- a forward-facing child seat
- a child booster seat with a backrest and seat belt guide

Mercedes-Benz recommends using a child booster seat with a backrest.

The child restraint system must be appropriate to the age, weight and size of the child.

Observing laws and legal requirements Always observe the legal requirements when using a child restraint system in the vehicle.

#### Observing standards for child restraint systems

All child restraint systems must meet the following standards:

- U.S. Federal Motor Vehicle Safety Standards 213 and 225
- Canadian Motor Vehicle Safety Standards 213 and 210.2

Confirmation that the child restraint system complies with the standards can be found on an instruction label on the child restraint system. This confirmation can also be found in the installation instructions that are included with the child restraint system.

#### Detecting risks, avoiding danger

### Securing systems for child restraint systems in the vehicle

Only use the following securing systems for child restraint systems:

- the LATCH-type (ISOFIX) mounting brackets
- the vehicle's seat belt system
- the Top Tether anchorages

Installing a LATCH-type (ISOFIX) child restraint system is preferred.

Simply attaching to the securing rings on the vehicle can reduce the risk of installing the child restraint system incorrectly.

A booster seat may be necessary to achieve proper seat belt positioning for children over 40 lbs (18 kg) in weight or until they reach a height where a three-point seat belt can be installed properly without a booster seat.

Mercedes-Benz recommends a suitable child booster seat with a backrest and seat belt guide.

# Advantage of a rearward-facing child restraint system

It is preferable to transport a baby or a small child in a suitable rearward-facing child restraint system. In this case, the child sits in the opposite direction to the direction of travel and faces backwards.

Babies and small children have comparatively weak neck muscles in relation to the size and weight of their head. The risk of injury to the cervical spine during an accident can be reduced in a rearward-facing child restraint system.



# Always secure a child restraint system correctly



**WARNING** Risk of injury or death caused by incorrect installation of the child restraint system

If the child restraint system is incorrectly installed on a suitable seating position, it cannot perform its intended protective function.

The child cannot be restrained in the event of an accident, heavy braking or a sudden change of direction.

- Always comply with the manufacturer's installation instructions for the child restraint system and its correct use.
- Make sure that the entire base of the child restraint system always rests on the sitting surface of the seat.
- Never place objects under or behind the child restraint system, e.g. cushions.

- Always use child restraint systems with the original cover designed for them.
- Always replace damaged covers with genuine covers.

# ▲ WARNING Risk of injury or death from unsecured child restraint systems in the vehicle

If the child restraint system is not correctly installed or secured, it could release in the event of an accident, sudden braking or a sudden change in direction.

The child restraint system could be flung around and hit vehicle occupants.

- Always install child restraint systems correctly, even when not in use.
- Always comply with the child restraint system manufacturer's installation instructions.
- Always observe the child restraint system manufacturer's installation and operating

instructions as well as the vehicle-specific information:

- Install the LATCH-type (ISOFIX) child restraint system on the rear seat ( page 49).
- Secure the child restraint system with the seat belt on the rear seat
   page 52).
- Secure the child restraint system with the seat belt on the front passenger seat
   ( >> page 53). Observe the specific instructions for the rearward-facing and forward-facing child restraint systems
   ( >> page 53).

- Observe the warning labels in the vehicle interior and on the child restraint system.
- Also secure Top Tether if present.



#### Do not alter the child restraint system

**WARNING** Risk of injury due to modifications to the child restraint system

The child restraint system may no longer function as it is supposed to if you make modifications or attach objects to it, e.g. toys or unsuitable accessories. This poses an increased risk of injury!

Never modify the child restraint system. Only attach accessories which the manufacturer of the child restraint system has authorized especially for this child restraint system.

# Only use child restraint systems which are in proper working condition

▲ WARNING Risk of injury or death caused by the use of damaged child restraint systems

Child restraint systems or their retaining systems that have been subjected to a load in an accident may then not be able to perform their intended protective function.

The child cannot be restrained in the event of an accident, heavy braking or a sudden change of direction.

- Always replace child restraint systems immediately that have been damaged or involved in an accident.
- Have the securing systems for the child restraint systems checked at a qualified specialist workshop before installing a child restraint system again.

### Avoiding direct sunlight

**WARNING** Risk of burns when the child seat is exposed to direct sunlight

If the child restraint system is exposed to direct sunlight or heat, parts could heat up. Children could suffer burns from these parts, particularly on metallic parts of the child restraint system.

Always make sure that the child restraint system is not exposed to direct sunlight.

- Protect it with a blanket, for example.
- If the child restraint system has been exposed to direct sunlight, allow it to cool before securing a child into it.
- Never leave children unattended in the vehicle.

#### Observe when stopping or parking


WARNING Risk of accident and injury due to children and animals left unattended in the vehicle

If you leave children and animals unattended in the vehicle, they may be able to set the vehicle in motion, for example by:

- · Releasing the parking brake.
- Shifting the automatic transmission out of park position P.
- Starting the engine.

In addition, they may operate vehicle equipment and become trapped.

DEALER EPROCESS



 When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

WARNING Risk of fatal injury due to exposure to extreme heat or cold in the vehicle

If people – particularly children – are exposed to extreme temperatures over an extended period of time, there is a risk of serious or even fatal injury.

- Never leave anyone particularly children unattended in the vehicle.
- Never leave animals in the vehicle unattended.

### Overview of suitable seats in the vehicle for installing a child restraint system

### Securing systems for child restraint systems

Vehicle seat		
Left/right rear seat	Preferred securing system:  LATCH-type (ISOFIX) child seat securing system  Also secure Top Tether if present  ( ) page 51)	Alternative securing system:  • Vehicle seat belt
Front passenger seat	Securing system:  • Vehicle seat belt	<ul> <li>Be sure to observe:</li> <li>If the front passenger seat is occupied, ensure, both before and during the journey, that the status of the front passenger front airbag is correct for the current situation (—&gt;&gt; page 40).</li> <li>Notes on automatic front passenger front airbag shutoff (—&gt;&gt; page 38).</li> </ul>



## Activating/deactivating the seat belt's child special seat belt retractor

A

**WARNING** Risk of injury or death if a seat belt is unfastened while the vehicle is in motion

If the seat belt is released while the vehicle is in motion, the child restraint system is no longer correctly secured. The child seat safety feature is deactivated and the seat belt is drawn in a bit by the inertia reel.

It is therefore not possible to engage the seat belt again.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- Activate the child seat safety feature again and correctly secure the child restraint system.

When enabled, the special seat belt retractor ensures that the seat belts of the front passenger seat and rear seats do not slacken once the child restraint system is secured.

The seat belts on the following seats are equipped with a special seat belt retractor:

- Front passenger seat
- Rear seats
- To install a child restraint system: when installing a child restraint system, always observe the manufacturer's installation and operating instructions as well as the information in this Operator's Manual.
- Pull the seat belt smoothly from the seat belt outlet.
- Engage the seat belt tongue in the seat belt buckle.
- To activate the special seat belt retractor: pull the seat belt out fully and let the inertia reel retract it again. When the special seat belt retractor is activated, you should hear a ratcheting sound.
- Push the child restraint system down until the seat belt sits tightly.
- To deactivate the special seat belt retractor: press the release button of the seat belt buckle.

Hold the seat belt tongue and guide back to the seat belt outlet.

# Installing the LATCH-type (ISOFIX) child restraint system on the rear seat

Installing the LATCH-type (ISOFIX) child restraint system on the rear seat



WARNING Risk of injury or death if the permissible gross mass of the child and child restraint system is exceeded

For LATCH-type (ISOFIX) child restraint systems in which the child is secured using the integrated seat belt in the child restraint system, the permissible gross mass of the child and child restraint system is 73 lb (33 kg).

If the child and the child restraint system together weigh more than 73 lb (33 kg), the LATCH-type (ISOFIX) child restraint system with integrated seat belt does not offer sufficient protection. An excessive load may be placed on the LATCH-type (ISOFIX) child seat attachments and the child may not be



restrained in the event of an accident, for example.

- If the child and the child restraint system together weigh more than 73 lb (33 kg), use only a LATCH-type (ISOFIX) child restraint system that secures the child with the vehicle seat belt.
- Also secure the child restraint system with the Top Tether belt, if available.

Always comply with the information about the mass of the child restraint system:

- in the manufacturer's installation and operating instructions for the child restraint system used
- on a label on the child restraint system, if present

Regularly check that the permissible gross mass of the child and child restraint system is still complied with.

When you are installing a child restraint system, observe the following:


- Always observe the correct use and the suitability of the seats for attaching a child restraint system.
- Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- Make sure that the child's feet do not touch the front seat. If necessary, move the front seat forward slightly.

When you are installing a LATCH-type (ISOFIX) child restraint system, observe the following:

- When you are using a Group 0/0+ baby car seat and a Group 1 rearward-facing child restraint system on a rear seat: adjust the front seat so that the seat does not touch the child restraint system.
- When you are using a Group 1 forwardfacing child restraint system: the backrest of the child restraint system must, as

DEALER ePROCESS

- far as possible, lie flat against the backrest of the vehicle seat.
- For certain child restraint systems in weight group 2 or 3, there may be restrictions in the maximum size setting, e.g. due to possible contact with the roof.
- The child restraint system must not be tensioned between the roof and the seat cushion and/or be installed facing the wrong direction. Where possible, adjust the seat cushion inclination accordingly.
- The child restraint system must not be put under strain by the head restraints. Adjust the head restraints accordingly.



Before every trip, make sure that the LATCH-type (ISOFIX) child restraint system is engaged correctly in both mounting brackets in the vehicle.

- Fold the upholstered lining 1 upwards.
- Turn the support on the rear side of the upholstered lining by 90°. The upholstered lining will remain folded upwards.

Attach the LATCH-type (ISOFIX) child restraint system to both mounting brackets in the vehicle.


### **Securing Top Tether**



If the child restraint system is equipped with a Top Tether belt:

The risk of injury can be reduced by Top Tether. The Top Tether belt facilitates an additional connection between the child restraint system attached with LATCH-type (ISOFIX) and the vehicle.





- If necessary, move head restraint upwards ( page 84).
- Fold up cover 
  onumber of Top Tether anchorage
  onumber of Top Tether anchorage
- Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Always comply with the child restraint system manufacturer's installation instructions when doing so.



- Guide Top Tether belt (a) under head restraint (b) between the two head restraint bars.
- Hook Top Tether hook (3) of Top Tether belt
   (4) without twisting into Top Tether anchorage
   (3) .
- Tension Top Tether belt . Always comply with the child restraint system manufacturer's installation instructions when doing so.
- Fold down cover of Top Tether anchorage .
- If necessary, slide head restraint downwards (→ page 84). Make sure that you

do not interfere with the correct routing of Top Tether belt 4.

### Securing the child restraint system with the seat belt

# Securing the child restraint system with the seat belt on the rear seat

When installing a belt-secured child restraint system, observe the following:

- Always comply with the manufacturer's installation and operating instructions for the child restraint system used.
- When using a category 0/0+ baby car seat and a category I rearward-facing child restraint system on a rear seat: adjust the front seat so that the seat does not touch the child restraint system.
- ▼ The backrest of the forward-facing child restraint system must, as far as possible, be resting on the seat backrest of the rear seat.
- For certain child restraint systems in weight category II or III, there may be restrictions in

- the maximum size setting, e.g. due to possible contact with the roof.
- ▼ The child restraint system must not be put under strain between the roof and the seat cushion and/or be installed facing the wrong direction. Where possible, adjust the seat cushion inclination accordingly.
- The child restraint system must not be put under strain by the head restraints. Adjust the head restraints accordingly.
- Make sure that the child's feet do not touch the front seat. If necessary, move the front seat forward slightly.

The seat belts on the following seats are equipped with a special seat belt retractor:

- Front passenger seat
- · Rear seats

- Install the child restraint system. The entire base of the child restraint system must always rest on the sitting surface of the rear seat.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from the seat belt outlet.

Notes on rearward-facing and forward-facing child restraint systems on the front passenger seat

▲ WARNING Risk of injury or death from using a rearward-facing child restraint system when the front passenger front airbag is enabled

If you secure a child in a rearward-facing child restraint system on the front passenger seat and the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger airbag can deploy in the event of an accident.

The child could be struck by the airbag.

Always ensure that the front passenger airbag is deactivated. The PASSENGER AIR BAG OFF indicator lamp must be lit.

NEVER use a rearward-facing child restraint system on a seat protected by an ENABLED FRONT AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

Warning notice on the front passenger sun visor

Always observe the status of the front passenger front airbag on the PASSENGER AIR BAG OFF indicator lamp:

 When using a rearward-facing child restraint system on the front passenger seat, the front passenger front airbag must always be disabled. This is only the case if the PASSENGER AIR BAG OFF indicator lamp is lit continuously ( page 40).

DEALER ePROCESS

 If the PASSENGER AIR BAG OFF indicator lamp is off, the front passenger front airbag is enabled. The front passenger front airbag may deploy during an accident.

# Securing the child restraint system with the seat belt on the front passenger seat

When installing a belt-secured child restraint system on the front passenger seat, always observe the following:

- Observe the child restraint system manufacturer's installation and operating instructions.
- When using a forward-facing child restraint system in Group I: remove the head restraint from the respective seat, if possible.

When you remove the child restraint system, install the head restraint again immediately and adjust all the head restraints correctly.

▼ The backrest of the forward-facing child restraint system must lie as flat as possible

against the backrest of the front passenger seat.

- For certain child restraint systems in weight group II or III, there may be restrictions in the maximum size setting, e.g. due to possible contact with the roof.
- ▼ The child restraint system must not be put under strain between the roof and the seat cushion and/or be installed facing the wrong direction. Adjust the seat backrest inclination accordingly.
- The child restraint system must not be put under strain by the head restraints. Adjust the head restraints accordingly.
- ✓ Never place objects under or behind the child restraint system, e.g. cushions.

The seat belt on the front passenger side is equipped with a special seatbelt retractor.

- Set the front passenger seat as far back as possible and move the seat into the highest position.
- Fully retract the seat cushion length adjustment.
- Adjust the seat cushion inclination so that the front edge of the seat cushion is in the highest position and the rear edge of the seat cushion is in the lowest position.
- Set the seat backrest to an almost vertical position.
- Install the child restraint system. The entire base of the child restraint system must always rest on the seat cushion of the front passenger seat.
- Always make sure that the shoulder belt strap is correctly routed from the seat belt outlet of the vehicle to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from the seat belt outlet.
- If necessary, adjust the seat belt outlet and the front passenger seat accordingly.

#### DEALER EPROCESS

#### Notes on pets in the vehicle

A

WARNING Risk of accident and injury due to animals left unsecured or unattended in the vehicle

If you leave animals in the vehicle unattended or unsecured, they could possibly press down buttons or switches.

Thereby an animal may:

- activate vehicle equipment and become trapped, for example
- switch systems on or off and endanger other road users

Unsecured animals may be thrown around in the vehicle in the event of an accident or sudden steering and braking maneuver and injure vehicle occupants in the process.

- Never leave animals in the vehicle unattended.
- Always correctly secure animals while driving, for example using a suitable animal carrier.

#### **SmartKey**

#### **Overview of SmartKey functions**

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- open doors, thereby endangering other persons or road users.
- get out of the vehicle and be hit by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, children could also set the vehicle in motion, for example, by:

- releasing the parking brake.
- shifting the automatic transmission out of park position P.
- starting the engine

- Never leave children and animals unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.
- ! NOTE Damage to the key caused by magnetic fields
- Keep the key away from strong magnetic fields.



- Locks
- ② Battery check lamp
- Unlocks
- Opens/closes the trunk lid
- Panic alarm

The SmartKey locks and unlocks the following components:

- Doors
- Trunk lid
- · Fuel filler flap



If you do not open the vehicle within approximately 40 seconds after unlocking:

- · The vehicle is locked again
- Anti-theft protection is reactivated

Do not keep the SmartKey together with electronic devices or metal objects. This can affect the SmartKey's functionality.

i If battery check lamp ② does not light up after pressing the for or button, the battery is discharged.

# Activating/deactivating the acoustic locking verification signal

Multimedia system:

- → Vehicle ➤ 😝 Vehicle Settings
- ➤ Acoustic Lock
- ▶ Activate or deactivate the function.

### Activating/deactivating the panic alarm

#### Requirements:

• The ignition is switched off

i The panic alarm function is only available in certain countries.



- To activate: press button (1) for approximately one second.
- A visual and audible alarm is triggered.
- ► To deactivate: briefly press button ① again.

or

Press the start/stop button on the cockpit (the SmartKey is inside the vehicle).

### Changing the unlocking settings

Possible unlocking functions of the SmartKey:

Central unlocking

DEALER ePROCESS

- Unlocking the driver's door and fuel filler flap

If the unlocking function for the driver's door and fuel filler flap has been selected:


- Pressing the button a second time centrally unlocks the vehicle
- Vehicles with KEYLESS-GO: If you touch the inner surface of the door handle on the driver's door, only the driver's door and fuel filler flap are unlocked.

#### **Deactivating the SmartKey functions**

If you do not use the vehicle or a SmartKey for an extended period of time, you can reduce the energy consumption of the respective Smart-Key . To do so, deactivate the SmartKey functions.

- ➤ To deactivate: press the button on the SmartKey twice in quick succession. The battery check lamp of the SmartKey flashes twice briefly and lights up once.
- **To activate:** press any button on the Smart-Key.

### Removing/inserting the emergency key



- To remove: press release button ①.
  Emergency key ② is pushed out slightly.
- Pull out emergency key ② until it engages in the intermediate position.
- i You can use the intermediate position of emergency key ② to attach the SmartKey to a key ring.
- Press release button **(1)** again and fully remove emergency key **(2)**.
- To insert: press release button 1.
- Insert emergency key ② to the intermediate position or fully until it engages.

### Replacing the SmartKey battery

**DANGER** Serious damage to health caused by swallowing batteries

Batteries contain toxic and corrosive substances. Swallowing batteries may cause serious damage to health.

DEALER EPROCESS

There is a risk of fatal injury.

- Keep batteries out of the reach of children.
- If batteries are swallowed, seek medical attention immediately.

ENVIRONMENTAL NOTE Environmental damage caused by improper disposal of batteries

Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.

Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified specialist workshop or to a collection point for used batteries.

#### Requirements:

• You require a CR 2032 3 V cell battery.

Mercedes-Benz recommends that you have the battery replaced at a qualified specialist workshop.

▶ Remove the mechanical key (→ page 57).



- Press release button ② down fully and remove cover ①.
- Remove battery compartment (3) and take out the discharged battery.
- Insert the new battery into battery compartment (3). Observe the positive pole marking in the battery compartment and on the battery.
- Push in battery compartment 3.
- Replace cover ① so that it engages.

#### **Problems with the SmartKey**

#### Problem

You can no longer lock or unlock the vehicle.

### Possible causes/consequences and ▶ Solutions

Possible causes are:


- The SmartKey battery is discharged or nearly discharged.
- There is interference from a powerful radio signal source.



Problem	Possible causes/consequences and ▶ Solutions	
	The SmartKey is defective.	
	<ul> <li>Check the battery using the battery check lamp and replace if necessary ( &gt;&gt; page 57).</li> <li>Use the emergency key to lock or unlock ( &gt;&gt; page 57).</li> <li>Have the SmartKey checked at a qualified specialist workshop.</li> </ul>	
You have lost a SmartKey.	<ul><li>Have the SmartKey deactivated at a qualified specialist workshop.</li><li>If necessary, have the mechanical lock changed as well.</li></ul>	

#### Doors

### Unlocking and opening doors from the inside




Pull door handle ②. Locking pin ① pops up when the door is unlocked.

### Locking the doors from the inside

Take the SmartKey with you when exiting the vehicle and close the driver's door.






Press down locking knob 
on the driver's door from the front passenger seat.

- Exit the vehicle and press down the locking knob on the front passenger door.
- Close the front passenger door.

#### Locking/unlocking the vehicle centrally from the inside



To unlock: press button 🕦.

► To lock: press button ②.

This does not lock or unlock the fuel filler flap. The vehicle is not unlocked:


- If you have locked the vehicle using the SmartKey.
- If you have locked the vehicle using KEY-LESS-GO.

#### Locking/unlocking the vehicle with KEY-LESS-GO

#### Requirements:

- The SmartKey is outside the vehicle.
- The distance between the SmartKey and the vehicle does not exceed 3 ft (1 m).
- The driver's door and the door at which the door handle is used are closed.





- To unlock the vehicle: touch the inner surface of the door handle.
- To lock the vehicle: touch sensor surface 1 or 2.
- Convenience closing: touch recessed sensor surface 2 for an extended period.
- Further information on convenience closing  $\rightarrow$  page 72).

If you open the trunk lid from outside, the trunk lid is automatically unlocked.


#### **Problems with KEYLESS-GO**

Problem	Possible causes/consequences and ▶ Solutions
You can no longer lock or unlock the vehicle using KEYLESS-GO.	Possible causes are:  The SmartKey battery is weak or discharged.  There is interference from a powerful radio signal source.  The SmartKey is defective.
	<ul> <li>Check the battery using the battery check lamp and replace if necessary ( page 57).</li> <li>Use the mechanical key to lock or unlock the vehicle ( page 57).</li> <li>Have the vehicle and SmartKey checked at a qualified specialist workshop.</li> </ul>

#### Switching the automatic locking feature on/off

The vehicle is locked automatically when the ignition is switched on and the wheels are turning faster than walking pace.





- ➤ To deactivate: press and hold button ⑥ for approximately five seconds until an acoustic signal sounds.
- To activate: press and hold button ② for approximately five seconds until an acoustic signal sounds.

In the following situations, there is a danger of being locked out when the function is activated:

• The vehicle is being towed/pushed.


The vehicle is being tested on a dynamometer.

## Information on the power closing function for the doors

If you push the door into the lock to the first detent position, the power closing function will automatically pull the door into the lock.




# Unlocking the driver's door with the emergency key



- Insert the emergency key as far as it will go into opening in the cover.
- Pull and hold the door handle.
- Pull the cover on the emergency key as straight as possible away from the vehicle until it releases.

Release the door handle.



- Turn the emergency key counter-clockwise to position 1.
- Carefully press the cover onto the lock cylinder until it engages and is seated firmly.

#### Trunk

#### Opening the trunk lid



### **DANGER** Risk of exhaust gas poisoning

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid is open when the engine is running, especially if the vehicle is in motion.

- Always switch off the engine before opening the trunk lid.
- Never drive with the trunk lid open.
- NOTE Damage to the trunk lid by obstacles above the vehicle


The trunk lid swings upwards when it is opened.

Therefore, make sure that there is sufficient clearance above the trunk lid.

You have the following options for opening the trunk lid:

- With the trunk lid unlocked, press the top of the Mercedes star.
- Pull the folded-out Mercedes star when the rear view camera is activated and the trunk lid is unlocked.
- Vehicles with trunk lid convenience closing: With the trunk lid stopped in an intermediate position, pull the trunk lid upwards and release as soon as it begins to open.
- i To open the trunk lid, pull on the folded-out Mercedes star when the rear view camera is activated.
- Press and hold the smartKey.





- Pull trunk lid remote operating switch ①.
- Vehicles with HANDS-FREE ACCESS: Make a kicking movement with your foot below the bumper ( page 66).

Vehicles with trunk lid convenience closing: If an item obstructs the trunk lid during the automatic opening process, the obstacle detection system will stop the trunk lid. The obstacle detection function is only an aid and is not a substitute for your attentiveness.

### Closing the trunk lid

**WARNING** Risk of injury from unsecured items in the vehicle

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be thrown around and thereby hit vehicle occupants.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around.
- Before the journey, secure objects, luggage or loads against slipping or tipping over.

Observe the notes on loading the vehicle.



**WARNING** Risk of becoming trapped during automatic closing of the trunk lid

Parts of the body could become trapped during automatic closing of the trunk lid. Moreover, people, e.g. children, may be standing in the closing area or may enter the closing area during the closing process.


- Make sure that nobody is in the vicinity of the closing area during the closing process.
- Use one of the following options to stop the closing process:
  - Press the ্র্রা button on the SmartKey.
  - Press or pull the remote operating switch on the driver's door.
  - Press the closing or locking button on the trunk lid.
  - Press the top of the star on the trunk lid.

**Vehicles with HANDS-FREE ACCESS:** It is also possible to stop the closing process by making a

kicking movement with your foot below the rear bumper.

You have the following options for closing the trunk lid:


- Vehicles with trunk lid convenience closing feature: Pull down the trunk lid slightly and release it as soon as it begins to close.
- Vehicles with trunk lid convenience closing feature: Press and hold the ক্র্যা button on the SmartKey (with the SmartKey in the vicinity of the vehicle).



- Vehicles with trunk lid convenience closing feature: Press closing button on the trunk lid.
- Vehicles with trunk lid convenience closing feature and KEYLESS-GO: Press locking button on the trunk lid.

If a SmartKey is detected outside the vehicle, the trunk lid will close and the vehicle will be locked.





- Vehicles with trunk lid convenience closing feature: Press trunk lid remote operating switch ①.

### Trunk lid automatic reversing feature

If an object obstructs the trunk lid during the automatic closing process, the trunk lid will

open again automatically. The automatic reversing feature is only an aid and is not a substitute for your attentiveness.

- When closing, make sure that no body parts are in the closing area.
- **WARNING** Risk of becoming trapped despite the reversing function

The reversing function does not react:

- to soft, light and thin objects, e.g. fingers.
- over the last  $\frac{1}{3}$  in (8 mm) of the closing path.

In these situations in particular, the reversing function cannot prevent someone being trapped.

- When closing, make sure that no body parts are in the closing area.
- If someone is trapped, use one of the following options:
  - Press the ্র্রা button on the SmartKey.
  - Press the remote operating switch on the driver's door.

- Press the closing or locking button on the trunk lid.
- Press the top of the star on the trunk lid.

#### **HANDS-FREE ACCESS function**



With HANDS-FREE ACCESS you can open, close or interrupt trunk lid movement by performing a kicking movement under the rear bumper.

The kicking movement triggers the opening or closing process alternately.

Observe the notes when opening (→ page 63) and closing (→ page 64) the trunk lid.

(i) A warning tone sounds while the trunk lid is opening or closing.

**WARNING** Risk of burns caused by a hot exhaust system

The vehicle exhaust system can become very hot. If you use HANDS-FREE ACCESS, you could burn yourself by touching the exhaust system.

 Always ensure that you only make a kicking movement within the detection range of the sensors.


- ! NOTE Damage to the vehicle caused by unintentionally opening the trunk lid
- When using an automatic car wash
- When using a high pressure cleaner
- Deactivate KEYLESS-GO or make sure that the SmartKey located is at least 10 ft (3 m) away from the vehicle in such situations.

When making the kicking movement, make sure that your feet are firmly on the ground, otherwise you could lose your balance, e.g. on ice.

Requirements:

- The SmartKey is behind the vehicle.
- Stand at least 12 in (30 cm) away from the vehicle while performing the kicking movement.
- Do not come into contact with the bumper while making the kicking movement.
- Do not carry out the kicking movement too slowly.

• The kicking movement must be towards the vehicle and back again.



Sensor detection range

If several consecutive kicking movements are not successful, wait ten seconds.

#### System limitations

The system may be impaired or may not function if:

- Snow or dirt, e.g. from road salt, covers the sensor area.
- The kicking movement is made using a prosthetic leg.

The trunk lid could be opened or closed unintentionally, in the following situations:


- If a person's arms or legs are moving in the sensor detection range, e.g. when polishing the vehicle, sitting on the edge of the trunk, or picking up objects.
- If objects are moved or placed behind the vehicle, e.g. charging cables, tensioning straps or luggage.

Deactivate KEYLESS-GO ( page 56) or do not carry the SmartKey about your person in these and similar situations.

### Switching separate trunk locking on/off

If you centrally unlock the vehicle while separate locking is activated, the trunk will remain locked.






- To switch on: slide the switch to position 2.
- To switch off: slide the switch to position 1.
- i If an accident has been detected, the trunk will unlock even if separate locking is switched on.

### Unlocking the trunk with the emergency release from inside

#### Requirements:


The 12V vehicle battery is connected and charged.



Press emergency release button briefly.
 The trunk lid unlocks and opens.

# Unlocking the trunk lid using the mechanical key

► Take the mechanical key out of the SmartKey (→> page 57).



Press the top of Mercedes star ①.



- With the handle pointing upwards, insert the mechanical key into the trunk lock as far as it will go.
- Turn the mechanical key clockwise from position 1 to position 2.
- Turn the mechanical key back to position 1 and remove it.
- i If you use the mechanical key to unlock and open the trunk lid, the anti-theft alarm system will be triggered.

# Activating/deactivating the trunk lid opening height restriction

Multimedia system:

→ Vehicle ➤ 🚅 Vehicle Settings
➤ Trunk Lid Restriction

This function allows you to avoid bumping the trunk lid on a low garage ceiling, for example.

▶ Activate or deactivate the function.

#### Roller sun blinds


Extending/retracting the rear window roller sunblind

A

WARNING Risk of entrapment when extending or retracting the roller sun blind

Body parts could become entrapped in the sweep of the roller sun blind when it is being extended or retracted.

- Make sure that no body parts are in the sweep of the roller sun blind when it is being extended or retracted.
- If someone becomes trapped, briefly press the button again.
   The opening or closing process is briefly stopped. The roller sun blind then returns to its starting position.
- ! NOTE Damage caused by objects
- Make sure that the roller sun blind can move freely.



- To extend or retract: press button ①.
- Depending on the model, button is located on the door control panel on the driver's side.



#### Side windows

### Opening and closing the side windows

**WARNING** Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- When opening, make sure that nobody is touching the side window.
- If someone is trapped, release the button immediately or pull it in order to close the side window again.

**WARNING** Risk of becoming trapped when closing a side window

When closing a side window, body parts could be trapped in the closing area in the process.

When closing, make sure that no body parts are in the closing area.

If someone is trapped, release the button immediately or press the button in order to reopen the side window.

**WARNING** Risk of becoming trapped when children operate the side windows


Children could become trapped if they operate the side windows, particularly when unattended.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

#### Requirements:

 The power supply or the ignition is switched on.





- Closes
- Opens

The buttons on the driver's door take precedence.

To start automatic operation: press the
 button beyond the point of resistance or pull and release it.

- To interrupt automatic operation: press or pull the 国 button again.
- (i) Automatic operation for closing is available only for the front side windows.

When the vehicle is switched off, the side windows can continue being operated.

The function is available for around five minutes or until a door is opened.

### Automatic reversing function of the side windows

If an object blocks a side window during the closing process, the side window opens again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

When closing, make sure that no body parts are in the closing area.

WARNING Risk of becoming trapped despite there being reversing protection on the side window

The reversing function does not react:

- To soft, light and thin objects, e.g. fingers
- · During resetting

This means that the reverse function cannot prevent someone from becoming trapped in these situations.

- When closing, make sure that no body parts are in the closing area.
- If someone becomes trapped, press the ☐ button to open the side window again.

# Convenience opening (ventilating the vehicle before starting a journey)

**WARNING** Risk of entrapment when opening a side window

When opening a side window, parts of the body could be drawn in or become trapped between the side window and window frame.

- When opening, make sure that nobody is touching the side window.
- Release the button immediately if somebody becomes trapped.
- Press and hold the button on the SmartKey.

The following functions are performed:

- The vehicle is unlocked.
- The side windows are opened.
- The seat ventilation of the driver's seat is switched on.
- ➤ To interrupt convenience opening: release the button.



# Convenience closing (closing the vehicle from outside)

**WARNING** Risk of entrapment caused by inadvertent convenience closing

When the convenience closing feature is operating, parts of the body could become trapped in the closing area of the side windows.

- Observe the complete closing procedure when using convenience closing.
- When closing, make sure that no body parts are in the closing area.
- Press and hold the button on the SmartKey.

The following functions are performed:

. The vehicle is locked.

- The side windows are closed.
- To interrupt convenience closing: release the button.
- (i) Convenience closing can also be operated with KEYLESS-GO (——) page 60).

#### Problems with the side windows

#### **Problem**

A side window cannot be closed and you cannot see the cause.

#### Possible causes/consequences and ▶ Solutions

Check to see whether any objects are in the window guide.

**WARNING** Risk of becoming trapped or fatally injured if reversing protection is not activated

If you close a side window again immediately after it has been blocked or reset, the side window closes with increased or maximum force. The reversing feature is then not active.

Parts of the body could become trapped in the closing area in the process.

Make sure that no parts of the body are in the closing area.



Problem	Possible causes/consequences and ▶ Solutions
	To stop the closing process, release the button or press the button again to reopen the side window.
	If a side window is obstructed during closing and reopens again slightly:
	Immediately after the window is blocked, pull the corresponding switch again until the side window has closed, and hold the switch for an additional second.  The side window will be closed with increased force.
	If a side window is obstructed again during closing and reopens again slightly:
	Repeat the previous step.  The side window is closed without the automatic reversing function.
The side windows cannot be opened or closed using the convenience opening feature.	The SmartKey battery is discharged or nearly discharged.  Check the battery using the battery check lamp and replace if necessary (————————————————————————————————————



#### Panoramic roof

### Operating the panoramic roof's roller sunblind

▲ WARNING Risk of becoming trapped when opening and closing the roller sunblinds

Body parts can become trapped between the roller sunblind and frame when opening or closing.

- When opening or closing, make sure that no body parts are in the range of movement of the roller sunblind.
- Release the button immediately if somebody becomes trapped.


#### or

 Briefly press the button in any direction during automatic operation.
 The opening/closing process is stopped.

#### Requirements:

The power supply is switched on

#### Opening and closing the roller sunblind



- To open: push the button in direction or pull in direction 2.
- To close: pull the button in direction

  3.

If you push or pull the button beyond the point of resistance, you will start automatic operation in the direction in question. You can

DEALER ePROCESS

stop automatic operation by pushing or pulling the button again.



**Vehicles without MAGIC SKY CONTROL:** You can start and interrupt automatic operation via button .

 Press button 

 Depending on the degree of openness, the roller sunblind will be completely opened or closed.

#### Automatic reversing function of the roller sunblind

If there is an object obstructing the roller sunblind during the closing process, the roller sunblind will open again automatically. The automatic reversing function is only an aid and is not a substitute for your attentiveness.

When closing the roller sunblind, make sure that no body parts are in the range of movement.

#### **WARNING** Risk of becoming trapped despite reversing feature

In particular, the reversing feature does not react to soft, light and thin objects, e.g. fingers.

This means that the reversing feature cannot prevent entrapment in these situations.

- When closing the roller sunblind, make sure that no body parts are in the range of movement.
- Release the button immediately if somebody becomes trapped.

#### or


Press the button in any direction during the automatic closing process. The closing process is stopped.

#### Adjusting the panoramic roof's roller sunblind

#### Requirements:

• The power supply is switched on

If the roller sunblind cannot be moved smoothly, you can re-adjust the roller sunblind.



- closed.
- Pull and hold the button for another second.
- Check whether the roller sunblind can be completely opened again.



- If this is not the case: repeat the steps above.
- If the roller sunblind still cannot be moved smoothly, contact a qualified specialist workshop.

#### MAGIC SKY CONTROL

#### MAGIC SKY CONTROL function

MAGIC SKY CONTROL is a function with which you can change the transparency of the panoramic roof. You can choose to have the panoramic roof darkened or transparent.

▲ DANGER Risk of fatal injury caused by touching electrical components of MAGIC SKY CONTROL

MAGIC SKY CONTROL operates using high voltage. If the roof lining behind the panoramic roof is damaged or removed, electric components will be exposed.

If you touch these components, you could get an electric shock.

- Never remove the roof lining behind the panoramic roof.
- If the roof lining is damaged, never touch the electrical components behind it.
- Always have work on MAGIC SKY CON-TROL carried out at a qualified specialist workshop.



#### Operating MAGIC SKY CONTROL



- To change the degree of transparency: press button ①.
- (i) When you switch off the power supply, the panoramic roof will darken automatically. When you switch on the power supply or the ignition, the degree of transparency of the panoramic roof will return to the state it was in before the power supply was switched off.

#### Anti-theft protection

#### Function of the immobilizer

The immobilizer prevents your vehicle from being started without the correct SmartKey.

The immobilizer is automatically activated when the ignition is switched off and deactivated when the ignition is switched on.

When leaving the vehicle, always take the Smart-Key with you and lock the vehicle. Anyone can start the engine if a valid SmartKey has been left inside the vehicle.

(i) In the event the engine cannot be started (yet the vehicle's starter battery is charged), the system is not operational. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).

#### ATA (anti-theft alarm system)


# Function of the ATA system (anti-theft alarm system)

If the ATA system is armed, a visual and audible alarm is triggered in the following situations:

- · When a door is opened
- When the trunk lid is opened
- · When the hood is opened

The ATA system is armed automatically after approximately 10 seconds:

- After locking the vehicle with the SmartKey
- After locking the vehicle using KEYLESS-GO.



When the ATA system is armed, indicator lamp flashes.

The ATA system is automatically deactivated:

- After unlocking the vehicle with the Smart-Key
- After pressing the start/stop button with the SmartKey inside the vehicle



#### **78** Opening and closing

 After unlocking the vehicle using KEYLESS-GO

#### Deactivating the ATA

Press the ্রা or ক্রা button on the SmartKey.

#### or

 Press the start/stop button with the Smart-Key in the stowage compartment ( page 128)

#### Deactivating the alarm using KEYLESS-GO:

Grasp the outside door handle with the SmartKey outside the vehicle.




#### Notes on the correct driver's seat position

**WARNING** Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten vour seat belt.



Ensure the following when adjusting steering wheel 1, seat belt 2 and driver's seat 3:

- you are as far away from the driver's airbag as possible
- you are sitting in an upright position
- your thighs are slightly supported by the seat cushion

DEALER ePROCESS



- ditions your seat belt is pulled snugly against your
- body and is routed across the center of your shoulder and across your hips in the pelvic area

- · your legs are not fully extended and you can depress the pedals properly
- the back of your head is supported at eye level by the center of the head restraint
- you can hold the steering wheel with your arms slightly bent
- vou can move vour legs freely
- you can see all the displays on the instrument cluster clearly
- you have a good overview of the traffic con-

#### Seats

#### Adjusting the front seat electrically

**WARNING** Risk of becoming trapped if the seats are adjusted by children

Children could become trapped if they adjust the seats, particularly when unattended.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Never leave children unattended in the vehicle.

The seats can be adjusted when the ignition is switched off.

**WARNING** Risk of becoming trapped when adjusting the seats

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail.

When adjusting a seat, make sure that no one has any body parts in the sweep of the seat.

Observe the safety notes on "Airbags" and "Children in the vehicle".

WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.



**WARNING** Risk of becoming trapped if the seat height is adjusted carelessly

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured.

Children in particular could accidentally press the electrical seat adjustment buttons and become trapped.

While moving the seats, make sure that hands or other body parts do not get under the lever assembly of the seat adjustment system.

WARNING Risk of injury due to head restraints which are not installed or are adjusted incorrectly

If head restraints are not installed or are adjusted incorrectly, the head restraints cannot provide protection as intended.

There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be able to adjust the height and angle of the head restraints correctly.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.

### A

**WARNING** Risk of injury or death due to incorrect seat position

The seat belt does not offer the intended level of protection if you have not moved the seat backrest to an almost vertical position.


When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdominal or neck injuries, for example.

- Adjust the seat properly before beginning your journey.
- Always ensure that the seat backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.
- NOTE Damage to the seats when moving the seats back

The seats may be damaged by objects when moving the seats back.

When moving the seats back, make sure that there are no objects in the footwell, under or behind the seats.






- Head restraint height
- Head restraint height
- Seat height
- Seat cushion inclination
- Seat cushion length
- Seat fore-and-aft position
- Seat backrest inclination

- The head restraint height will be adjusted automatically when you adjust the seat height or the seat fore-and-aft position.

### Adjusting the front passenger seat electrically from the driver's seat

#### Requirements:

- To select the front passenger seat: the power supply is switched on
- i This function is not available for all models.



You can call up the following functions for the front passenger seat:

- Seat adjustment
- Seat heating
- Seat ventilation
- Memory function
   DEALER SPROCESS

- To select the front passenger seat: press button (1).
  - When the indicator lamp lights up, the front passenger seat is selected.
- Adjust the front passenger seat using the buttons on the door control panel on the driver's side.

#### **Head restraints**

# Adjusting the front seat head restraints mechanically

★ WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion

Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.

▲ WARNING Risk of injury due to head restraints which are not installed or are adjusted incorrectly

If head restraints are not installed or are adjusted incorrectly, the head restraints cannot provide protection as intended.


There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

- Always drive with the head restraints installed.
- Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not interchange the head restraints of the front and rear seats. Otherwise, you will not be

able to adjust the height and angle of the head restraints correctly.

Adjust the head restraint fore-and-aft position so that it is as close as possible to the back of your head.




- To move forwards: pull the head restraint forwards.
- To move backwards: press release knob and push the head restraint backwards.

Lowering the rear seat head restraints electrically from the front compartment

#### Requirements:


• The power supply is switched on





- Press button ①.
- Depending on the model, button is located on the door control panel on the driver's side.

#### Adjusting the rear seat head restraints



- To raise: pull the head restraint up.
- ➤ To lower: press release knob in the direction of the arrow and push the head restraint down.

#### Configuring the seat settings

#### Requirements:

• The ignition is switched on.

#### Multimedia system:

- → Vehicle → 🗾 Seats
- Select Driver's Seat or Passenger Seat.

#### Adjusting the backrest side bolsters

- ► Select Side Bolsters.
- Select the setting.

# Adjusting the seat contour in the lumbar region of the seat backrest (lumbar)

- Select Lumbar.
- Adjust the air cushion.

#### Setting the shoulder section

- Select Shoulders.
- Select the settings.

#### Setting the seat heating balance

- Select Seat Heating Balance.
- Select the settings.



#### Memory function

# Setting automatic adjustment of the lateral support (active multicontour seat)

Multimedia system:

→ Vehicle → 💋 Seats

With this function, the lateral support of the active multicontour seat is automatically adjusted to the driving and cornering dynamics of the vehicle.

- Select Driver's Seat or Passenger Seat.
- Select Dynamic Seat.
- ► Select setting: Off, Level 1 or Level 2.

#### Overview of massage and workout programs

#### Massage programs

The following programs can be selected:

- Hot Relaxing Back
- Hot Relaxing Shoulder

- Activating Massage
- Classic Massage
- Mobilizing Massage

#### **Active Workout**

The Act. Workout Back program requires your active cooperation. Alternating between tensing and releasing helps to improve blood flow to your muscles. Press against a pressure point as soon as you feel it.

### Selecting the massage program for the front seats

Multimedia system:

- → Vehicle → 🗾 Seats
- ▶ Select Driver's Seat or Passenger Seat.
- Select Massage.
- Select a massage program.
   The massage program runs for approximately 8 to 18 minutes, depending on the setting.
- To set the massage intensity: switch High Intensity on or off □.

#### Resetting the seat and massage settings


Multimedia system:

- → Vehicle → 🗾 Seats → Reset
- Select Yes or No.
- i Only the currently selected seat is reset.

### Folding the front seat backrest forwards/back

With the EASY-ENTRY function, the seat will move forwards if you have folded the seat backrest forwards. This makes it easier for passengers to get into and out of the rear of the vehicle.





- To fold forwards: pull the seat release handle and fold the seat backrest forwards as far as it will go.
  The seat will move to the foremost position.
- To fold back: swing back the seat backrest horizontally.

If the seat backrest is not engaged, this will be shown on the multifunction display of the instrument cluster. A warning tone will also sound.

The seat will move to the saved position. If the previous seat position can no longer be set, e.g. because of luggage in the rear footwell or after occupants have entered the rear of the vehicle:

Pull seat release handle again and return the seat backrest to an upright position. The seat will lock in the new fore-and-aft position.

#### Switching the seat heating on and off

WARNING Risk of burns due to repeatedly switching on the seat heating

Repeatedly switching on the seat heating can cause the seat cushion and seat backrest padding to become very hot.

The health of persons with limited temperature sensitivity or a limited ability to react to high temperatures may be affected or they may even suffer burn-like injuries.


- Do not repeatedly switch on the seat heating.
- NOTE Damage to the seats caused by objects or documents when the seat heater is switched on

When the seat heater is switched on, overheating can occur due to objects or documents placed on the seats e.g. seat cushions or child seats. This could cause damage to the seat surface.


Make sure that no objects or documents are on the seats when the seat heater is switched on.

#### Requirements:

• The power supply is switched on







- To switch off/reduce the level: press button 
  repeatedly until the desired heating level is set.
- If all indicator lamps are off, the seat heating is switched off.
- The seat heating will automatically switch down from the three heating levels after 8, 10 and 20 minutes until the seat heating switches off.
- i If you switch the power supply off and on again within 20 minutes, the previous setting of the seat heating for the driver's seat will remain active.
- You can set the distribution of the heated sections of the seat cushions and seat backrests on the front and rear seats via the multimedia system ( page 87).
- Vehicles with the Warmth Comfort Package: you can adjust the heating of the center console and the door armrests by using the multimedia system ( page 87).



#### Setting the panel heating

#### Requirements

The seat heating is activated ( page 86).


#### Multimedia system:

- → Vehicle ➤ 😝 Vehicle Settings
- >> Panel Heating
- Select one or more seats. The armrests of the selected seats and the center console are heated.

#### Switching the seat ventilation on/off

#### Requirements:

· The power supply is switched on



- To switch off/reduce the level: press button repeatedly until the desired ventilation level is set.
- If all indicator lamps are off, the seat ventilation is switched off.
- (i) If you switch the power supply off and on again within 20 minutes, the previous seat ventilation setting for the driver's seat will remain active.

#### Steering wheel

Adjusting the steering wheel electrically

**WARNING** Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion

▶ Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.


**WARNING** Risk of entrapment for children when adjusting the steering wheel

Children could injure themselves if they adjust the steering wheel.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

The steering wheel can be adjusted when the power supply is switched off.






- Adjusts the distance to the steering wheel
- Adjusts the height

#### Switching the steering wheel heater on or off

#### Requirements:

 The power supply or the ignition is switched on.



Turn the lever in the direction of arrow or @.
 If indicator lamp or lights up, the steering wheel heater is switched on.

#### DEALER ePROCESS

# Easy entry and exit feature Using the easy entry and exit feature

- **WARNING** Risk of accident when driving off while adjusting the easy exit feature
- If you drive off while the easy entry and exit feature is making adjustments, you could lose control of the vehicle.
- Always wait until the adjustment process is complete before driving off.
- ▲ WARNING Risk of becoming trapped while adjusting the easy entry and exit feature

When the easy entry and exit feature adjusts the steering wheel and the driver's seat, you and other vehicle occupants – particularly children – could become trapped.

During the adjustment process of the easy entry and exit feature, make sure that no one has any body parts in the sweep of the seat or the steering wheel. If there is a risk of becoming trapped by the steering wheel:

Move the adjustment lever of the steering wheel.

The adjustment process is stopped.

If there is a risk of becoming trapped by the driver's seat:

Press the seat adjustment switch.
The adjustment process is stopped.

Vehicles with memory function: You can stop the adjustment process by pressing one of the memory function position buttons.

**WARNING** Risk of becoming trapped during activation of the easy entry and exit feature by children

If children activate the easy entry and exit feature, they can become trapped, particularly when unattended.

Never leave children unattended in the vehicle.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

If the easy entry and exit feature is active, the steering wheel will move upwards and the driver's seat will move back in the following situations:

- you switch the ignition off when the driver's door is open
- you open the driver's door when the ignition is switched off
- i The steering wheel will move upwards only if it is not already as high as it will go. The driver's seat will move backwards only if it is not already in the rearmost position.

The steering wheel and the driver's seat will move back to the last drive position in the following cases:

- you switch the power supply or the ignition on when the driver's door is closed
- you close the driver's door when the ignition is switched on

The last drive position is stored in the following situations:

- you switch the ignition off
- Vehicles with memory function: call up the seat settings via the memory function.
- Vehicles with memory function: save the seat settings via the memory function.

**Vehicles with memory function:** press one of the memory function saved position buttons to stop the adjustment process.

#### Setting the easy entry and exit feature

Multimedia system:

→ Vehicle >> 😝 Vehicle Settings

- ➤ Easy Entry/Exit
- Select Steering Wheel & Seat, Steering Wheel Only or Off.



#### Operating the memory function

**WARNING** Risk of an accident if the memory function is used while driving

If you use the memory function on the driver's side while driving, you could lose control of the vehicle as a result of the adjustments being made.

Only use the memory function on the driver's side when the vehicle is stationary.

**WARNING** Risk of entrapment when setting the seat with the memory function

When the memory function adjusts the seat or steering wheel, you and other vehicle occupants – particularly children – could become trapped.

During the setting procedure of the memory function, ensure that no body parts are in the sweep of the seat or the steering wheel. If somebody becomes trapped, immediately release the memory function position button.

The adjustment process is stopped.

**WARNING** Risk of entrapment if the memory function is activated by children

Children could become trapped if they activate the memory function, particularly when unattended.

- Never leave children unattended in the vehicle.
- When leaving the vehicle, always take the key with you and lock the vehicle.

The memory function can be used when the ignition is switched off.


#### Storing

The memory function is only available in vehicles with the memory package.

Seat adjustments for up to three people can be stored and called up using the memory function. The following settings can be stored for the front seats:

- Seat, backrest, head restraint position and contour of the seat backrest in the lumbar region
- Active multicontour seat: side bolsters of the seat backrest, shoulder of the seat backrest, contour of the seat backrest, dynamic function level
- Seat heating: distribution of the heated sections of the seat cushion and seat backrest
- Driver's side: steering wheel position and position of the outside mirrors on the driver's and front passenger sides
- Head-up Display





- Set the seat, the steering wheel, the Head-up Display and the outside mirror to the desired position.
- Briefly press memory button M and then press preset position button 1, 2 or 3 within three seconds.

An acoustic signal sounds. The settings are stored.

- Depending on the model, only preset position buttons 1 and 2 are available.
- To call up: press and hold the relevant preset position button 1, 2 or 3 until the front seat, the steering wheel, Head-up Display and outside mirror are in the stored position.
- Depending on the model, only preset position buttons 1 and 2 are available.
- If you release the preset position button, the seat, steering wheel and mirror setting functions stop immediately.

Vehicles with the Active Multicontour Seat Package: Setting the active multicontour seat or the 4-way lumbar support is still carried out.

Vehicles without the Active Multicontour **Seat Package:** Adjustment of the 4-way lumbar support is still carried out.



#### Stowage areas

#### Notes on loading the vehicle



#### **DANGER** Risk of exhaust gas poisoning

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid is open when the engine is running, especially if the vehicle is in motion.

- Always switch off the engine before opening the trunk lid.
- Never drive with the trunk lid open.

#### WARNING Risk of injury from unsecured items in the vehicle

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be thrown around and thereby hit vehicle occupants.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be thrown around.
- Before the journey, secure objects, luggage or loads against slipping or tipping over.
- **WARNING** Risk of injury due to objects being stowed incorrectly

If you do not adequately stow objects in the vehicle interior, they could slip or be tossed around and thereby strike vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always restrain the objects they contain in the event of an accident.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always stow objects in such a way that they cannot be tossed about in these or similar situations.

- Always make sure that objects do not project from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the trunk.

Observe the notes on the cup holders.

**WARNING** Risk of burning from the tailpipe or tailpipe trim

The tailpipe and tailpipe trim can become very hot. If you come into contact with these car parts, you could burn yourself.

- Always be particularly careful when in the vicinity of the tailpipe and tailpipe trims and supervise children very closely when in this area.
- Before any contact, allow the car parts to cool down.

The driving characteristics of your vehicle are dependent on the distribution of the load within the vehicle. You should bear the following in mind when loading the vehicle:

- never exceed the permissible gross mass or the gross axle weight rating for the vehicle (including occupants). The values are specified on the vehicle identification plate on the vehicle's B-pillar.
- the load must not protrude above the upper edge of the seat backrests.
- always place the load behind unoccupied seats if possible.
- secure the load using the parcel net hooks.
   Distribute the load on the parcel net hooks evenly.



#### Stowage spaces in the vehicle interior

### Overview of the front stowage compartments

**WARNING** Risk of injury due to objects being stowed incorrectly


If you do not adequately stow objects in the vehicle interior, they could slip or be tossed around and thereby strike vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always restrain the objects they contain in the event of an accident.

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be tossed about in these or similar situations.
- Always make sure that objects do not project from stowage spaces, parcel nets or stowage nets.

- Close the lockable stowage spaces before starting a journey.
- Always stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the trunk.

Observe the notes on loading the vehicle.




- Stowage compartment in the doors
- Stowage/telephone compartment in the armrest with multimedia and USB ports as well as stowage space, e.g. for an MP3 player

DEALER ePROCESS

Stowage compartment in the front center console

Glove box

#### Locking and unlocking the glove box




Turn the emergency key a quarter turn clockwise 2 (to lock) or counter-clockwise 1 (to unlock).

#### Opening the eyeglasses compartment



Press button ①.

### Opening the stowage compartment in the rear armrest



- Fold down the rear armrest.
- Press release catch and swing the cover of the armrest upwards.

# Opening the stowage compartment in the rear-compartment center console




Slide cover 1 in the direction of the arrow.

# Opening the stowage box in the backrest in the rear passenger compartment

NOTE Damage to the rear armrest
When folded out, the rear armrest can be damaged by the weight of your body.

DEALER ePROCESS

Do not sit or support yourself on the rear armrest.




- Fold down the rear armrest.
- Pull handle ① and fold down cover ②.

#### Overview of the parcel net hooks

Observe the following notes:

- Secure the load using the parcel net hooks.
- Do not use elastic straps or nets to secure a load. These are intended only as anti-slip protection for light loads.
- Do not route tie downs across sharp edges or corners.
- Pad sharp edges for protection.

There are up to four parcel net hooks in the trunk depending on the equipment installed.



Parcel net hooks


# Opening the through-loading feature in the rear passenger compartment

NOTE Damage to the soft top caused by loading


The soft top can be damaged if the throughloading feature is loaded in the rear passenger compartment and the trunk separator has not been lowered.

Before loading the through-loading feature in the rear passenger compartment, lower the trunk separator.





- Fold down the rear armrest.
- Pull handle ① and fold down cover ②.




If necessary, pull rear apron (a) upwards and fold it down.

If the through-loading feature is to be used as a stowage compartment again:


Pull rear apron (3) upwards and attach wire brackets (2) to hooks (1).




### Opening the stowage space under the trunk floor



Pull trunk floor ② upwards using handle ① until it rests against the trunk partition.



Fold out hook 
on the underside of the trunk floor.



► Clip hook ③ onto drip rail ④.



#### Cup holder

Installing the cup holder in or removing it from the center console




**WARNING** - Risk of accident or injury when using the cup holder while the vehicle is moving

The cup holder cannot secure containers while the vehicle is moving.

If you use a cup holder while the vehicle is moving, the container may be flung around and liquids may be spilled. The vehicle occupants may come into contact with the liquid and if it is hot, they could be scalded. You could be distracted from traffic conditions and you may lose control of the vehicle.

- Only use the cup holder when the vehicle is stationary.
- Only use the cup holder for containers of the right size.
- Close the container, particularly if the liquid is hot.




- To remove: slide catch (2) forwards and pull out cup holder (1).
- ➤ To install: insert cup holder ① and slide back catch ②.
- The cup holder rubber mat can be removed for cleaning, e.g. using clean, lukewarm water.
- (i) Observe the notes on loading the vehicle (page 92).

#### Opening the cup holder in the rear armrest

! NOTE Damage to the cup holder

When the rear armrest is folded back the cup holder could become damaged.


Only fold the rear armrest back when the cup holder is closed.



- Press cup holder ① or ②.
- Place a container in or remove a container from cup holder 1 or 2.



# Ashtray and cigarette lighter Using the ashtray in the front center console



- To open: briefly press marking 4.
- To remove the insert: grip the sides of insert (1), push it forward and pull it upwards (2).
- To re-install the insert: press insert ① into the drawer until it engages.
- To close: press stowage compartment (3) closed until it locks.

### Using the cigarette lighter in the front center console



**WARNING** - Risk of fire and injury from hot cigarette lighter


You can burn yourself if you touch the hot heating element or the socket of the cigarette lighter.

In addition, flammable materials may ignite if:

- you drop the hot cigarette lighter
- a child holds the hot cigarette lighter to objects, for example
- Always hold the cigarette lighter by the knob.
- Always make sure that the cigarette lighter is out of reach of children.
- Never leave children unattended in the vehicle.

#### Requirements:

• The ignition is switched on.



Press in cigarette lighter ①.
 The cigarette lighter will pop out automatically when the heating element is red-hot.

#### Sockets

Using the 12 V socket in the front center console

#### Requirements:

 Only devices up to a maximum of 180 W (15 A) are permissible.






- Lift up socket cap 1.
- Insert the plug of the device.

If you have connected a device to the 12 V socket, leave the cover of the stowage compartment open.

Using the 12 V socket in the rear passenger compartment

#### Requirements:

 Only connect devices up to a maximum of 180 watts (15 A).




- Slide cover 1 backwards.
- Lift up socket cap (2).
- Insert the plug of the device.

If you have connected a device to the 12 V socket, leave the cover of the stowage compartment open.

#### Using the 12 V socket in the trunk

#### Requirements:

 Only connect devices up to a maximum of 180 watts (15 A).



- Lift up socket cap 1.
- Insert the plug of the device.



#### Refrigerator box

Using the refrigerator box



WARNING Risk of fire due to a covered vent grille on the refrigerator box

If you cover the vent grille for the refrigerator box, it may overheat.

Always make sure that the vent grille is not covered.

The ventilation grille for the refrigerator box is in the trunk.

The refrigerator box can bear a maximum load of 7.7 lb (3.5 kg).

Store only plastic bottles in the upper compartment of the refrigerator box. The contents of the bottle must be no more than 17 fl. oz. (0.5 l).

If you do not need to use the refrigerator box for an extended period you should switch it off, defrost it and clean it. After doing so, leave the lid open for a time.

The refrigerator box will reduce its cooling capacity or switch off in the following cases:

- too many electrical consumers are turned on
- the starter battery is not sufficiently charged

If this is the case, the indicator lamps will flash on the button for switching the refrigerator box on and off. The cooling function will automatically switch back on as soon as there is sufficient voltage.



- Fold down the rear seat armrest.
- Pull handle ① and fold down cover ②.




- ➤ To open: pull handle (1) and fold down the cover.
- To switch on: press button @ repeatedly until an indicator lamp (low cooling) flashes or two indicator lamps (high cooling) flash.
- ➤ To switch off: press button ② repeatedly until both indicator lamps go out.



#### Removing or installing the refrigerator box

#### Removing



- Switch off the refrigerator box.
- Pull plug ② down and out.
- Unscrew both screws 3.
- Pull out the refrigerator box.
- Close flap 1.

#### Installing

- Swing flap 1 to the side until it is locked in place by the magnet.
- Insert the refrigerator box.
- Tighten both screws 3.
- Connect plug 2.

Wireless charging of the mobile phone and connection with the exterior antenna

Notes on wirelessly charging the mobile phone

**WARNING** Risk of injury due to objects being stowed incorrectly

If you do not adequately stow objects in the vehicle interior, they could slip or be tossed around and thereby strike vehicle occupants. In addition, cup holders, open stowage spaces and mobile phone brackets cannot always restrain the objects they contain in the event of an accident.

DEALER ePROCESS

There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects in such a way that they cannot be tossed about in these or similar situations.
- Always make sure that objects do not project from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces before starting a journey.
- Always stow and secure objects that are heavy, hard, pointed, sharp-edged, fragile or too large in the trunk.

Observe the notes on loading the vehicle.

WARNING Risk of fire from placing objects in the mobile phone stowage compartment

If you place objects in the mobile phone stowage compartment, they may heat up excessively and even catch fire.

- Do not place additional objects, especially those mode of metal, in the mobile phone stowage compartment.
- NOTE Damage to objects caused by placing them in the mobile phone stowage compartment

If objects are placed in the mobile phone stowage compartment, they may be damaged by electromagnetic fields.

- Do not place credit cards, storage media or other objects sensitive to electromagnetic fields in the mobile phone stowage compartment.
- ! NOTE Damage to the mobile phone stowage compartment caused by liquids

If liquids enter the mobile phone stowage compartment, the compartment may be damaged.

Ensure that no liquids enter the mobile phone stowage compartment.


- Depending on the vehicle equipment, the mobile phone is connected to the vehicle's exterior antenna via the charging module.
- The charging function and wireless connection of the mobile phone to the vehicle's exterior antenna are only available if the ignition is switched on.
- Small mobile phones may not be able to be charged in every position of the mobile phone stowage compartment.
- Large mobile phones which do not rest flat in the mobile phone stowage compartment may not be able to be charged or connected with the vehicle's exterior antenna.
- The mobile phone may heat up during the charging process. This depends on the applications (apps) currently running.
- To ensure more efficient charging and connection with the vehicle's exterior antenna, remove the protective cover from the mobile phone. Protective covers which are designed for wireless charging are excluded.
- When charging, the mat should be used if possible.

### Wireless charging of the mobile phone in the front

#### Requirements:

 The mobile phone must be suitable for wireless charging (Qi-compatible mobile phone).
 You can find a list of Qi-compatible mobile phones at:

http://www.mercedes-benz.com/connect



When the charging symbol is shown in the multimedia system, the mobile phone is being charged.



- Malfunctions during the charging process are shown in the multimedia system display.
- The mat can be removed for cleaning, e.g. using clean, lukewarm water.


#### Installing and removing the floor mats

WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

This jeopardizes the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell.
- Always install the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.



- To install: press stud 1 into holder 2.
- **To remove:** pull the floor mat off holders **2**.




#### **Exterior lighting**

# Information about lighting systems and your responsibility

The various lighting systems of the vehicle are only aids. The driver of the vehicle is responsible for correct vehicle illumination in accordance with the prevailing light and visibility conditions, legal requirements and traffic situation.

#### Light switch

#### Operating the light switch



- 1 ←P Left standing light
- **2 P**≤→ Right standing light
- 3 | >0000 | Parking lights and license plate lamp
- 4 Automatic driving lights (preferred light switch position)

DEALER ePROCESS

- 5 D Low beam/high beam
- **⑥ O‡** Switches the rear fog lights on or off

When low beam is activated, the [305] indicator lamp for the parking lights is deactivated and replaced by the [30] low beam indicator lamp.

- Always park your vehicle safely and in a welllit area, in accordance with the relevant legal stipulations.
- **NOTE** Battery discharging by operating the standing lights

Operating the standing lights over a period of hours puts a strain on the battery.

Where possible, switch on the right **P** ≠ or left **P** parking light.

In the case of severe battery discharging, the standing lights or parking lights are automatically switched off to facilitate the next engine start.

The exterior lighting (except standing and parking lights) switches off automatically when the driver's door is opened.

Observe the notes on surround lighting  $\longrightarrow$  page 110).

#### Automatic driving lights function

The parking lights, low beam and daytime running lamps are switched on automatically depending on the ignition status and the ambient light.

**WARNING** Risk of accident when the low beam is switched off in poor visibility

When the light switch is set to AUTO, the low beam may not be switched on automatically if there is fog, snow or other causes of poor visibility such as spray.

In such cases, turn the light switch to ■D.

The automatic driving lights are only an aid. You are responsible for vehicle lighting.

### Switching the rear fog lights on or off

#### Requirements:


• The light switch is in the ☑ or AUTO position.

► Press the 0 button.

Please observe the country-specific laws on the use of rear fog lamps.



# Operating the combination switch for the lights



- High-beam headlamps
- Turn signal indicator, right
- High-beam flasher
- Turn signal light, left
- Use the combination switch to activate the desired function.

#### High-beam headlamps

- To switch on: turn the light switch to the or AUTO position.
- Press the combination switch beyond the point of resistance in the direction of arrow

When the high beam is activated, the Dindicator lamp for low beam will be deactivated and replaced by the Dindicator lamp for high beam.

➤ **To switch off**: move the combination switch back to its starting position.

### High-beam flasher

Pull the combination switch in the direction of arrow <a>(3)</a>.

### Turn signal lights

To indicate briefly: press the combination switch briefly to the point of resistance in the direction of arrow 2 or 3.


The corresponding turn signal indicator will flash three times.

To indicate permanently: press the combination switch beyond the point of resistance in the direction of arrow ② or ③.

Vehicles with Active Lane Change Assist

- Indicator operation activated by the driver can extend for the duration of the lane change.
- If the driver has indicated immediately beforehand but a lane change is then not possible, the turn signal indicator may activate automatically.

# Activating/deactivating the hazard warning lights




Press button ①.



### Cornering light

#### Cornering light function



The cornering light improves the illumination of the roadway over a wide angle in the turning direction, enabling better visibility on tight bends, for example. It can be activated only when the low beam is switched on.

The function is active in the following cases:

• at speeds below 25 mph (40 km/h) when the turn signal indicator is switched on or the steering wheel is turned

• at speeds between 25 mph (40 km/h) and 45 mph (70 km/h) when the steering wheel is turned

# **Adaptive Highbeam Assist**

### Adaptive Highbeam Assist function

**WARNING** Risk of accident despite Adaptive Highbeam Assist

Adaptive Highbeam Assist does not recognize the following road users:

- Road users without lights, e.g. pedestrians
- Road users with poor lighting, e.g. cvclists
- Road users whose lighting is obstructed, e.g. by a barrier

On very rare occasions, Adaptive Highbeam Assist may fail to recognize other road users with their own lighting, or may recognize them too late.

DEALER EPROCESS

In these or similar situations, the automatic high beam is not deactivated or is activated despite the presence of other road users.


Always observe the traffic carefully and switch off the high beam in good time.

Adaptive Highbeam Assist cannot take into account road, weather or traffic conditions.

Detection may be restricted in the following cases:

- in poor visibility, e.g. fog, heavy rain or snow
- if there is dirt on the sensors or the sensors are obscured

Adaptive Highbeam Assist is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.



The Adaptive Highbeam Assist automatically switches between the following types of light:

- Low-beam headlamps
- · High-beam headlamps

At speeds above 19 mph (30 km/h):

• If no other road users are detected, the high beam is switched on automatically.

The high beam switches off automatically:

- At speeds below 16 mph (25 km/h).
- · If other road users are detected.
- If street lighting is sufficient.

At speeds above approximately 31 mph (50 km/h):

The headlamp range of the low beam is regulated automatically based on the distance to other road users.

The system's optical sensor is located behind the windshield near the overhead control panel.

#### Switching Adaptive Highbeam Assist on/off

- To switch on: turn the light switch to the AUTO position.
- Switch on the high beam using the combination switch.

When the high beam is switched on automatically in the dark, the high indicator lamp on the multifunction display comes on.

To switch off: switch off the high beam using the combination switch.

### Switching the daytime running lamps on/off

Multimedia system:

- → Vehicle → 🙀 Light Settings
- >> Daytime Run. Lights
- ➤ Activate ✓ or deactivate ☐ the function.

# Setting the exterior lighting switch-off delay time

Multimedia system:

- → Vehicle → 🚖 Light Settings
- > Ext. Light Switch Off
- Set the switch-off delay time.

### Setting the surround lighting

Multimedia system:

- → Vehicle → 🙀 Light Settings
- >> Locator Lighting
- ▶ Activate or deactivate the function.


If the surround lighting is switched on, the exterior lighting remains lit for 40 seconds after the



vehicle is unlocked. When you start the vehicle, the surround lighting is deactivated and the automatic driving lights are activated.

#### Interior lighting

### Adjusting the interior lighting



- Switches the front left-hand reading lamp on/off
- Switches the automatic interior lighting control on/off
- Switches the front interior lighting on/off

- Switches the rear interior heating on/off
- M Switches the front right-hand reading lamp on/off

# Adjusting the ambient lighting

#### Multimedia system:

→ Vehicle → 🛱 Light Settings >> Ambient Light

# Setting the color

- Select Color.
- Set a color.

# Adjusting the brightness

- Select Brightness.
- Set a brightness value.

#### Activating the brightness for zones

- Select Brightness Zones.
- Activate or deactivate the function. The Display, Front and Rear zones can be set separately.

#### DEALER EPROCESS

#### Activating multi-color lighting

- Select Multi-color.
- Activate  $\overline{\triangleleft}$  or deactivate  $\square$  the function. There are ten preset color combinations available.

#### Activating multi-color animation

- Select Multi-color Anim...
- Activate  $\overline{\checkmark}$  or deactivate  $\square$  the function. The chosen color combination changes at predefined intervals.

#### Activating dependency on air conditioning settings

- Select Climate.
- Activate  $\mathbf{\nabla}$  or deactivate  $\square$  the function. If changes are made to the temperature setting in the vehicle, the color of the ambient lighting changes briefly.

#### Activating welcome lighting

Select Welcome.

#### 112 Light and visibility

Activate 

or deactivate 

the function.

When the vehicle is unlocked, a special interior lighting sequence runs.


# Setting the interior lighting switch-off delay time

Multimedia system:

- → Vehicle → 🙀 Light Settings
- >> Int. Light Switch Off
- Set the switch-off delay time.

# Windshield wiper and windshield washer system

Switching the windshield wipers on/off



- 1 0 Windshield wiper off
- 2 ••• Intermittent wiping, normal
- Intermittent wiping, frequent

DEALER ePROCESS

- 4 Continuous wiping, slow
- 5 Continuous wiping, fast
- Turn the combination switch to the corresponding position 1 5.
- Single wipe/washing: push the button on the combination switch in the direction of arrow .
  - Single wipe
  - Wipes with washer fluid

# Replacing the windshield wiper blades (MAGIC VISION CONTROL)

**WARNING** Risk of becoming trapped if the windshield wipers are switched on while wiper blades are being replaced


If the windshield wipers begin to move while you are changing the wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and the ignition before changing the wiper blades.

#### Moving the wiper arms to the change position

- If the ignition has been switched off, switch it on first of all.
- Switch the ignition off.
- Within around 15 seconds, press the 🔯 button on the combination switch for around 3 seconds ( $\longrightarrow$  page 112). The wiper arms will move into the change position.


#### Removing the wiper blades



To bring the wiper blade into position to be removed: hold the wiper arm firmly in one hand. With the other hand, turn the wiper blade in the direction of arrow 1 beyond the point of resistance. The wiper blade engages in the removal position with a click.

To remove the wiper blade: press release knob 2, pull the wiper blade in the direction of arrow (3) and remove.

# Installing the wiper blades



Push the new wiper blade onto the wiper arm in the direction of arrow 1 until release knob 2 engages.



### 114 Light and visibility

- Press the wiper blade beyond the point of resistance in the direction of arrow (3) on the wiper arm.
  - The wiper blade engages with a noticeable click and moves freely again.
- ▶ Fold the wiper arm back onto the windshield.
- Switch on the ignition.
- Press the button on the combination switch ( page 112).
   The wiper arms will move into the original position.

#### Mirrors

#### Operating the outside mirrors

▲ WARNING Risk of injury from adjusting the vehicle settings while the vehicle is in motion

You could lose control of the vehicle in the following situations:

- if you adjust the driver's seat, the head restraint, the steering wheel or the mirror while the vehicle is in motion
- if you fasten your seat belt while the vehicle is in motion
- Before starting the engine: adjust the driver's seat, the head restraint, the steering wheel or the mirror and fasten your seat belt.



**WARNING** Risk of accident due to misjudgment of distances when using the passenger mirror


The outside mirror on the front-passenger side reflects objects on a smaller scale. The objects in view are in fact closer than they appear.

As a result, you may misjudge the distance between you and the road user driving behind you, for example, when changing lanes.

Therefore, always look over your shoulder in order to ensure that you are aware of the actual distance between you and the road users driving behind you.



#### Folding the outside mirrors in/out



Briefly press switch ①.

#### Resetting the outside mirrors

- If the battery has been disconnected or completely discharged, the outside mirrors must be reset. Only then will the automatic mirror folding function work properly.
- Briefly press switch ①.

#### Adjusting the outside mirrors

- Select the required mirror using button (3) or
- Use button ② to set the position of the mirror you have selected.

# Engaging the outside mirrors

Press and hold button 
You will hear a click and the mirror will audibly engage in position. The mirror is set in the correct position.

# Automatic anti-glare mirrors function

**WARNING** Risk of burns and poisoning due to the anti-glare mirror electrolyte

Electrolyte may escape if the glass in an automatic anti-glare mirror breaks.

The electrolyte is harmful and causes irritation. It must not come into contact with your skin, eyes, respiratory organs or clothing or be swallowed.

DEALER EPROCESS

- If you come into contact with electrolyte, observe the following:
  - Rinse the electrolyte from your skin and seek medical attention immediately.
  - If electrolyte comes into contact with your eyes, rinse them thoroughly with clean water and seek medical attention immediately.
  - If the electrolyte is swallowed, immediately rinse your mouth out thoroughly. Do not induce vomiting. Seek medical attention immediately.
  - Immediately change out of clothing which has come into contact with electrolyte.
  - If an allergic reaction occurs, seek medical attention immediately.

The inside rearview mirror and the outside mirror on the driver's side automatically go into anti-glare mode if light from a headlamp hits the sensor on the inside rearview mirror.

#### System limitations

The system does not go into anti-glare mode in the following situations:

- · the engine is switched off
- reverse gear is engaged
- · the interior lighting is switched on

### Function of the front-passenger outside mirror parking position

The parking position makes parking easier.

The front-passenger outside mirror tilts downwards and shows the rear wheel on the front-passenger side in the following situations:

- the parking position is stored
   page 116)
- the passenger mirror is selected
- · reverse gear is engaged


The front-passenger outside mirror moves back to its original position in the following situations:

you shift the transmission to another transmission position

- at speeds greater than 9 mph (15 km/h)
- you press the button for the outside mirror on the driver's side

# Storing the parking position of the frontpassenger outside mirror using reverse gear

### **Storing**



- Select the front-passenger outside mirror using button 2.
- Engage reverse gear.
- Move the front-passenger outside mirror into the desired parking position using button (1).

### Calling up

- Select the front-passenger outside mirror using button 2.
- Engage reverse gear. The front-passenger outside mirror will move to the stored parking position.

# Activating/deactivating the automatic mirror folding function

Multimedia system:


→ Vehicle → ✓ Vehicle Settings

➤ Autom. Mirror Folding


▶ Activate or deactivate the function.

### Operating the sun visors

#### Using the single sun visor




- Glare from the front: fold sun visor (1) down.
- Glare from the side: swing sun visor 10 to the side.



Vehicles with an extendable sun visor: slide sun visor 1 horizontally as required.



#### Area permeable to radio waves on the windshield



Radio-controlled equipment, such as toll systems, can be mounted only on areas ① of the windshield that are permeable to radio waves.

Areas permeable to radio waves ① are best visible from outside the vehicle when the windshield is illuminated with an external light source.

Note this position for vehicles with:

- Windshield heating
- Infrared reflective windshield

# The infrared reflective windshield is coated and reduces the build-up of heat in the vehicle interior.

The coating shields the vehicle interior from radio waves up to the gigahertz range.




### Overview of climate control systems

#### Notes on climate control

An interior air filter must always be used so that the air conditioning system, pollution level monitoring and the air filtering function work correctly. Make sure that the filter is installed correctly and the filter housing in the engine compartment is closed correctly using the cap and always tightly sealed when in operation. Use filters recommended and approved by Mercedes-Benz. Always have service work carried out at a qualified specialist workshop.

# Overview of the control panel for automatic climate control

The indicator lamps in the buttons indicate that the corresponding function is activated.



- Auto Sets climate control to automatic, left
   page 120)
- ② ▼▲ Sets the temperature, left
- Sets the airflow on the left or switches off climate control
- Switches air-recirculation mode on/off
   → page 121)
- Defrosts the windshield
- **⑥** MENU

Calls up the air conditioning menu

Switches the rear window defroster on/off

DEALER EPROCESS

- M/C Switches the A/C function on/off (→ page 120)

  Switches the residual heat on/off (→ page 121)
- Sets the airflow, right, or switches off climate control
- Sets the temperature, right
- AUTO Sets climate control to automatic, right

# Operating the climate control system Activating/deactivating climate control

- To switch on: set the airflow to level 1 or higher using the button.
- ➤ To switch off: set the airflow to level 0 using the 19 button.
- (i) If climate control is switched off, the windows may fog up more quickly. Switch off climate control only briefly.

# Switching the A/C function on or off via the control panel

The A/C function heats, cools and dehumidifies the vehicle's interior air.

► Press the A/C button.

Switch off the A/C function only briefly otherwise the windows may fog up more quickly.

Condensation may drip from the underside of the vehicle when cooling mode is active. This is not a sign that there is a malfunction.

# Activating/deactivating the A/C function via the multimedia system

Multimedia system:

→ Vehicle → 😕 Climate Control → A/C

The A/C function heats, cools and dehumidifies the vehicle's interior air.

▶ Activate or deactivate the function.

#### Setting climate control to automatic

In automatic mode, the set temperature is regulated by the temperature of the dispensed air and the airflow.

- Press the AUTO button.
- To switch to manual mode: press the or ▼ button.

# **Climate style**

#### Climate style function

In automatic mode, you can select the following climate style settings for the driver's and front passenger areas:

- FOCUS: high airflow, slightly cooler setting
- MEDIUM: medium airflow, standard setting
- **DIFFUSE:** low airflow, slightly warmer and draft-free setting



# Adjusting the climate mode settings Multimedia system:

- → Vehicle → ☐ Climate Control
- >> Climate Mode
- Select Driver and/or Passenger.
- Select FOCUS, MEDIUM or DIFFUSE.
- To feel the effect of the climate style, the AUTO function must be active ( page 120).

### Overview of the air distribution settings

The symbols on the display indicate which vents the airflow is being directed through:

- defroster vents نه
- center and side air vents
- footwell vents نر
- center, side and footwell vents
- defroster and footwell vents فرج
- all vents نزيّ
- defroster, middle and side air vents
- automatic air distribution

#### Setting the air distribution

Multimedia system:

- → Vehicle → Climate Control
- ➤ Air Distribution
- Select Driver and/or Passenger.
- Set the air distribution.

### Setting the footwell temperature

Multimedia system:

- → Vehicle → Climate Control
- >> Footwell Temperature
- Select Driver and/or Passenger.
- Set the footwell temperature.

# Setting the rear climate control using the multimedia system

Multimedia system:

→ Vehicle >> 😕 Climate Control >> Rear

# Setting the airflow

Select Airflow.

Set the airflow.

#### Setting the temperature

- Select Temperature.
- Set the temperature.

# Activating or deactivating the climate control synchronization function using the multimedia system

Multimedia system:

→ Vehicle → ☑ Climate Control → SYNC

The climate control can be controlled centrally using the synchronization function. The temperature setting is automatically adopted for all climate zones.

► Activate ✓ or deactivate ☐ the function.

# Removing condensation from the windows

Windows fogged up on the inside

Press the Auto button.

# DEALER EPROCESS

If the windows continue to fog up: press the windows continue to fog up: press the

#### Windows fogged up on the outside

- Switch on the windshield wipers.
- Press the AUTO button.

# Switching air-recirculation mode on/off

Press the button.
The interior air will be recirculated.

Air-recirculation mode automatically switches to fresh air mode after some time.

i If air-recirculation mode is switched on, the windows may fog up more quickly. Switch on air-recirculation mode only briefly.

# Switching the residual heat on or off

#### Requirements:

The vehicle is parked.

It is possible to make use of the residual heat from the engine to continue heating or ventilat-

ing the front compartment of the vehicle for approximately 30 minutes.

► To switch on: press the A/C button.

Residual heat is switched off automatically.

# Activating/deactivating ionization

Multimedia system:

→ Vehicle → ☐ Climate Control → Ionization

lonization cleans and refreshes the interior air of the vehicle. The ionization of the interior air is odorless.

▶ Activate or deactivate the function.

### Fragrance system

#### Setting the fragrance system

#### Requirements:

- · Automatic climate control is activated.
- The glove box is closed.

Multimedia system:

→ Vehicle → ☐ Climate Control

Air Freshener

The fragrance system distributes a pleasant fragrance throughout the vehicle interior from a flacon located in the glove box.

To set the intensity: select High, Medium, Low or Off.

# Inserting or removing the flacon of the fragrance system

**WARNING** Risk of injury from liquid perfume

If children open the flacon, they could drink the liquid perfume or it could come into contact with their eyes.

- Do not leave children unattended in the vehicle.
- Consult a doctor immediately if liquid perfume has been drunk.




- If liquid perfume comes into contact with your eyes or skin, rinse your eyes with clean water.
- If symptoms continue, consult a doctor.

ENVIRONMENTAL NOTE Environmental damage due to improper disposal of full flacons

Full flacons must not be disposed of with household waste.

Full flacons must be taken to

a harmful substance collection point.



- Cap
- Flacon
- To insert: slide the flacon into the holder as far as it will go.
- To remove: pull out the flacon.

If you do not use genuine Mercedes-Benz interior perfumes, observe the manufacturers' safety notices on the perfume packaging.

Dispose of the genuine Mercedes-Benz interior perfume flacon when it is empty and do not refill

#### Refillable flacon

- Unscrew the cap of the empty flacon.
- Fill the flacon with a maximum of 0.5 fl. oz. (15 ml).
- Screw the cap back on to the flacon.

Always refill the empty refillable flacon with the same perfume. Observe the separate information sheet with the flacon.

#### Information on the windshield heater

The windshield heater is switched on automatically if the wax button is activated.

After the vehicle is started, the windshield heater is switched on automatically as required.



#### Air vents

#### Adjusting the front air vents

WARNING - Danger of burns or frostbite due to being too close to the air vents


Very hot or very cold air can flow from the air vents.

This could result in burns or frostbite in the immediate vicinity of the air vents.

- Make sure that all vehicle occupants always maintain a sufficient distance to the air vents.
- If necessary, direct the airflow to another area of the vehicle interior.

To guarantee the fresh air supply through the air vents into the vehicle interior, comply with the following:

- Always keep the vents and the ventilation grille in the vehicle interior free.
- Keep the air inlet free of deposits  $(\longrightarrow)$  page 343).



- ➤ To open or close: turn controller ① to the left or right as far as it will go.
- ➤ To adjust the air direction: hold air vent ②
  in the center and move it up or down or to
  the left or right.

### Adjusting the rear air vents



- To open or close: turn controller 2 to the left or right as far as it will go.
- To adjust the air direction: hold air vent on in the center and move it up or down or to the left or right.

# Opening or closing the air vent in the glove box


! NOTE Damage to temperature-sensitive objects in the glove box

Temperature-sensitive objects stored in the glove box may be damaged by the air vent located inside it.

- Close the air vent when you heat the vehicle.
- At high outside temperatures, open the air vent and switch on the A/C function.

The automatic climate control must be switched on to cool the glove box.





- Air vent controller
- Air vent
- To open or close: turn controller 1 to the left or right.



#### Notes on Mercedes-AMG vehicles

Observe the notes on the following topics in the Supplement, as you may otherwise fail to recognize dangers:

- AMG Performance exhaust system
- AMG high-performance brake system and AMG ceramic high-performance composite brake system
- RACE START
- AMG adaptive sport suspension system

# Switching on the power supply or ignition using the start/stop button

WARNING Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle, they could:

- open doors, thereby endangering other persons or road users.
- get out of the vehicle and be hit by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, children could also set the vehicle in motion, for example, by:

- releasing the parking brake.
- shifting the automatic transmission out of park position P.
- starting the engine



- Never leave children and animals unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

**DANGER** Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases is hazardous to health and can lead to poisoning.

 Never leave the engine running in an enclosed space without sufficient ventilation.

WARNING Risk of fire caused by flammable material on the exhaust system


Flammable materials brought in by either animals or environmental influences may ignite

if they come into contact with hot parts of the engine or exhaust system.

Therefore, check regularly that there are no flammable materials in the engine compartment or on the exhaust system.

#### Requirements:

• The SmartKey is located in the vehicle and the SmartKey battery is not discharged.



To switch on the power supply: press button 
once. You can activate the windshield wipers, for

The power supply is switched off again if the following conditions are met:

· you open the driver's door

example.

you press button 1 twice.

DEALER EPROCESS

To switch on the ignition: press button (1) twice

The indicator lamps in the instrument cluster light up.

The ignition is switched off again if one of the following conditions is met:

 you do not start the vehicle within 15 minutes.

The transmission is in position **P**. or

The electric parking brake is applied.

vou press button 
 once.

# Starting the vehicle

Starting the vehicle with the start/stop button

#### Requirements:


- . The SmartKey is located in the vehicle and the SmartKey battery is not discharged.
- Shift the transmission to position  $\mathbf{P}$  or  $\mathbf{N}$ .

- Depress the brake pedal and press button
   once.
- If the vehicle does not start: switch off nonessential consumers and press button once.
- If the vehicle still does not start and the Place the Key in the Marked Space See Operator's Manual display message also appears in the multifunction display: start the vehicle in emergency operation mode.

You can switch off the engine while driving by pressing button • for about three seconds. Be sure to observe the safety notes under "Driving tips".

# Starting the vehicle in emergency operation mode

If the vehicle does not start and the Place the Key in the Marked Space See Operator's Manual display message appears in the multifunction display, you can start the vehicle in emergency operation mode.



- Make sure that marked space ② is empty.
- Remove SmartKey from the SmartKey ring.
- Place SmartKey in marked space 2.
  The vehicle will start after a short time.
  If you remove SmartKey in from marked space 2 the engine continues running. For further vehicle starts however, SmartKey in must be located in marked space 2 during the entire journey.
- Have SmartKey the checked at a qualified specialist workshop.

DEALER ePROCESS

#### If the vehicle does not start:

- Leave SmartKey ① in marked space ②.
- Depress the brake pedal and start the vehicle using the start/stop button.
- i You can also switch on the power supply or the ignition with the start/stop button.

# Starting the vehicle via Remote Online services

# Cooling or heating the vehicle interior before commencing your journey

(i) This function is not available in all countries. If you start the vehicle via your smartphone, the previously selected air conditioning adjustment is active.

Ensure the following before starting the engine:

- The legal stipulations in the area where your vehicle is parked allow engine starting via smartphone.
- It is safe to start and run the engine where your vehicle is parked.
- The fuel tank is sufficiently filled.

- The starter battery is sufficiently charged.
- You can also set the temperature with your smartphone. Information on Mercedes me connect and other services: http:// www.mercedes.me

This function is not available for all models.

#### Charging the battery before commencing your journey

- This function is not available in all countries.
- If the vehicle battery is discharged, you receive a message on your smartphone.
- You can then start the vehicle with the smartphone to charge the battery.
- The vehicle is automatically switched off after ten minutes.

Ensure the following before starting the engine:

- The legal stipulations in the area where your vehicle is parked allow engine starting via smartphone.
- It is safe to start and run the engine where your vehicle is parked.
- The fuel tank is sufficiently filled.

#### Starting the vehicle

WARNING Risk of crushing or entrapment due to unintentional starting of the engine

Limbs could be crushed or trapped if the engine is started unintentionally during service or maintenance work.

Always secure the engine against unintentional starting before carrying out maintenance or repair work.

#### Requirements:

- Park position P is selected.
- The anti-theft alarm system is not activated.
- The panic alarm is not activated.
- The hazard warning lights are switched off.
- The hood is closed.
- The doors are closed and locked.
- The windows and sliding sunroof are closed.
- ► Start the vehicle using the smartphone:

DEALER EPROCESS

- After every vehicle start, the engine runs for ten minutes.
- You can carry out a maximum of two consecutive starting attempts. The vehicle must be started once with the SmartKey before trying to start the vehicle again with the smartphone.
- You can stop the vehicle again at any time.
- Further information can be found in the smartphone app.

### Securing the engine against starting before carrying out maintenance or repair work:

Switch on the hazard warning lights.

or

Unlock the doors.

or

Open a side window or the sliding sunroof.

# **Breaking-in notes**

Mercedes-AMG vehicles: observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.

To preserve the engine during the first 1000 miles (1500 km):

- drive at varying road speeds and engine speeds.
- drive the vehicle in drive program or .
- change gear before the tachometer needle is ½ of the way to the red area of the tachometer.
- do not shift down a gear manually in order to brake.
- avoid overstraining the vehicle, e.g. driving at full throttle.
- do not depress the accelerator pedal past the pressure point (kickdown).
- only increase the engine speed gradually and accelerate the vehicle to full speed after 1000 miles (1500 km).

This also applies when the engine or parts of the drivetrain have been replaced.

Please also observe the following breaking-in notes:

- in certain driving and driving safety systems, the sensors adjust automatically while a certain distance is being driven after the vehicle has been delivered or after repairs. Full system effectiveness is not reached until the end of this teach-in process.
- brakepads, brake discs and tires that are either new or have been replaced only achieve optimum braking effect and grip after several hundred kilometers of driving. Compensate for the reduced braking effect by applying greater force to the brake pedal.

# Notes on driving

WARNING Risk of accident due to objects in the driver's footwell

Objects in the driver's footwell may impede pedal travel or block a depressed pedal.

DEALER EPROCESS

This jeopardizes the operating and road safety of the vehicle.

- Stow all objects in the vehicle securely so that they cannot get into the driver's footwell
- Always install the floor mats securely and as prescribed in order to ensure that there is always sufficient room for the pedals.
- Do not use loose floor mats and do not place floor mats on top of one another.

WARNING Risk of accident due to unsuitable footwear

Operation of the pedals may be restricted due to unsuitable footwear such as:

- · Shoes with platform soles
- · Shoes with high heels
- Slippers
- When driving always wear suitable shoes in order to be able to operate the pedals safely.

**WARNING** Risk of accident when switching off the ignition when driving

If you switch off the ignition while driving, safety functions are restricted or no longer available. This may affect the power steering system and the brake force boosting, for example.

You will then need to use considerably more force to steer and brake.

Do not switch off the ignition while driving.

**DANGER** Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases is hazardous to health and can lead to poisoning.

Never leave the engine running in an enclosed space without sufficient ventilation. WARNING Risk of skidding and of an accident due to shifting down on slippery road surfaces

If you shift down on slippery road surfaces to increase the engine braking effect, the drive wheels may lose traction.

Do not shift down on slippery road surfaces to increase the engine braking effect.

**DANGER** Risk of fatal injury due to poisonous exhaust gases

If the tailpipe is blocked or sufficient ventilation is not possible, poisonous exhaust gases such as carbon monoxide may enter the vehicle. This is the case if the vehicle gets stuck in snow, for example.

 Keep the tailpipe and the area around the vehicle free from snow when the engine or the stationary heater are running.

DEALER EPROCESS

 Open a window on the windward side of the vehicle to ensure an adequate supply of fresh air.

WARNING Risk of accident and injury due to being under the influence of alcohol and drugs while driving

Driving when under the influence of alcohol and/or drugs is an extremely dangerous combination. Even small quantities of alcohol or drugs may affect your reflexes, perception and judgment.

The probability of a serious or even fatal accident greatly increases if you drive when under the influence of alcohol or drugs.

Do not drink alcohol or take drugs while driving, and do not allow anyone to drive who has been drinking alcohol or taking drugs. If you leave your foot on the brake pedal when driving, the brake system may overheat.

This increases the braking distance and the brake system may even fail.

- Never use the brake pedal as a footrest.
- Do not depress the brake pedal and the accelerator pedal at the same time while driving.
- ! NOTE Wearing out the brake linings by continuously depressing the brake pedal
- Do not depress the brake pedal continuously whilst driving.
- ➤ To use the braking effect of the engine, shift to a lower gear in good time.

- NOTE Damage to the drivetrain and engine when pulling away
- Do not warm up the engine while the vehicle is stationary. Pull away immediately.
- Avoid high engine speeds and driving at full throttle until the engine has reached its operating temperature.
- NOTE Damage to the catalytic converter due to non-combusted fuel

The engine is not running smoothly and is misfiring.

Non-combusted fuel may get into the catalytic converter.

- Only depress the accelerator pedal slightly.
- Have the cause rectified immediately at a qualified specialist workshop.

Limited braking effect on salt-treated roads:

- Due to salt build-up on the brake discs and brakepads, the braking distance can increase considerably or result in braking only on one side
- Maintain a much greater safe distance to the vehicle in front

To prevent salt build-up:

- Brake occasionally while paying attention to the traffic conditions
- Carefully depress the brake pedal at the end of the journey and when starting the next journey

### ECO start/stop function

Operation of the ECO start/stop function Mercedes-AMG vehicles: observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.



The engine is automatically switched off if the following conditions are met:

- you brake the vehicle to a standstill in transmission position  $\mathbf{D}$  or  $\mathbf{N}$ .
- if all vehicle conditions for an automatic engine stop are met.

The A symbol appears in the multifunction display when the vehicle is stationary.


The engine is restarted automatically if:

- you release the brake pedal in transmission position **D** when the HOLD function is not active.
- you shift from transmission position **P**.
- you engage transmission position **D** or **R**.
- · you depress the accelerator pedal.
- · you change the vehicle level.
- an automatic engine start is necessary.

If the engine was switched off by the ECO start/ stop function and you leave the vehicle, a warning tone sounds. The Vehicle Operational Switch the Ignition Off Before Exiting display message also appears in the multifunction display. If you

do not switch off the ignition, the ignition is automatically switched off after one minute.

# Deactivating or activating the ECO start/ stop function



Press button 1. If indicator lamp 2 lights up, the ECO start/ stop function is activated.

DEALER EPROCESS

#### ECO display function

The ECO display summarizes the driving characteristics from the start of the journey to its completion and assists you in achieving the most economical driving style.

You can influence consumption if you:

- drive with particular care
- drive the vehicle in drive program
- · observe the gearshift recommendations



The inner segment lights up green and the outer segment fills up:

Moderate acceleration

- ② Gentle deceleration and rolling
- 3 Consistent speed

The inner segment is gray and the outer segment empties:

- Sporty acceleration
- ② Heavy braking
- 3 Fluctuations in speed

You have driven economically when:

- the three outer segments are completely filled simultaneously
- the ECO display border lights up

The additional range achieved as a result of your driving style in comparison with a driver with a very sporty driving style is shown under Bonus fr. Start. The range displayed does not indicate a fixed reduction in consumption.

#### **DYNAMIC SELECT switch**

#### Function of the DYNAMIC SELECT switch

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.

Use the DYNAMIC SELECT switch to change between the following drive programs:

- (Individual): individual settings
- (Sport Plus): particularly sporty driving style
- **S** (Sport): sporty driving style
- (Comfort): comfortable and economical driving style
- Vehicles with MAGIC BODY CONTROL:
   (CURVE): comfortable driving with curve inclination function


Depending on the drive program selected, the following vehicle characteristics will change:

- Drive system:
  - Engine and transmission management
  - Active Distance Assist DISTRONIC



- ESP®
- Suspension
- Steering

# Selecting the drive program



Press DYNAMIC SELECT switch (1) forwards or backwards.

The drive program selected appears in the multifunction display.

# Configuring drive program I

Multimedia system:

- → Vehicle → 🙀 DYNAMIC SELECT
- >> Individual
- Select the individual setting.

### Switching the operation feedback for drive program on/off

Multimedia system:

- ¬→ Vehicle → 🙀 DYNAMIC SELECT
- Switch Notification for User on **✓** or off □. When this function is active, a corresponding message is shown in the media display when a drive program is selected with the DYNAMIC SELECT switch.

#### Displaying vehicle data

Multimedia system:

- ▼ Vehicle ➤ 🙀 DYNAMIC SELECT
- Select Vehicle Data.
  - The vehicle data is displayed.

# Displaying engine data

Multimedia system:

- ¬→ Vehicle → A DYNAMIC SELECT
- Select Engine Data.
- The values for engine output and engine torque may deviate from the nominal values. Items that can influence this are, for example:
  - Sea level
  - Fuel grade
  - Outside temperature



#### Automatic transmission

DIRECT SELECT lever

#### Function of the DIRECT SELECT lever

**WARNING** Risk of accident and injury due to children left unattended in the vehicle

If children are left unattended in the vehicle. they could:

- open doors, thereby endangering other persons or road users.
- get out of the vehicle and be hit by oncoming traffic.
- operate vehicle equipment and become trapped, for example.

In addition, children could also set the vehicle in motion, for example, by:

- releasing the parking brake.
- shifting the automatic transmission out of park position **P**.
- starting the engine


- Never leave children and animals unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- Keep the SmartKey out of the reach of children.

# **WARNING** Risk of accident due to incorrect gearshifting

If the engine speed is higher than the idle speed and you engage the transmission position  $\boxed{\mathbf{D}}$  or  $\boxed{\mathbf{R}}$ , the vehicle may accelerate sharply.

If you engage the transmission position
D or R always depress the brake
pedal firmly and do not accelerate at the same time.

Use the DIRECT SELECT lever to shift the transmission position. The current transmission position is displayed in the multifunction display.



- P Park position
- R Reverse gear
- Neutral
- **D** Drive position



### Engaging reverse gear R

Depress the brake pedal and push the DIRECT SELECT lever upwards past the first point of resistance.

The transmission position display shows **R** in the multifunction display.

### Engaging neutral N

 Depress the brake pedal and push the DIRECT SELECT lever up or down to the first point of resistance.
 The transmission position display shows N in the multifunction display.

Subsequently releasing the brake pedal will allow you to move the vehicle freely, e.g. to push it or tow it away.

# If you want the automatic transmission to remain in neutral N even if the ignition is switched off:

- Start the vehicle.
- Depress the brake pedal and engage neutral N.
- Release the brake pedal.
- Switch the ignition off.

i If you then exit the vehicle leaving the SmartKey in the vehicle, the automatic transmission remains in neutral N.

#### Engaging park position P

- Observe the notes on parking the vehicle (——) page 141).
- Press the P button.
  The transmission position display shows P in the multifunction display.

Park position P is engaged automatically if one of the following conditions is met:

- you switch the engine off with the transmission in position D or R.
- you open the driver's door when the vehicle is at a standstill or when driving at a very low speed and the transmission is in position D or R.

### Engaging drive position D

Depress the brake pedal and push the DIRECT SELECT lever down past the first point of resistance.

The transmission position display shows **D** in the multifunction display.

When the automatic transmission is in transmission position  $\boxed{\mathbf{D}}$ , it shifts the gears automatically. This depends on the following factors:

- The selected drive program
- The position of the accelerator pedal
- · The driving speed


### Manual gearshifting

WARNING Risk of skidding and of an accident due to shifting down on slippery road surfaces

If you shift down on slippery road surfaces to increase the engine braking effect, the drive wheels may lose traction.

 Do not shift down on slippery road surfaces to increase the engine braking effect.





When the automatic transmission is shifted to position  $\boxed{\textbf{D}}$ , you can manually shift it with the steering wheel paddle shifter. If permitted, the automatic transmission shifts to the next gear up or down depending on the steering wheel paddle shifter being pulled.

You have two options to manually shift the automatic transmission:

- Temporary setting
- Permanent setting

The gears shift automatically when manual gearshifting is deactivated.

# Temporary setting:

- ➤ To activate: pull steering wheel paddle shifter ① or ②.

  Manual gearshifting is activated for a short time. The current gear is displayed in the multifunction display.
- i How long the manual gearshifting stays activated is dependent on the driving style.
- To shift up: pull steering wheel paddle shifter 2.
- ➤ To shift down: pull steering wheel paddle shifter ①.
- ➤ To deactivate: pull steering wheel paddle shifter ② and hold it in place. The transmission position D appears in the multifunction display.

#### Permanent setting:


- Change to drive program ( page 134).
- Select drive program Manual ( page 135).

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.

#### Gearshift recommendation

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.

The gearshift recommendation assists you in adopting an economical driving style.



► If gearshift recommendation message ① is shown on the multifunction display, shift to the recommended gear.

#### Using kickdown

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.

Maximum acceleration: depress the accelerator pedal beyond the pressure point.

The automatic transmission shifts up to the next gear when the maximum engine speed is reached to protect the engine from overrevving.

#### Glide mode function

With an anticipatory driving style, glide mode helps you to reduce fuel consumption.

Glide mode is characterized by the following:

- The combustion engine is disconnected from the drivetrain and the vehicle continues to roll in neutral.
- The transmission position D is displayed in green in the multifunction display.



Glide mode is activated if the following conditions are met:

- Vehicles with MAGIC BODY CONTROL: drive program [CV] is selected.
- Vehicles without MAGIC BODY CONTROL: drive program 

  | is selected.
- The speed is within a suitable range.
- The road's course is suitable, e.g. no steep uphill or downhill inclines or tight bends.
- You do not depress the accelerator or brake pedal.
- i Glide mode can also be activated if you have selected the Eco setting for the drive when in drive program .

Glide mode is deactivated again if one of the conditions is no longer met.

Vehicles with Active Distance Assist DISTRONIC: when Active Distance Assist DISTRONIC is active, the glide mode function is not available.

#### **Function of the 4MATIC**

4MATIC ensures that all four wheels are driven when needed. Together with ESP® and 4ETS, 4MATIC improves the traction of your vehicle whenever a driven wheel spins due to insufficient traction.

If you fail to adapt your driving style, 4MATIC can neither reduce the risk of an accident nor override the laws of physics. 4MATIC cannot take account of road, weather and traffic conditions. 4MATIC is only an aid. You are responsible for maintaining a safe distance from the vehicle in front, for vehicle speed, for braking in good time and for staying in lane.

i In wintry road conditions, the maximum effect of 4MATIC can be achieved only if you use winter tires (M+S tires), with snow chains if necessary.



#### Refueling

### Refueling the vehicle

**WARNING** Risk of fire or explosion from fuel

Fuels are highly flammable.

- Fire, open flames, smoking and creation of sparks must be avoided.
- Switch off the ignition and, if available, the stationary heater, before and while refueling the vehicle.

# **WARNING** Risk of injury from fuels

Fuels are poisonous and hazardous to your health.

- Do not swallow fuel or let it come into contact with skin, eyes or clothing.
- Do not inhale fuel vapor.
- Keep children away from fuel.
- Keep doors and windows closed during the refueling process.

If you or other people come into contact with fuel, observe the following:

- Immediately rinse fuel off your skin with soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical attention immediately.
- If you swallow fuel, seek medical attention immediately. Do not induce vomiting.
- Change immediately out of clothing that has come into contact with fuel.
- **WARNING** Risk of fire or explosion from electrostatic charge

Electrostatic charge can create sparks and thereby ignite fuel vapors.

- Before you open the fuel filler cap or take hold of the pump nozzle, touch the metallic vehicle body.
   This discharges any electrostatic charge that may have built up.
- Do not get into the vehicle again during the refueling process.
   Otherwise, electrostatic charge could build up again.
- I NOTE Damage caused by the wrong fuel

Vehicles with a gasoline engine:

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and the emission control system.

- The RON requirement is located in the fuel filler flap.
- Only refuel with low-sulfur unleaded fuel.

This fuel may contain up to 10% ethanol. Your vehicle is suitable for use with E10 fuel.

Never refuel using any of the following fuels:

- Diesel
- Gasoline with more than 10% ethanol by volume, e.g. E15, E85, E100
- Gasoline with more than 3% methanol by volume, e.g. M15, M30, M85, M100
- Gasoline with additives containing metal

If you accidentally refuel with the wrong fuel:

- Do not switch the ignition on.
- Consult a qualified specialist workshop.
- **NOTE** Do not use diesel to refuel vehicles with a gasoline engine.

If you accidentally refuel with the wrong fuel:

- Do not switch the ignition on. Otherwise fuel can enter the engine.
  - Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high.
- Consult a qualified specialist workshop.




- Have the fuel tank and fuel lines drained completely.
- **NOTE** Damage to the fuel system caused by overfilled fuel tanks.
- Only fill the fuel tank until the pump nozzle switches off.
- **NOTE** Fuel may spray out when you remove the fuel pump nozzle.
- Only fill the fuel tank until the pump nozzle switches off.

#### Requirements:

- The vehicle is unlocked.
- Do not get into the vehicle again during the refueling process. Otherwise, electrostatic charge could build up again.

Observe the notes on operating fluids → page 408).



- Fuel filler flap
- Bracket for the fuel filler cap
- Tire pressure table
- QR code for rescue card
- Stationary heater indication
- Fuel type
- Press fuel filler flap 1



- Turn the fuel filler cap counter-clockwise and remove it.
- Insert the fuel filler cap into bracket 2.
- Completely insert the pump nozzle into the tank filler neck, hook in place and refuel.
- Only fill the tank until the pump nozzle switches off.
- Replace the cap on the filler neck and turn clockwise until it engages audibly.
- Close the fuel filler flap.

#### Parking

# Parking the vehicle

**WARNING** Risk of fire caused by hot exhaust system parts

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system or exhaust gas flow.

- Park the vehicle so that no flammable material can come into contact with hot vehicle components.
- In particular, do not park on dry grassland or harvested grain fields.
- ▲ WARNING Risk of accident and injury due to children left unattended in the vehicle


If you leave children unattended in the vehicle, they may be able to set the vehicle in motion, for example by:

- Releasing the parking brake.
- Shifting the automatic transmission out of park position P.
- Starting the engine.

In addition, they may operate vehicle equipment and become trapped.

Never leave children unattended in the vehicle.

- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.
- **NOTE** Damage to the vehicle due to it rolling away
- Always secure the vehicle against rolling away.



- Start/stop button
- On uphill or downhill inclines, turn the front wheels towards the curb.
- Apply the electric parking brake.
- Select transmission position P.
- Switch the ignition off.
- Lock the vehicle.



When you switch off the vehicle, you can still operate the side windows for approximately five minutes if the driver's door is closed

# Garage door opener

## Programming buttons for the garage door opener

**DANGER** Risk of fatal injuries due to exhaust gases

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases is hazardous to health and can lead to poisoning.

Never leave the engine running in an enclosed space without sufficient ventilation.

WARNING Risk of injury when opening or closing a door with the garage door opener

When you operate or program the door with the integrated garage door opener, people in the range of movement of the door may become trapped or struck by the door.

When using the integrated garage door opener, always make sure that nobody is within the range of movement of the door.

Only operate the following doors using the garage door opener:


- Doors with a safety stop and reversing feature.
- Doors which conform to the current U.S. safety standards.

### Requirements:

- The vehicle has been parked outside the garage or outside the range of movement of the door.
- The engine is switched off.

DEALER ePROCESS

- The ignition is switched on.
- The garage door opener function is always available when the ignition is switched on.



Check if the transmitter frequency of the remote control has the frequency range of 280 to 868 MHz.

Radio equipment approval number:

NZLMUAHL5 (USA)


- 4112A-MUAHL5 (Canada)
- Press and hold button ①, ② or ③ that you wish to program.
  Indicator lamp ④ flashes yellow.
- i It can take up to 20 seconds before the indicator lamp flashes yellow.
- Release the previously pressed button. Indicator lamp 4 continues to flash yellow.
- Point remote control (a) from a distance of 1 in (1 cm) to 3 in (8 cm) towards buttons
   (a) or (a).
- Press and hold button of remote control until:
  - Indicator lamp (a) lights up green continuously. Programming is complete.
  - Indicator lamp flashes green. Programming was successful. Additionally, synchronization of the rolling code with the door system must also be carried out.
- If indicator lamp (a) does not light up or flash green: repeat the procedure.
- Release all of the buttons.

 The remote control for the door drive is not included in the scope of delivery of the garage door opener.

# Synchronizing the rolling code

## Requirements:

- The door system uses a rolling code.
- The vehicle must be within range of the garage door or door drive.
- The vehicle as well as persons and objects, are located outside the range of movement of the door.




- Press the programming button on the door drive unit.
   Initiate the next step within approximately 30 seconds.
- Press previously programmed button ①, ②
   or ③ repeatedly until the door closes.
   When the door closes, programming is completed.



i Please also read the operating instructions for the door drive.

#### Troubleshooting when programming the remote control



- Check if the transmitter frequency of remote control (5) is supported.
- Replace the batteries in remote control **5**.
- Hold remote control (5) at various angles at a distance between 1 in (1 cm) to 3 in (8 cm) in front of the inside rearview mirror. You should test every position for at least 25 seconds before trying another position.


- Hold remote control (5) at the same angles at various distances in front of the inside rearview mirror. You should test every position for at least 25 seconds before trying another position.
- Note that some remote controls transmit only for a limited period, press button (6) on remote control (5) again before transmission ends.
- Align the antenna line of the door opener unit with the remote control.
- Support and additional information on programming:
  - On the toll free Homel ink® Hotline on 1-800-355-3515.
  - On the Internet at http:// www.homelink.com/mercedes.

# Opening/closing a garage door

# Requirements:


• The corresponding button is programmed to operate the door.





- Press and hold buttons (1), (2) or (3) until the door opens or closes.
- If indicator lamp 4 flashes yellow after approximately 20 seconds: press and hold the previously pressed button again until the door opens or closes.

# Clearing the garage door opener memory



- Press and hold buttons (1) and (3). Indicator lamp (4) lights up yellow.
- If indicator lamp (a) flashes green: release buttons (a) and (a).

  The entire memory has been deleted.

Radio equipment approval numbers for the garage door opener

# Radio equipment approval numbers



#### Brazil

Este equipamento opera em caráter secundário, isto é, não tem direito à proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Para maiores informações acessar www.anatel.gov.br



# Radio equipment approval numbers

Country	Radio equipment approval number
Egypt	TAC.2511151293.WIR
Andorra	CE
Australia	R-NZ
Barbados	MED1578
Chile	2488/DFRS20576/F-74
European Union	CE
Gibraltar	CE
Iceland	CE
Jordan	TRC/LPD/2015/299
Canada	IC: 4112A-MUAHL5
Kuwait	CE
Liechten- stein	CE

Country	Radio equipment approval number
Mexico	RCPGEMU15-0448
Monaco	CE
New Zea- land	R-NZ
Norway	CE
Russian Federa- tion	Not required
Saudi Ara- bia	TA 10525
Switzer- land	CE
South Africa	TA-2015/1386

Country	Radio equipment approval number
Turkey	Not required
United Arab Emi- rates	ER41849/15 Dealer No: DA35176/14
United States	FCC ID: NZLMUAHL5

Further information on the declaration of conformity for wireless vehicle components (—— page 21).



# **Electric parking brake**

# Electric parking brake function (applying automatically)

lack

WARNING Risk of accident and injury due to children and animals left unattended in the vehicle

If you leave children and animals unattended in the vehicle, they may be able to set the vehicle in motion, for example by:

- · Releasing the parking brake.
- Shifting the automatic transmission out of park position P.
- Starting the engine.

In addition, they may operate vehicle equipment and become trapped.

- Never leave children and animals unattended in the vehicle.
- When leaving the vehicle, always take the SmartKey with you and lock the vehicle.

The electric parking brake is applied if the transmission is in position P and one of the following conditions is fulfilled:

- · The engine is switched off.
- The seat belt tongue is not inserted in the seat belt buckle of the driver's seat and the driver's door is opened.
- (i) To prevent application: pull the handle of the electric parking brake.

In the following situations, the electric parking brake is also applied:

- Active Distance Assist DISTRONIC is bringing the vehicle to a standstill.
- The HOLD function is keeping the vehicle stationary.
- Active Parking Assist is keeping the vehicle stationary.

This is only the case if one of the following conditions is also fulfilled:

· The engine is switched off.

- The seat belt tongue is not inserted in the seat belt buckle of the driver's seat and the driver's door is opened.
- There is a system malfunction.
- · The power supply is insufficient.
- The vehicle is stationary for a lengthy period.

When the electric parking brake is applied, the red PARK (USA) or (②) (Canada) indicator lamp appears in the instrument cluster.

The electric parking brake is not automatically applied if the engine is switched off by the ECO start/stop function.

# Electric parking brake function (releasing automatically)

The electric parking brake is released when the following conditions are fulfilled:

- The engine is running.
- The seat belt tongue is inserted into the seat belt buckle of the driver's seat.
- The transmission is in position D or R and you depress the accelerator pedal or you

shift from transmission position  $\boxed{\mathbf{P}}$  to  $\boxed{\mathbf{D}}$  or  $\boxed{\mathbf{R}}$ .

 If the transmission is in position R, the trunk lid must be closed.

If the seat belt tongue is not inserted into the seat belt buckle of the driver's seat, the following conditions must be fulfilled:


- · The driver's door is closed.
- You move the transmission out of transmission position P or you have previously driven faster than 2 mph (3 km/h).
- If the transmission is in position R, the trunk lid must be closed.

When the electric parking brake is released, the red PARK (USA) or (©) (Canada) indicator lamp in the instrument cluster goes out.



### Applying/releasing the electric parking brake manually

### **Applying**



Push handle 1. The red PARK (USA) or (P) (Canada) indicator lamp appears in the instrument cluster.

The electric parking brake is only securely applied if the indicator lamp is lit continuously.

#### Releasing

- Switch on the ignition.
- Pull handle 

  . The red PARK (USA) or (P) (Canada) indicator lamp in the instrument cluster goes out.

### **Emergency braking**

Press and hold handle ①. When the vehicle has been braked to a standstill, the electric parking brake is applied. The red PARK (USA) or (P) (Canada) indicator lamp appears in the instrument cluster.

## Notes on parking the vehicle for an extended period

If you leave the vehicle parked for longer than four weeks, the disconnected battery may be damaged by deep discharge.

DEALER ePROCESS

If you leave the vehicle parked for longer than six weeks, it may suffer disuse damage.

(i) Further information can be obtained at a qualified specialist workshop.

# Standby mode (extension of the starter battery's period out of use)

#### Standby mode function

(i) This function is not available for all models. If standby mode is activated, the vehicle can be parked for an extended period of time without losing power.

Standby mode is characterized by the following:

- The starter battery is preserved.
- The maximum non-operational time out of use is displayed in the multimedia system display.
- The connection to online services is interrupted.

If the following conditions are fulfilled, standby mode can be activated or deactivated using the multimedia system:

- · The engine is switched off.
- · The ignition is switched on.

Exceeding the vehicle's displayed non-operational time may cause inconvenience, i.e. it cannot be guaranteed that the starter battery will reliably start the engine.

The starter battery must be charged first in the following situations:

- The vehicle's non-operational time must be extended.
- The Battery Charge Insufficient for Standby Mode message appears in the multimedia system display.
- i Standby mode is automatically deactivated when the ignition is switched on.

# Activating/deactivating standby mode Multimedia system:

- → Vehicle ➤ 😝 Vehicle Settings
- >> Standby Mode
- (i) This function is not available for all models.
- ➤ Activate ✓ or deactivate ☐ the function. When you activate the function, a prompt appears.
- Select Yes. Standby mode is activated.

# Driving and driving safety systems Driving systems and your responsibility

Your vehicle is equipped with driving systems which assist you in driving, parking and maneuvering the vehicle. The driving systems are aids and do not relieve you of your responsibility pertaining to road traffic law. Pay attention to the traffic conditions at all times and intervene when necessary. Be aware of the limitations regarding the safe use of these systems.

DEALER ePROCESS

#### Function of the radar sensors

Some driving and driving safety systems use radar sensors to monitor the area in front of, behind or next to the vehicle (depending on the vehicle's equipment).

Depending on the vehicle's equipment, the radar sensors are integrated behind the bumpers and/or behind the Mercedes star. Keep these parts free of dirt, ice and slush

( >> page 349). The sensors must not be covered, for example by cycle racks, overhanging loads, stickers, foil or foils to protect against stone chipping. In the event of damage to the bumpers or radiator grill, or following a collision impacting the bumpers or radiator grill, have the function of the radar sensors checked at a qualified specialist workshop. The driver assistance system may no longer work properly.

# Overview of driving systems and driving safety systems

In this section, you will find information about the following driving systems and driving safety systems:

- 360° Camera (→ page 188)
- ABS (Anti-lock Braking System)  $(\longrightarrow)$  page 151)
- Active Distance Assist DISTRONIC  $(\longrightarrow)$  page 162)
- AIR BODY CONTROL (——— page 174)
- Active Brake Assist (——> page 155)
- ATTENTION ASSIST ( page 197)
- BAS (Brake Assist System) (→ page 151)
- Hill Start Assist (→ page 173)
- EBD (Electronic Brakeforce Distribution)  $(\longrightarrow)$  page 155)
- ESP® (Electronic Stability Program)  $(\longrightarrow)$  page 152)

- HOLD function (—— page 173)
- STEER CONTROL (→ page 155)
- Active Steering Assist (→ page 167)
- Night View Assist (—— page 200)
- Active Parking Assist (→ page 191)
- Parking Assist PARKTRONIC  $(\longrightarrow)$  page 182)
- Rear view camera (——— page 186)
- Cruise control (——> page 159)
- Blind Spot Assist and Active Blind Spot Assist  $(\longrightarrow)$  page 203)
- Traffic Sign Assist (→ page 198)

# Function of ABS (Anti-lock Braking System)

ABS regulates the brake pressure in critical driving situations:

- During braking, e.g. at full brake application or insufficient tire traction, the wheels are prevented from locking.
- Vehicle steerability while braking is ensured.

If ABS intervenes when braking, you will feel a pulsing in the brake pedal. The pulsating brake pedal can be an indication of hazardous road conditions and can serve as a reminder to take extra care while driving.

# **System limitations**

- ABS is active from speeds of approx. 5 mph (8 km/h).
- ABS may be impaired or may not function if a malfunction has occurred and the yellow ABS warning lamp lights up continuously in the instrument cluster after the engine is started.

### Function of BAS (Brake Assist System)

**WARNING** Risk of an accident caused by a malfunction in BAS (Brake Assist System)

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased.



Depress the brake pedal with full force in emergency braking situations. ABS prevents the wheels from locking.

BAS supports your emergency braking situation with additional brake force.

If you depress the brake pedal quickly, BAS is activated:

- BAS automatically boosts the brake pressure.
- BAS can shorten the braking distance.
- ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

# Function of ESP® (Electronic Stability Program)

# ▲ WARNING Risk of skidding if ESP<sup>®</sup> is malfunctioning

If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have ESP® checked at a qualified specialist workshop.

# **WARNING** Risk of skidding if ESP<sup>®</sup> is deactivated

If you deactivate ESP®, ESP® cannot carry out vehicle stabilization.

ESP® should only be deactivated in the following situations.

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may not recognize dangers.

DEALER ePROCESS

ESP® can monitor and improve driving stability and traction in the following situations, within physical limits:

- When pulling away on wet or slippery roadway.
- · When braking.
- In strong side winds when you are driving faster than 50 mph (80 km/h).

If the vehicle deviates from the direction desired by the driver, ESP $^{\otimes}$  can stabilize the vehicle by intervening in the following ways:

- · One or more wheels are braked.
- The engine output is adapted according to the situation.

ESP® is deactivated if the Spp ESP® OFF warning lamp lights up continuously in the instrument cluster:

- Driving stability will no longer be improved.
- Crosswind Assist is no longer active.
- · The drive wheels could spin.
- ETS/4ETS traction control is still active.

(i) When ESP® is deactivated, you are still assisted by ESP® when braking.

ESP® is intervening if the SP® warning lamp flashes in the instrument cluster:

- Do not deactivate ESP®
- Only depress the accelerator pedal as far as is necessary.
- Adapt your driving style to suit the current road and weather conditions.

It can make sense to deactivate ESP® in the following situations to improve traction:

- When using snow chains.
- In deep snow.

- On sand or gravel.
- (i) Spinning the wheels results in a cutting action which provides better grip.

If the SP® warning lamp lights up continuously. ESP® is not available due to a malfunction. Observe the following information:

- Warning and indicator lamps  $(\longrightarrow)$  page 462)
- Display messages (—— page 416)

ETS/4ETS (Electronic Traction System) ETS/4ETS traction control is part of ESP® and makes it possible to pull away or accelerate on a slippery surface.

ETS/4ETS can improve the vehicle's traction by intervening in the following ways:

- The drive wheels are braked individually if they spin.
- More drive torque is transferred to the wheel or wheels with traction.

# Influence of drive programs on ESP®

The drive programs enable ESP® to adapt to different weather and road conditions as well as the driver's preferred driving style. You can select the drive programs using the DYNAMIC SELECT switch ( $\longrightarrow$  page 134).



# ESP® characteristics per drive program

Drive program	ESP® mode	Characteristics
S (Sport)	ESP® Sport	This drive program continues to offer stability but with a sporty setup which allows the enthusiastic driver a more active driving style.
		Select drive program sin good road conditions, for example on dry roads and clear stretches of road.
C (Comfort)  Vehicles with MAGIC BODY CONTROL:	ESP® Comfort	These drive programs provide the ideal balance between traction and stability.
(CURVE)  [E] (Economy)		Select drive program [C], [CV] or [E] in difficult road conditions, such as snow or ice, or when the road is wet from rain.

# Activating/deactivating ESP® (Electronic Stability Program)

Multimedia system:

→ Vehicle → (Assistance → ESP

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may not recognize dangers.

▶ Activate or deactivate the function.

ESP® is deactivated if the Bere ESP® OFF warning lamp lights up continuously in the instrument cluster.

Observe the information on warning lamps and display messages which may be shown in the instrument cluster.

DEALER ePROCESS

# **Function of ESP® Crosswind Assist**

 $\mathsf{ESP}^{\circledR}$  Crosswind Assist detects sudden gusts of side wind and helps the driver to keep the vehicle in the lane:

 ESP® Crosswind Assist is active at vehicle speeds between 50 mph (80 km/h) and

- 125 mph (200 km/h) when driving straight ahead or cornering slightly.
- · The vehicle is stabilized by means of individual brake application on one side.

# Function of EBD (electronic brake force distribution)

EBD is characterized by the following:

- Monitoring and regulating the brake pressure on the rear wheels.
- Improved driving stability when braking, especially on bends.

#### **Function of STEER CONTROL**

STEER CONTROL helps you by transmitting a noticeable steering force to the steering wheel in the direction required for vehicle stabilization.

This steering recommendation is given particularly in the following situations:

 Both right wheels or both left wheels are on a wet or slippery road surface when you brake

The vehicle starts to skid

#### System limitations

STEER CONTROL may be impaired or may not function in the following situations:

- ESP® is deactivated
- ESP® is malfunctioning
- The steering is malfunctioning

If ESP® is malfunctioning, you will be assisted further by the electric power steering.

#### **Function of Active Brake Assist**

Active Brake Assist consists of:

- Distance warning function
- Autonomous braking function
- Situation-dependent braking assistance
- Vehicles with Driving Assistance Package: Evasive Steering Assist

Active Brake Assist can help you to minimize the risk of a collision with vehicles or pedestrians or to reduce the effects of such a collision.

DEALER ePROCESS

If Active Brake Assist has detected a risk of collision, a warning tone sounds and the \( \bar{A} \) distance warning lamp lights up in the instrument cluster.

If you do not react to the warning, autonomous braking can be initiated in critical situations.

In especially critical situations, Active Brake Assist can initiate autonomous braking directly. In this case, the warning lamp and warning tone occur simultaneously with the braking application.

If you apply the brake yourself in a critical situation or apply the brake during autonomous braking, situation-dependent braking assistance occurs. This increases the brake pressure up to maximum full-stop braking if necessary.

If the autonomous braking function or the situation-dependent braking assistance is triggered, additional preventive measures for occupant protection (PRE-SAFE®) may also be initiated, if the vehicle is equipped with these.

Active Brake Assist cannot always clearly identify objects and complex traffic situations.

In such cases, Active Brake Assist might:

- Give a warning or brake without reason
- Not give a warning or not brake
- Always pay careful attention to the traffic situation; do not rely on Active Brake

Assist alone. Active Brake Assist is only an aid. The driver is responsible for maintaining a suitable distance to the vehicle in front, vehicle speed and for braking in good time.

Be prepared to brake or swerve if necessary.

Also observe the system limitations of Active Brake Assist.

The individual subfunctions are available in the following speed ranges:
Distance warning function

The distance warning function issues a warning at speeds:

From approximately 4 mph (7 km/h), if your vehicle is critically close to a vehicle or pedestrian. An intermittent warning tone sounds and the distance warning lamp lights up in the instrument cluster.

Brake immediately or take evasive action, provided it is safe to do so and the traffic situation allows this.

# The distance warning function can aid you in the following situations with an intermittent warning tone and a warning lamp:

	Vehicles traveling in front	Stationary vehicles	Crossing vehicles	Moving pedestrians	Stationary pedes- trians
Vehicles without Driv- ing Assistance pack- age	Up to approx. 155 mph (250 km/h)	Up to approx. 50 mph (80 km/h)	No reaction	Up to approx. 50 mph (80 km/h)	No reaction
Vehicles with Driving Assistance package	Up to approx. 155 mph (250 km/h)	Up to approx. 62 mph (100 km/h)	Up to approx. 43 mph (70 km/h)	Up to approx. 50 mph (80 km/h)	Up to approx. 43 mph (70 km/h)

# **Autonomous braking function**

The autonomous braking function may intervene at speeds starting from approximately 4 mph (7 km/h) in the following situations:

	Vehicles traveling in front	Stationary vehicles	Crossing vehicles	Crossing pedestrians	Stationary pedes- trians
Vehicles without Driv- ing Assistance pack- age	Up to approx. 124 mph (200 km/h)	Up to approx. 31 mph (50 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction
Vehicles with Driving Assistance package	Up to approx. 155 mph (250 km/h)	Up to approx. 62 mph (100 km/h)	Up to approx. 43 mph (70 km/h)	Up to approx. 43 mph (70 km/h)	Up to approx. 43 mph (70 km/h)

# Situation-dependent braking assistance

Situation-dependent braking assistance may intervene at speeds starting from approximately 4 mph (7 km/h) in the following situations:

	Vehicles traveling in front	Stationary vehicles	Crossing vehicles	Crossing pedestrians	Stationary pedes- trians
Vehicles without Driv- ing Assistance pack- age	Up to approx. 155 mph (250 km/h)	Up to approx. 50 mph (80 km/h)	No reaction	Up to approx. 37 mph (60 km/h)	No reaction
Vehicles with Driving Assistance package	Up to approx. 155 mph (250 km/h)	Up to approx. 62 mph (100 km/h)	Up to approx. 43 mph (70 km/h)	Up to approx. 43 mph (70 km/h)	Up to approx. 43 mph (70 km/h)

#### Canceling a brake application of Active Brake Assist

You can cancel a brake application of Active Brake Assist at any time by:

- Depressing the accelerator pedal fully.
- Releasing the brake pedal.

Active Brake Assist may cancel the brake application when one of the following conditions is fulfilled:

- You maneuver to avoid the obstacle.
- There is no longer a risk of collision.
- An obstacle is no longer detected in front of your vehicle.

# Evasive Steering Assist (only vehicles with Driving Assistance Package)

Evasive Steering Assist has the following characteristics:

- Can detect stationary or crossing pedestrians.
- Can assist the driver with additional steering assistance if it detects a swerving maneuver.

- Can be activated by an abrupt steering movement during a swerving maneuver.
- Can assist during swerving and straightening of the vehicle.
- Can react from a speed of approximately 12 mph (20 km/h) up to a speed of approximately 43 mph (70 km/h).
- You can prevent the assistance at any time by actively steering.

# **WARNING** Risk of an accident despite Evasive Steering Assist

Evasive Steering Assist cannot always clearly identify objects and complex traffic situations.

In addition, the steering support of Evasive Steering Assist is generally not sufficient to avoid a collision.

In such cases Evasive Steering Assist can:

- give an unnecessary warning or provide assistance
- not give a warning or not provide assistance

- Always pay careful attention to the traffic situation; do not rely on Evasive Steering Assist alone.
  - Be ready to brake and take evasive action if necessary.
- Prevent the assistance by actively steering in non-critical driving situations.
- Drive at an appropriate speed if pedestrians are close to the path of your vehicle.

Also observe the system limitations of Evasive Steering Assist.

# **System limitations**

The system may be impaired or may not function in the following situations:

- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying ambient light.
- If the sensors are dirty, fogged up, damaged or covered.



- If the sensors malfunction due to other radar source interference, for example strong radar reflections in parking garages.
- If a loss of tire pressure or a defective tire has been detected and displayed.

The system may not react correctly:

- In complex traffic situations where objects cannot always be clearly identified.
- To pedestrians or vehicles if they move quickly into the sensor detection range.
- To pedestrians who are hidden by other objects.
- If the typical outline of a pedestrian cannot be distinguished from the background.
- If a pedestrian is not recognized as such, e.g. due to special clothing or other objects.
- On bends with a tight radius.

### **Setting Active Brake Assist**

Multimedia system:

► Vehicle ► ( Assistance Active Brake Assist

Vehicles without Driving Assistance Package: The settings can be made after starting the vehicle.

Vehicles with Driving Assistance Package: The settings can be made when the ignition is

The following settings are available:

- Early
- Medium

switched on.

- Late
- Select a setting.
- i) Your selection is retained when the vehicle is next started.

#### **Deactivating Active Brake Assist**

(i) It is recommended that you always leave Active Brake Assist activated.



Select Off.

The distance warning function and the autonomous braking function are deactivated.

Vehicles without Driving Assistance Package: When the vehicle is next started, the medium setting is automatically selected.

Vehicles with Driving Assistance Package: Evasive Steering Assist is not available. When the ignition is next started, the medium setting is selected automatically and Evasive Steering Assist is available.

i) If Active Brake Assist is deactivated, the symbol appears in the status bar of the multifunction display.

# **Speed control cruise control**

#### Function of cruise control

Cruise control regulates the speed to the value selected by the driver.

If you accelerate to overtake, for example, the stored speed is not deleted. If you remove your foot from the accelerator pedal after overtaking, cruise control will resume speed regulation back to the stored speed.

Cruise control is operated using the corresponding steering wheel buttons. You can store any speed above 15 mph (20 km/h) up to the maximum speed.

If you fail to adapt your driving style, cruise control can neither reduce the risk of an accident nor override the laws of physics. It cannot take into account road, weather or traffic conditions. Cruise control is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

# Displays on the multifunction display

The status of cruise control and the stored speed are shown in the multifunction display.



- Cruise control is selected
- Speed is saved, cruise control is deactivated
- Speed is saved, cruise control is activated
- The segments between the stored speed and the end of the segment display light up in the speedometer.

#### System limitations

Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out.

Change into a lower gear in good time on long and steep downhill gradients. Take particular note of this when driving a laden vehicle. By

DEALER ePROCESS

doing so, you will make use of the engine's braking effect. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Do not use cruise control in the following situations:

- In traffic situations which require frequent changes of speed, e.g. in heavy traffic, on winding roads.
- On slippery roads. Accelerating can cause the drive wheels to lose traction and the vehicle could then skid.
- If you are driving when visibility is poor.

# Operating cruise control


WARNING Risk of accident due to stored speed

If you call up the stored speed and this is lower than your current speed, the vehicle decelerates.

Take into account the traffic situation before calling up the stored speed.

# Requirements:

- ESP® must be activated, but not intervening.
- The driven speed is at least 15 mph (20 km/h).
- The transmission is in position **D**.



To activate cruise control: press rocker switch 1 up.

To activate cruise control: press rocker switch ② up (SET/+) or down (SET/-). The current speed is stored and maintained by the vehicle.

or

Press rocker switch (a) up (RES). The last stored speed is called up and maintained by the vehicle.

If the last stored speed has previously been deleted, the currently driven speed is stored.

- i When you switch off the vehicle, the last speed stored is cleared.
- To increase/reduce speed: press rocker switch ② up/down to the pressure point. The stored speed is increased or reduced by 1 mph (1 km/h).

10

Press rocker switch ② beyond the pressure point.

The stored speed is increased or reduced by 5 mph (10 km/h).

or

Accelerate the vehicle to the desired speed.

DEALER ePROCESS

- ▶ Press rocker switch ② up.
  If cruise control is activated and Traffic Sign
  Assist has detected a speed restriction sign with
  a maximum permissible speed and this is displayed in the instrument cluster:
- To adopt the detected speed: press rocker switch (a) up.
  The maximum permissible speed shown by the traffic sign is stored and the vehicle
- ➤ To deactivate cruise control: press rocker switch ③ down (CNCL).

maintains this speed.

- To deactivate cruise control: press rocker switch own.
- i If you brake, deactivate ESP® or if ESP® intervenes, cruise control is deactivated. When you switch off the vehicle, the last speed stored is cleared.

#### Active Distance Assist DISTRONIC

#### **Function of Active Distance Assist** DISTRONIC



Active Distance Assist DISTRONIC maintains the set speed on free-flowing roads. If vehicles in front are detected, the set distance is maintained, if necessary, until the vehicle comes to a halt. The vehicle accelerates or brakes depending on the distance to the vehicle in front and the set speed. The speed (in the range between 15 mph (20 km/h) and 130 mph (210 km/h)) and the distance to the vehicle in front are set and saved on the steering wheel.

Other features of Active Distance Assist DISTRONIC:

- · Adjusts the driving style depending on the selected drive program (fuel-saving, comfortable or dynamic) ( $\longrightarrow$  page 134)
- Reacts to stationary vehicles detected in urban speed ranges (except bicycles and motorcycles)
- Initiates acceleration to the stored speed if the turn signal indicator is switched on to change to the overtaking lane.
- Takes one-sided overtaking restrictions into account on highways or on multi-lane roads with separate roadways (country-dependent).

Vehicles with Active Parking Assist: if the vehicle has been braked to a standstill on multilane, separate roadways by Active Distance Assist DISTRONIC, it can automatically follow the vehicle in front driving off again within 30 seconds. If a critical situation is detected when driving off, a visual and acoustic warning is given indicating that the driver must now take control of the vehicle. The vehicle is not accelerated any further.

Active Distance Assist DISTRONIC is only an aid. The driver is responsible for keeping a safe distance to the vehicle in front, for vehicle speed and for braking in good time.

# **System limitations**

The system may be impaired or may not function in the following instances:

- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying ambient light.
- The windshield in the area of the camera is dirty, fogged up, damaged or covered.
- If the radar sensors are dirty or covered.
- In parking garages or on roads with steep uphill or downhill gradients.
- If there are narrow vehicles in front, such as bicycles or motorcycles.

In addition, on slippery roads, braking or accelerating can cause one or several wheels to lose traction and the vehicle could then skid.

Do not use Active Distance Assist DISTRONIC in these situations.



WARNING Risk of accident from acceleration or braking by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC may accelerate or brake in the following cases, for example:

- If the vehicle pulls away using Active Distance Assist DISTRONIC.
- If the stored speed is called up and is considerably faster or slower than the currently driven speed.
- If Active Distance Assist DISTRONIC no. longer detects a vehicle in front or does not react to relevant objects.
- Always carefully observe the traffic conditions and be ready to brake at all times.
- Take into account the traffic situation before calling up the stored speed.

WARNING Risk of accident due to insufficient deceleration by Active Distance Assist DISTRONIC

Active Distance Assist DISTRONIC brakes your vehicle with up to 50% of the maximum possible deceleration. If this deceleration is not sufficient, Active Distance Assist DISTRONIC alerts you with a visual and acoustic warning.

- In these cases, adjust your speed and keep a sufficient distance.
- Brake the vehicle yourself and/or take evasive action.

WARNING Risk of accident if detection function of Active Distance Assist DISTRONIC is impaired

Active Distance Assist DISTRONIC does not react or has a limited reaction:

 when driving on a different lane or when changing lanes

DEALER EPROCESS

- · to pedestrians, animals, bicycles or stationary vehicles, or unexpected obstacles
- to complex traffic conditions
- to oncoming vehicles and crossing traffic

As a result. Active Distance Assist DISTRONIC may neither give warnings nor intervene in such situations


Always observe the traffic conditions carefully and react accordingly.

# **Operating Active Distance Assist DISTRONIC**

### Requirements:

- The vehicle has been started
- The electric parking brake is released.
- ESP® is activated and is not intervening.
- The transmission is in position  $\mathbf{D}$ .
- All the doors are closed.
- Check of the radar sensor system has been successfully completed (vehicle traveling faster than 12 mph (20 km/h)).

- Parking Assist PARKTRONIC is not being used to park the vehicle or to exit from a parking space.
- The vehicle does not skid.



- To activate/deactivate Active Distance Assist DISTRONIC: press button 1.
- ➤ To activate Active Distance Assist DISTRONIC: press rocker switch (3) up (SET

+) or down (SET-), or press rocker switch @ up. Remove your foot from the accelerator pedal.

The current speed is stored and maintained by the vehicle.

or

- If rocker switch is pressed up again after activation with a stored speed, Active Distance Assist DISTRONIC is activated with the speed restriction displayed in the instrument cluster.
- To pull away with Active Distance Assist DISTRONIC: remove your foot from the

brake pedal and activate Active Distance Assist DISTRONIC.

Press rocker switch 4 up (RES).

or

Depress the accelerator pedal briefly and firmly.

The functions of Active Distance Assist DISTRONIC continue to be carried out.

▲ WARNING Risk of accident due to Active Distance Assist DISTRONIC still being activated when you leave the driver's seat

If you leave the driver's seat while the vehicle is being braked by Active Distance Assist DISTRONIC only, the vehicle can roll away.

- Always deactivate Active Distance Assist DISTRONIC and secure the vehicle to prevent it from rolling away before you leave the driver's seat.
- ➤ To deactivate Active Distance Assist DISTRONIC: press rocker switch down (CNCL).



To increase/reduce speed: press rocker switch (3) up/down to the pressure point. The stored speed is increased or reduced by 1 mph (1 km/h).

Press and hold rocker switch (3) up/down to the pressure point.

The stored speed is increased or reduced in increments of 1 mph (1 km/h).

Press rocker switch (3) beyond the pressure point.

The stored speed is increased or reduced by 5 mph (10 km/h).

- Press and hold rocker switch (3) beyond the pressure point.
  - The stored speed is increased or reduced in increments of 5 mph (10 km/h).
- To increase or reduce the specified distance from the vehicle in front: press rocker switch 2 up or down.

### **Function of Active Speed Limit Assist**

(i) The availability of the following function is country-dependent.



If a change in the speed limit is detected and Active Distance Assist DISTRONIC is activated. Active Distance Assist DISTRONIC adapts this new speed as the stored speed.

DEALER ePROCESS

The driven speed is adjusted when the vehicle is level with the traffic sign at the latest. In the case of signs indicating entry into an urban area, the speed is adapted beforehand. The speed limit display in the Instrument Display is always updated when the vehicle is level with the traffic sign.

If there is no speed restriction on an unlimited stretch of road (e.g. on a freeway), the recommended speed is adopted as the stored speed. The system uses the speed stored on an unlimited stretch of road as the recommended speed. If you do not alter the stored speed on an unlimited stretch of road, the recommended speed is 80 mph (130 km/h).

If Active Distance Assist DISTRONIC has been put into passive mode by pressing the accelerator pedal, only speed limits which are higher than the set speed are adopted.

Active Speed Limit Assist is only an aid. The driver is responsible for keeping a safe distance to the vehicle in front, for vehicle speed and for braking in good time. The maximum permissible speed also depends on factors such as the road surface and traffic conditions.

# **System limitations**

Temporary speed restrictions (e.g. for a certain time or due to weather conditions) cannot be properly detected by the system. The maximum permissible speed applying for a vehicle with a trailer is not detected by the system. In these situations you must adjust your speed yourself.

★ WARNING Risk of accident due to Active Speed Limit Assist adapting the vehicle's speed

The speed adopted by Active Speed Limit Assist may be too high or incorrect in some individual cases, such as:

- . In the wet or in fog
- When towing a trailer
- Ensure that the driven speed complies with traffic regulations.
- Adjust the driving speed to suit current traffic and weather conditions.

# Function of route-based speed adaptation

(i) The availability of the following function is country-dependent.

When Distance Assist DISTRONIC is active, the function adjusts the speed depending on the route events ahead. Depending on the drive program selected, the vehicle negotiates the route event ahead in a fuel-saving, comfortable or dynamic manner. When the route event has been passed, the vehicle accelerates again to the stored speed. The set distance to the vehicle in front, vehicles detected ahead and speed restrictions ahead are taken into account.

Route-based speed adjustment can by configured in the multimedia system

 $(\longrightarrow)$  page 167).

Route events ahead are:

- Bends
- T-intersections, traffic circles and toll stations
- Turns and exits



i When the toll station is reached, Active Distance Assist DISTRONIC adopts the speed as the stored speed.

Also, the speed is reduced if the turn signal to change lanes is switched on and one of the following situations is detected:

- . Turning off at intersections
- Driving on slowing-down lanes
- Driving on lanes adjacent to slowing-down lanes

The driver is responsible for choosing the right speed and observing other road users. This applies in particular to intersections, traffic circles and traffic lights, as route-based speed adaptation does not brake the vehicle to a standstill.

When route guidance is active, the first speed adjustment is carried out automatically. If the turn signal indicator is switched on, the selected route is confirmed and further speed adjustment is activated.

Speed adjustment is canceled in the following cases:

- If the turn signal indicator is switched off before the route event.
- If the driver depresses the accelerator or brake pedal during the process.

#### **System limitations**

Route-based speed adaptation does not take right of way regulations into account. The driver is responsible for complying with road traffic regulations and driving at a suitable speed.

In difficult conditions (e.g. unclear roads, narrow lanes, wet road surfaces, snow or ice) or when driving with a trailer, the speed adjustment made by the system may not always be suitable. In these situations the driver must intervene accordingly.



**WARNING** Risk of accident in spite of route-based speed adjustment

Route-based speed adjustment might malfunction or be temporarily unavailable in the following situations:

- If map data is not up to date or available
- If you do not follow the selected route guidance
- If the set route is re-planned
- In road construction areas
- When towing a trailer
- · In bad weather or road conditions
- · If the accelerator pedal is depressed
- Adjust the speed to the traffic situation.

# Setting route-based speed adjustment

#### Requirements:

Active Distance Assist DISTRONIC is activated.

#### Multimedia system:

- → Vehicle → ( Assistance
- >> Speed Adjustment
- ▶ Activate or deactivate the function.



# **Active Steering Assist**

#### **Function of Active Steering Assist**

Active Steering Assist is country-dependent and only available for vehicles with the Driving Assistance Package.

Active Steering Assist is operational at speeds up to 130 mph (210 km/h) and helps you to stay in the center of the lane by means of moderate steering interventions. It uses the vehicle in front and the lane markings as a reference depending on the driven speed.

When the system is actively steering, the symbol is shown in green in the multifunction display.

#### Steering and touch detection

The driver is required to keep their hands on the steering wheel at all times and to be able to intervene at any time. The driver must expect a change from active to passive mode or vice versa at any time.



If the system reaches a system limitation or the driver has not steered the vehicle for a considerable period of time or has removed their hands from the steering wheel, the system will, depending on the situation, first alert the driver with a visual warning. Display **(1)** appears in the multifunction display. If the driver still does not steer the vehicle, or has still not taken hold of the steering wheel, a repeated warning tone sounds in addition to the visual warning message to remind the driver to take control of the vehicle.

The warning message does not appear or disappears if one of the following conditions are met:

The driver steers the vehicle.

• The driver presses a steering wheel button or operates Touch Control.

Active Steering Assist is only an aid. The driver is responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in lane. Before changing lanes, the driver must make sure that the neighboring lane is free (glance over the shoulder).

#### System limitations

Active Steering Assist has a limited steering torque for lateral guidance. In some cases, the steering intervention is not sufficient to keep the vehicle in the lane.

If the detection of lane markings and vehicles ahead is impaired, Active Steering Assist switches to passive mode. The system provides no support in this case. During the transition from the active to passive status, the symbol is shown as enlarged and flashes yellow. Once the system is passive the symbol is grayed out in the multifunction display.



The system may be impaired or may not function in the following instances:

- · In snow, rain, fog, heavy spray, if there is glare, direct sunlight, greatly varying ambient light, reflections or strong shadows on the roadway.
- Insufficient road illumination.
- The windshield in the area of the camera is dirty, fogged up, damaged or covered.
- · Absence of lane markings, or several unclear lane markings, or if the markings change rapidly.
- The distance to the vehicle in front is too small and the lane markings thus cannot be detected.
- The road is narrow and winding.
- Obstacles on the lane or projecting out into the lane.

The system does not provide assistance in the following conditions:

On tight bends, traffic circles and when turning.

When actively changing lane without switching on the turn signal.

**WARNING** Risk of accident if Active Steering Assist unexpectedly stops functioning

If the system limitations of Active Steering Assist are reached there is no guarantee that the system will remain active or will keep the vehicle in lane.

- Always keep your hands on the steering wheel and observe the traffic carefully.
- Always steer the vehicle paying attention to traffic conditions.

**WARNING** Risk of accident if Active Steering Assist unexpectedly intervenes

A malfunction in the detection of lane markings and objects can occur.


This could cause unexpected steering intervention.

Steer according to traffic conditions.

# **Activating Active Steering Assist**

### Requirements

- ESP® must be activated, but not intervening.
- Active Distance Assist DISTRONIC is activated.



If indicator lamp (1) is off: press button (2).



# **Function of Active Lane Change Assist**

(i) The availability of the following function is country-dependent.

Active Lane Change Assist supports the driver when changing lanes by applying steering torque if the driver operates a turn signal.

Assistance when changing lanes is provided if all the following conditions are met:

- · You are driving on a freeway or road with multiple lanes in the direction of travel.
- The neighboring lane is separated by a broken lane marking.
- No vehicle is detected in the adjacent lane.
- The driven speed is between 50 mph (80 km/h) and 110 mph (180 km/h).
- Active Lane Change Assist is switched on in the multimedia system.
- Active Steering Assist is switched on and active.



If no vehicle is detected in the adjacent lane and a lane change is permitted, the steering wheel symbol and the arrow are shown in green ②. The Lane Change to the Left message appears, for example. If Active Lane Change Assist has been activated with the turn signal indicator but a lane change is not immediately possible, the steering wheel symbol remains green and the arrow appears gray ①. When the lane change support starts, the turn signal indicator is automatically activated.

If a lane change is not possible, the arrow fades out after a few seconds and a new lane change must be initiated. An immediate lane change is

only possible on freeway sections without speed limits.

If the system is impaired, Active Lane Change Assist may be canceled. If it is canceled, the Lane Change Canceled message appears in the multifunction display and a warning tone sounds.

**WARNING** Risk of accident from changing lane to an occupied adjacent lane

Lane Change Assist cannot always detect clearly if the adjacent lane is free.

The lane change might be initiated although the adjacent lane is not free.

- Before changing lanes, make sure that the neighboring lane is free and there is no danger to other road users.
- Monitor the lane change.



▲ WARNING Risk of accident if Lane Change Assist unexpectedly stops functioning

If the system limitations for Lane Change Assist have been reached, there is no guarantee that the system will remain active.

Lane Change Assist cannot then assist you by applying steering torques.

Always monitor the lane change and keep your hands on the steering wheel. Observe the traffic conditions and steer and/or brake if necessary.

#### System limitations

The system limitations of Active Steering Assist apply to Active Lane Change Assist (→ → page 167).

The system may also be impaired or may not function in the following situations:

- The sensors in the rear bumper are dirty, damaged or covered, for instance by a sticker or ice and snow.
- The exterior lighting is malfunctioning.

#### Activating/deactivating Active Lane Change **Assist**

Multimedia system:

- → Vehicle → ( Assistance
- Select Lane Change Assist.
- Activate  $\overline{\triangleleft}$  or deactivate  $\square$  the function.

# **Function of Active Emergency Stop Assist**

If the driver continually ignores the visual or acoustic warning to put their hands on the steering wheel, the Beginning Emergency Stop message appears in the multifunction display. If the driver still does not respond, Active Distance Assist DISTRONIC reduces the speed. The vehicle is decelerated in stages to a standstill. At speeds below 40 mph (60 km/h) the hazard warning lights switch on automatically.

When the vehicle is stationary, the following actions are carried out:

- The vehicle is secured with the electric parking brake
- Active Distance Assist DISTRONIC is ended
- The vehicle is unlocked

• If possible, an emergency call is placed to the Mercedes-Benz emergency call center

The driver can cancel the deceleration at any time by performing one of the following actions:

- Steering
- Braking or accelerating
- Pressing a steering wheel button
- Operating Touch Control
- · Activating or deactivating Active Distance Assist DISTRONIC

# Overview of Active Distance Assist DISTRONIC displays in the instrument cluster

The assistance graphic and the status display show the status of the following functions in the instrument cluster:

- Active Distance Assist DISTRONIC
- Route-based speed adaptation

# Active Steering Assist DEALER EPROCESS

### **Assistant display**



- Route-based speed adaptation (type of route event)
- Vehicle in front
- Distance indicator
- Set specified distance
- Own vehicle

# Active Distance Assist DISTRONIC status display and route-based speed adaptation



- Active Distance Assist DISTRONIC selected, set specified distance (number of segments below the vehicle)
- Active Distance Assist DISTRONIC deactivated, speed stored

- Active Distance Assist DISTRONIC active, speed stored, no vehicle detected (bright vehicle symbol)
- Active Distance Assist DISTRONIC active, speed stored, vehicle detected (green vehicle symbol)
- Active Distance Assist DISTRONIC and routebased speed adaptation active, speed stored
- i) On highways or high-speed major roads, the green 医文 vehicle symbol is displayed cyclically when the vehicle is ready to pull away.

# Speedometer

The stored speed is highlighted on the speedometer. If the speed of the vehicle in front or the speed adjustment is less than the stored speed due to the route event ahead, the segments in the speedometer light up. Activation or deactivation of Active Distance Assist DISTRONIC, as well as alterations to the speed due to manual or automatic adoption of the speed limit, are displayed in the control feedback of the multifunction display on a single line.

DEALER ePROCESS

# **Active Steering Assist status display**



- Gray steering wheel: Active Steering Assist switched on and passive
- Green steering wheel: Active Steering Assist switched on and active
- Flashing steering wheel: prompt to the driver to actively confirm or transition from active to passive status, system limitation detected

During the transition from the active to passive status, symbol (3) is shown as enlarged and flashes yellow. Once the system is passive, symbol (1) is shown as gray in the multifunction display.

#### Information on Hill Start Assist

Hill Start Assist holds the vehicle for a short time when pulling away on a hill under the following conditions:

- The transmission is in position **D** or **R**.
- The electric parking brake is released.

This gives you enough time to move your foot from the brake pedal to the accelerator pedal and depress it before the vehicle begins to roll.

**WARNING** Risk of accident and injury due to the vehicle rolling away

After a short time, Hill Start Assist no longer holds the vehicle and it can roll away.

Therefore, swiftly move your foot from the brake pedal to the accelerator pedal. Never attempt to leave the vehicle if it is being held by Hill Start Assist.

#### **HOLD** function

#### **HOLD** function

The HOLD function holds the vehicle at a standstill without requiring you to depress the brake pedal, e.g. while waiting in traffic.

#### **System limitations**

The HOLD function is only intended to provide assistance when driving and is not a sufficient means of safeguarding the vehicle against rolling away when stationary.

• The incline must not be greater than 30%.

# Activating/deactivating the HOLD function



WARNING Risk of an accident due to the HOLD function being activated when you leave the vehicle

If you leave the vehicle while only the HOLD function is braking the vehicle, the vehicle can roll away in the following situations:

 If there is a malfunction in the system or in the power supply.



- If the HOLD function is deactivated by depressing the accelerator pedal or brake pedal, e.g. by a vehicle occupant.
- Always deactivate the HOLD function and secure the vehicle against rolling away before leaving the vehicle.

I NOTE Damage from automatic braking

When Active Brake Assist, Active Distance Assist DISTRONIC or the HOLD function are activated, the vehicle brakes autonomously in certain situations.

To avoid damage to the vehicle, deactivate these systems in the following or similar situations:

- During towing
- ▶ In a car wash

#### Requirements:

- The vehicle is stationary.
- The driver's door is closed or the seat belt on the driver's side is fastened.

- The engine is running or has been automatically switched off by the ECO start/stop function.
- The electric parking brake is released.
- Active Distance Assist DISTRONIC is deactivated.
- The transmission is in position **D**, **R** or **N**.

# Activating the HOLD function

- Depress the brake pedal and after a short time quickly depress further until the HOLD display appears in the multifunction display.
- Release the brake pedal.

#### **Deactivating the HOLD function**

- Depress the accelerator pedal to pull away.
- Depress the brake pedal until the HOLD display disappears from the multifunction display.

The HOLD function is deactivated in the following situations:

- Active Distance Assist DISTRONIC is activated.
- The transmission is switched to position  ${\bf P}$ .
- The vehicle is secured with the electric parking brake.

In the following situations, the vehicle is held by the transmission position  $\boxed{\textbf{P}}$  or by the electric parking brake:

- The seat belt is unfastened and the driver's door is opened.
- The drive system is switched off.
- There is a malfunction in the system or the power supply is insufficient.

#### **AIRMATIC**

#### **Function of AIRMATIC**

AIRMATIC is an air suspension system with variable damping for improved driving comfort. The



all-round level control system ensures the best possible suspension and constant ground clearance, even with a laden vehicle. When driving at speed, the vehicle is lowered automatically to improve driving safety and to reduce fuel consumption. You also have the option of manually adjusting the vehicle level.

AIRMATIC includes the following components and functions:

- air suspension with automatic all-round level control
- speed-dependent lowering to reduce fuel consumption
- manually selectable high-level setting for greater ground clearance
- ADS PLUS (Adaptive Damping System with constant damping force adjustment)
- DYNAMIC SELECT switch and level button

# Available suspension settings

Drive program	Characteristics
S (Sport) S (Sport Plus)	<ul> <li>The suspension tuning is firmer.</li> <li>When driving at speeds above 50 mph (70 km/h) the vehicle is lowered.</li> <li>The vehicle is not lowered any further if you are traveling at higher speeds.</li> <li>When driving at speeds below 30 mph (48 km/h) the vehicle is raised again.</li> </ul>
(Comfort) (E) (Economy)	<ul> <li>The suspension tuning is comfortable.</li> <li>When driving at speeds above 75 mph (120 km/h) the vehicle is lowered.</li> <li>When driving at speeds above 100 mph (160 km/h) the vehicle continues to be lowered.</li> <li>When driving at speeds below 75 mph (120 km/h) the vehicle is raised again.</li> </ul>

# Setting the vehicle level

**WARNING** Risk of accident because vehicle level is too high

If you drive at a higher vehicle level, the driving characteristics may be impaired due to the higher vehicle center of gravity.

The vehicle can drift outwards, for example, when steering or cornering.

Always choose a vehicle level which is suited to the driving style and the road surface conditions.

WARNING Risk of entrapment from vehicle lowering

When lowering the vehicle, people could become trapped if their limbs are between

the vehicle body and the tires or underneath the vehicle.

Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when you lower the vehicle.



WARNING Risk of entrapment from vehicle lowering

# Vehicles with AIRMATIC or level control:

When you unload luggage or leave the vehicle, the vehicle first rises slightly and then returns to the set level shortly afterwards.

You or anyone else in the vicinity of the wheel arches or the underbody could thus become trapped.


The vehicle can also be lowered after being locked.

When leaving the vehicle, make sure that nobody is in the vicinity of the wheel arches or the underbody.

### Requirements:

- The vehicle has been started.
- The vehicle must not be moving faster than 50 mph (80 km/h).

# Raising the vehicle



Press button 1. Indicator lamp (2) lights up. The vehicle is set to the high level.

Your selection is saved.



The vehicle is lowered again in the following situations:

- When driving faster than 75 mph (120 km/h).
- When driving between 50 mph (80 km/h) and 75 mph (120 km/h) for approximately three minutes.
- After selecting a drive program using the DYNAMIC SELECT switch.

The vehicle is adjusted to the height of the last active drive program.

# Lowering the vehicle

Press button Indicator lamp 2 goes out. The vehicle is adjusted to the height of the last active drive program.

#### MAGIC BODY CONTROL

#### MAGIC BODY CONTROL function

MAGIC BODY CONTROL is an electrohydraulic suspension with variable damping for improved driving comfort. The all-round level control system ensures the best possible suspension and constant ground clearance, even with a laden vehicle. When driving at speed, the vehicle is lowered automatically to improve driving safety and to reduce fuel consumption. The suspension tuning is adjusted depending on the road surface, vehicle load and the drive program selected. The ROAD SURFACE SCAN function detects areas of unevenness in the road before you drive over them by means of a multifunction camera. This reduces chassis movements. The option of manually adjusting the vehicle level is also available.

The damping is tuned individually for each wheel and is affected by the following factors:

- The driving style, e.g. sporty
- The road condition, e.g. bumps
- The individual selection of the drive program:
   (Sport+), (Sport), (Comfort),
   (CURVE) or (Economy)

MAGIC BODY CONTROL comprises:

- Active Body Control ABC
- ROAD SURFACE SCAN

- Curve inclination function CURVE
- Automatic level control system
- Automatic vehicle stabilization in the event of sidewinds
- Speed-dependent lowering to reduce fuel consumption
- Manually selectable high-level setting for greater ground clearance
- DYNAMIC SELECT switch and level button



# Available suspension settings

Drive program	Characteristics
(Sport Plus) (Sport)	<ul> <li>The suspension tuning is firmer.</li> <li>The vehicle is lowered.</li> <li>When driving at speeds between 40 mph (65 km/h) and 87 mph (140 km/h) the vehicle is lowered steadily and remains at this level up to the maximum vehicle speed.</li> <li>When returning to speeds between 87 mph (140 km/h) and 40 mph (65 km/h) the vehicle is raised again.</li> <li>ROAD SURFACE SCAN is deactivated.</li> </ul>
© (Comfort)	<ul> <li>The suspension tuning is comfortable.</li> <li>The vehicle is set to the normal level.</li> <li>When driving at speeds between 40 mph (65 km/h) and 63.7 mph (102.5 km/h) the vehicle is lowered steadily.</li> <li>ROAD SURFACE SCAN is active.</li> </ul>



Drive program	Characteristics
(CURVE)	<ul> <li>The suspension tuning is comfortable.</li> <li>The vehicle is set to the normal level.</li> <li>When driving at speeds between 40 mph (65 km/h) and 63.7 mph (102.5 km/h) the vehicle is lowered steadily.</li> <li>The curve inclination function is active.</li> <li>ROAD SURFACE SCAN is active.</li> </ul>
<b>E</b> (Economy)	<ul> <li>The suspension tuning is comfortable.</li> <li>The vehicle is set to the normal level.</li> <li>When driving at speeds between 40 mph (65 km/h) and 63.7 mph (102.5 km/h) the vehicle is lowered steadily.</li> <li>ROAD SURFACE SCAN is deactivated.</li> </ul>

#### **Crosswind Assist**

The crosswind stabilization:

- Operates by changing wheel loads through adjusting the ABC spring struts.
- Reduces disruptions when driving straight ahead.
- Supports countersteering.

 Is active in the speed range between 50 mph (80 km/h) and 130 mph (210 km/h) when driving straight ahead or cornering gently.

#### **Function of ROAD SURFACE SCAN**

i This function is not available in all countries.



#### ROAD SURFACE SCAN:

- Monitors the road in front of the vehicle using multifunction camera (1).
- Is active when one of drive programs (Comfort) or (CURVE) is selected.
- Detects unevenness in the road surface, e.g. bumps, before the vehicle drives over them.
- · Reduces chassis movements.

### **System limitations**

ROAD SURFACE SCAN can be impaired in the following situations or can stop functioning:

- If the roadway is insufficiently lit, e.g. at night.
- In snow, rain, fog, heavy spray, if there is glare, in direct sunlight or in greatly varying ambient light.
- If the windshield in the area of multifunction camera is dirty, fogged up, damaged or covered.
- If the road surface has no optic structure or reflects light.
- If the distance to the vehicle in front is too short.
- If sections of the route have a very small radius of curvature.
- During dynamic driving maneuver, e.g. if you accelerate or brake the vehicle sharply.
- At speeds below 5 mph (7 km/h) or above 112 mph (180 km/h).
- If the vehicle is at a raised level or in drive program (Sport) or (Sport Plus).

DEALER ePROCESS

#### Setting the vehicle level



**WARNING** Risk of accident because vehicle level is too high

If you drive at a higher vehicle level, the driving characteristics may be impaired due to the higher vehicle center of gravity.

The vehicle can drift outwards, for example, when steering or cornering.

Always choose a vehicle level which is suited to the driving style and the road surface conditions.

# A

**WARNING** Risk of entrapment from vehicle lowering

When lowering the vehicle, people could become trapped if their limbs are between the vehicle body and the tires or underneath the vehicle.

Make sure no one is underneath the vehicle or in the immediate vicinity of

the wheel arches when you lower the vehicle.

WARNING Risk of entrapment from vehicle lowering

Vehicles with AIR BODY CONTROL or level control system: When you unload luggage or leave the vehicle, the vehicle first rises slightly and then returns to the set level shortly afterwards.

You or anyone else in the vicinity of the wheel arches or the underbody could thus become trapped.

The vehicle can also be lowered after being locked.


When leaving the vehicle, make sure that nobody is in the vicinity of the wheel arches or the underbody.

#### Requirements:

- The vehicle has been started.
- The vehicle must not be moving faster than 75 mph (120 km/h).

• Only lower the vehicle: when the vehicle is stationary, all the doors have to be closed.

# Raising the vehicle



Press button 1. Indicator lamp ② lights up.

The vehicle is set to the high level.

Your selection is saved.

DEALER ePROCESS

The vehicle is lowered again in the following situations:

- When driving faster than 75 mph (120 km/h).
- When driving between 50 mph (80 km/h) and 75 mph (120 km/h) for approximately three minutes.
- After selecting a drive program using the DYNAMIC SELECT switch.


The vehicle is adjusted to the height of the last active drive program.

# Lowering the vehicle

Press button 1 Indicator lamp 2 goes out. The vehicle is adjusted to the height of the last active drive program.

#### **Parking Assist PARKTRONIC**

### **Function of Parking Assist PARKTRONIC**



Parking Assist PARKTRONIC is an electronic parking assistance system with ultrasound. It monitors the area around your vehicle using six sensors 1 in the front bumper and six sensors in the rear bumper. Parking Assist PARKTRONIC shows you the distance between your vehicle and a detected obstacle visually and audibly.

Parking Assist PARKTRONIC is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that there are no persons, animals or objects in

the maneuvering area while maneuvering and parking in/exiting parking spaces.

In the standard setting, an intermittent warning tone sounds from a distance of approximately 1.0 ft (0.3 m) to an obstacle in front and approximately 3.3 ft (1.0 m) to an obstacle behind. A continuous tone sounds from a distance of approximately 0.7 ft (0.2 m). Using the Warn early setting in the multimedia system, the warning tones for front and side impact protection can also be set to sound at a greater distance of approximately 3.3 ft (1.0 m) → page 185).

The **Warn early** setting is always active in the rear of the vehicle.

If Parking Assist PARKTRONIC is deactivated, Active Parking Assist is unavailable.

### Parking Assist PARKTRONIC display in the multimedia system



Vehicles with Active Parking Assist without a 360° Camera





Vehicles with Active Parking Assist and a 360° Camera

If Active Parking Assist is deactivated and an obstacle is detected in the path of the vehicle, a pop-up window for Parking Assist PARKTRONIC appears in the multimedia system at speeds below 6 mph (10 km/h).

#### System limitations

Parking Assist PARKTRONIC does not necessarily take into account the following obstacles:

• Obstacles below the detection range, e.g. persons, animals or objects.

 Obstacles above the detection range, e.g. overhanging loads, overhangs or loading ramps of trucks.

The sensors must be free of dirt, ice and slush. Otherwise, they may not function correctly. Clean the sensors regularly, taking care not to scratch or damage them.

# Function of the passive side impact protection

Passive side impact protection is an additional Parking Assist PARKTRONIC function which warns the driver about obstacles at the side of the vehicle. A warning is issued when obstacles are detected between the front and rear detection range. In order for an object on the side to be detected, the sensors in the front and rear bumper must first detect the object while you are driving past it.

During the parking procedure or maneuvering, objects are detected as the vehicle drives past. If you steer in the direction of a detected obstacle and there is a risk of a lateral collision, a warning is issued. The segments on the sides

light up yellow or red, depending on the distance to the obstacle.

#### Segment color depending on distance

Color	Lateral distance in cm
Yellow	Approx. 30 - 60
Red	Approx. < 30

In order for lateral front or rear segments to be displayed, the vehicle must first travel a distance of at least half of the vehicle length. Once the vehicle has traveled the length of the vehicle, all of the lateral front and rear segments can be displayed.





Vehicles without 360° Camera

- Parking Assist PARKTRONIC is only operational in the front and rear
- Parking Assist PARKTRONIC is operational and can also warn the driver about obstacles. at the side of the vehicle
- Obstacle detected at the front right (yellow) and rear (red)



Vehicles with 360° Camera

- Parking Assist PARKTRONIC is only operational in the front and rear
- Parking Assist PARKTRONIC is operational and can also warn the driver about obstacles at the side of the vehicle
- Obstacle detected at the front right (red)

Saved obstacles on the sides are deleted in the following situations, for example:

- · You park the vehicle and switch off the ignition.
- You open the doors. DEALER ePROCESS

After the engine is restarted, obstacles must be detected again before a new warning can be issued.

#### **System limitations**

The system limitations for Parking Assist PARKTRONIC apply for passive side impact protection.

The following objects are not detected, for example:

- Pedestrians who approach the vehicle from the side
- Objects placed next to the vehicle

#### Deactivating/activating Parking Assist PARKTRONIC


**NOTE** Risk of an accident from objects at close range

Parking Assist PARKTRONIC may not detect certain objects at close range.

When parking or maneuvering the vehicle, pay particular attention to any objects which are above or below the sensors, e.g. flower pots or drawbars.

The vehicle or other objects could otherwise be damaged.

If indicator lamp (2) is not lit, Parking Assist PARKTRONIC is active. If the indicator lamp is lit and the symbol appears in the multifunction display, Parking Assist PARKTRONIC is not active.



Press button 1

(i) Parking Assist PARKTRONIC is automatically activated when the vehicle is started

#### Adjusting the warning tones of Parking Assist PARKTRONIC

Multimedia system:

→ Vehicle → ( Assistance

➤ Camera & Parking
➤ Set Warning Tones

#### Adjusting the volume of the warning tones

- Select Warning Tone Volume.
- Set a value.

#### Adjusting the pitch of the warning tones

Select Warning Tone Pitch. Set a value.

#### Specifying the starting point for the warning tones

You can specify whether the Parking Assist PARKTRONIC warning tones should commence when the vehicle is further away from an obstacle.

- Select Warn Early.
- Activate ✓ or deactivate ☐ the function.

#### DEALER ePROCESS


### Activating/deactivating audio fadeout

You can specify whether the volume of a media source in the multimedia system is to be reduced when Parking Assist PARKTRONIC gives an audible warning.

- Select Audio Fadeout During Warning Tones.
- Activate  $\overline{ }$  or deactivate  $\square$  the function.

#### Reversing camera

#### Function of the rear view camera



When you engage reverse gear, the image from rear view camera (1) is shown in the multimedia system. Dynamic guide lines show the path the vehicle will take with the steering wheel in its current position. This helps you to orient yourself and to avoid obstacles when backing up.

The rear view camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that there are no persons, animals or objects etc., in the maneuvering area while maneuvering and parking.


You can select from the following views:

- Normal view
- · Wide-angle view

The area behind the vehicle is displayed as a mirror image, as in the inside rearview mirror.



#### Camera views in the multimedia system



Normal view

- Yellow lane marking the course the tires will take at the current steering wheel angle (dynamic)
- Yellow guide line, vehicle width (driven surface) depending on the current steering wheel angle (dynamic)
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the rear area
- Orange warning display of Parking Assist PARKTRONIC: obstacles are a medium distance away (between approximately 1.0 ft (0.3 m) and 2.0 ft (0.6 m))

- Red warning display of Parking Assist PARKTRONIC: obstacles are very close (approximately 1.0 ft (0.3 m) or less)
- Yellow warning display of Parking Assist PARKTRONIC: obstacles are at a distance of between approximately 2.0 ft (0.6 m) and 3.3 ft (1.0 m)
- i) If the entire system fails, the inner segments of the warning display are shown in red. The indicator lamp on the Parking Assist PARKTRONIC button lights up and the symbol appears in the multifunction display. If the system fails at the rear, the display of the segments changes as follows:
  - The rear segments are shown in red when backing up.
  - The rear segments are hidden when driving forwards.

When Active Parking Assist is active, the lanes are displayed in green.
If Parking Assist PARKTRONIC is deactivated, the warning display fades out.



Wide-angle view

# System failure

If there is no operational readiness, the following message appears in the multimedia system:



DEALER ePROCESS

### **System limitations**

The rear view camera will not function or will only partially function in the following situations:

- The trunk lid is open.
- There is heavy rain, snow or fog.
- The ambient light conditions are poor, e.g. at night.
- The camera lens is obstructed, dirty or fogged up. Observe the notes on cleaning the rear view camera ( >>> page 349).
- The camera or rear of your vehicle is damaged. In this case, have the camera and its position and setting checked at a qualified specialist workshop.

The field of vision and other functions of the rear view camera may be restricted due to additional accessories on the rear of the vehicle (e.g. license plate bracket or bicycle rack).

(i) The contrast of the display may be impaired by direct sunlight or by other light sources, e.g. when driving out of a garage. In this case, pay particular attention.  Have the display repaired or replaced if, for example, pixel errors considerably restrict its use.

#### 360° camera

#### Function of the 360° Camera

The 360° Camera is a system that consists of four cameras. The cameras cover the immediate vehicle surroundings. The system assists you, e.g. when parking or at exits with reduced visibility.

The 360° Camera is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that there are no persons, animals or objects etc., in the maneuvering area while maneuvering and parking.

The system evaluates images from the following cameras:

Rear view camera

- Front camera
- Two side cameras in the outside mirrors

#### Views of the 360° Camera

You can select from different views:



- Wide-angle view, front
- Top view with image from the front camera
- Top view with images from the side cameras in the outside mirrors
- Wide-angle view, rear
- Top view with image from the rear view camera
- Top view with trailer view (if trailer hitch is installed)

#### DEALER ePROCESS

#### Top view



- Lane indicating the route the vehicle will take with the steering wheel in its current position
- Yellow warning display of Parking Assist PARKTRONIC: obstacles at a distance of approximately 3.3 ft (1.0 m) or less
- Your vehicle from above

If the distance to the object lessens, the color of warning display ② changes. From a distance of approximately 2.0 ft (0.6 m) the warning display is shown in orange. From a distance of approximately 1.0 ft (0.3 m) the warning display is shown in red.

When Parking Assist PARKTRONIC is operational and no object is detected, the segments of the warning display are shown in gray.


(i) If the entire system fails, the segments of the warning display are shown in red. The indicator lamp on the PARKTRONIC button lights up and the Post symbol appears in the multifunction display.

If the system fails at the rear, the display of the segments changes as follows:

- The rear segments are shown in red when backing up.
- The rear segments are hidden when driving forwards.

If Parking Assist PARKTRONIC is deactivated, the warning display fades out.

#### **Guide lines**




- Yellow lane marking the course the tires will take at the current steering wheel angle (dvnamic)
- Yellow guide line, vehicle width (driven surface) depending on the current steering wheel angle (dynamic)
- Red guide line at a distance of approximately 1.0 in (0.3 m) from the rear area
- Mark at a distance of approx. 3.3 ft (1.0 m)
- (i) When Active Parking Assist is active, the lanes are displayed in green.

DEALER EPROCESS

The guide lines in the multimedia system display show the distances to your vehicle. The distances only apply to road level.

#### Side view of the mirror cameras

The sides of the vehicle can be seen in this view.



- Guide line of external vehicle dimensions with outside mirrors folded out
- Marker of the wheel contact points

# System failure

If there is no operational readiness, the following message appears in the multimedia system:



# **System limitations**

The 360° Camera will not function or will only partially function in the following situations:

- The doors are open.
- The side mirrors are folded in.
- The trunk lid is open.
- There is heavy rain, snow or fog.
- The ambient light conditions are poor, e.g. at night.
- The camera lens is obstructed, dirty or fogged up.
- If cameras or vehicle components in which the cameras are installed are damaged. In

this event, have the cameras, their positions and their setting checked at a qualified specialist workshop.

Do not use the 360° Camera under such circumstances. You could otherwise injure others or collide with objects when parking or maneuvering the vehicle.

On vehicles with height-adjustable suspension or if the vehicle is carrying a heavy load, leaving the standard height can result in inaccuracies in the guide lines and in the display of the generated images, depending on technical conditions.

The field of vision and other functions of the camera system may be restricted due to additional attachments on the vehicle (e.g. license plate bracket, bicycle rack).

See the notes on cleaning the 360° Camera  $(\longrightarrow)$  page 349).

# Selecting a view for the 360° Camera

#### Requirements:

• The Auto, Rear View Cam, function is selected in the multimedia system.

DEALER ePROCESS

- Engage reverse gear.
- In the multimedia system, select the desired view.

#### Opening the camera cover of the rear view camera

Multimedia system:

- → Vehicle → ( Assistance
- >> Camera & Parking
- Select Open Camera Cover.
  - The camera cover closes automatically after some time or after an ignition cycle.

### Setting the camera as a favorite

You can call up the camera view directly in the multimedia system by setting it as a favorite.

- Press the button on the control element. The main functions are displayed.
- Navigate downwards twice. The Favorites menu appears.
- Select New Favorite.
- Select Vehicle.
- Select Camera.

#### **Active Parking Assist**

#### **Function of Active Parking Assist**

Active Parking Assist is an electronic parking assistance system which uses ultrasound and is automatically activated during forward travel. The system is operational at speeds of up to approximately 22 mph (35 km/h). When all the conditions are fulfilled, the symbol appears in the multifunction display in the instrument cluster and the system automatically searches for and measures parking spaces on both sides of the vehicle parallel and perpendicular to the direction of travel. If Active Parking Assist is activated, suitable parking spaces are shown in the display of the multimedia system. The symbol appears in the display of the multimedia system. The arrows show on which side of the roadway free parking spaces are located.

The parking space and, if necessary, the parking direction can be selected as desired. Active Parking Assist calculates a suitable vehicle path and assists you in parking and exiting the parking space.

Active Parking Assist supports by changing gear, accelerating, braking and steering the vehicle.

Active Parking Assist is only an aid. It is not a substitute for your attention to the surroundings. The responsibility for safe maneuvering and parking remains with you. Make sure that no persons, animals or objects etc. are in the maneuvering range.

Active Parking Assist is canceled if, among other things, one of the following actions is carried out:

- You deactivate Parking Assist PARKTRONIC.
- You deactivate Active Parking Assist.
- · You begin steering.
- You apply the parking brake.
- You engage transmission position **P**.
- ESP® intervenes.
- You open the doors or the trunk lid while driving.

#### System limitations

Objects located above or below the detection range of Active Parking Assist are not detected



when the parking space is being measured. These are also not taken into account when the parking maneuver is calculated, e.g. overhanging loads, overhangs or loading ramps of trucks or the boundaries of parking spaces. In some circumstances, Active Parking Assist may therefore guide you into the parking space prematurely.

WARNING Risk of accident due to objects located above or below the detection range of Active Parking Assist

If there are objects above or below the detection range, the following situations may arise:

- Active Parking Assist may steer too early.
- Vehicles with automatic transmis**sion:** The vehicle may not stop in front of these objects.

This could cause a collision.

In these situations, do not use Active Parking Assist.

Snowfall or heavy rain may lead to a parking space being measured inaccurately. Parking

spaces that are partially occupied by trailer drawbars might not be identified as such or be measured incorrectly. Only use Active Parking Assist on level, high-grip ground.

Do not use Active Parking Assist in the following situations:

- In extreme weather conditions such as ice, packed snow or in heavy rain.
- When transporting a load that protrudes beyond the vehicle.
- If the parking space is on a steep downhill or uphill gradient.
- · When snow chains are installed.

Active Parking Assist may also display parking spaces that are not suitable for parking, e.g.:

- Parking spaces where parking is prohibited.
- Parking spaces on unsuitable surfaces.

Active Parking Assist will not assist you with parking spaces at right angles to the direction of travel in the following situations:


If two parking spaces are located immediately next to each other.

• If the parking space is immediately next to a low obstacle such as a curb.

Active Parking Assist will not assist you with parking spaces parallel or at right angles to the direction of travel in the following situations:

- If the parking space is on a curb.
- If the parking space is bordered by an obstacle, e.g. a tree, a post or a trailer.


# Parking with Active Parking Assist



Press button **①**.

The Active Parking Assist view appears on the multimedia system display.





- If you have driven past a suitable parking space: bring the vehicle to a standstill. Area 2 displays detected parking spaces (4) and vehicle path (3).
- Vehicle path (3) shown on the multimedia system display may differ from the actual vehicle path.
- Select desired parking space 4.
- Where necessary, select the parking direction: forwards or reverse. Vehicle path (3) is shown, depending on the selected parking space and parking direction.

- Confirm the selected parking space.
- The indicator is automatically switched on when the parking procedure is started. When the gear is changed to  $\mathbf{D}$ , the indicator is automatically switched off.
- WARNING Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or exiting a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users

- Pay attention to objects and other road users.
- Where necessary, stop the vehicle or cancel the parking procedure with Active Parking Assist.
- If, for example, the Please Engage Reverse Gear message appears in the multimedia sys-

tem display: select the corresponding transmission position.

The vehicle drives into the selected parking space.

On completion of the parking procedure, the Parking Assist Finished, Take Control of Vehicle display message appears. Further maneuvering may still be necessary.

- After completion of the parking procedure, safeguard the vehicle against rolling away. When required by legal requirements or local conditions: turn the wheels towards the curb.
- You can stop the vehicle and change the transmission position during the parking procedure. The system then calculates a new vehicle path. The parking procedure can then be continued. If no new vehicle path is available, the transmission position will be changed again. If the vehicle has not yet reached the parking space, the parking procedure will be canceled, should a gear be changed.




#### Exiting a parking space with Active Parking Assist

#### Requirements

You can only exit a parking space with Active Parking Assist if you have previously parked the vehicle with Active Parking Assist.

Please note that you are responsible for the vehicle and surroundings during the entire parking procedure.

Start the vehicle.



Press button 1. The Active Parking Assist view appears on the multimedia system display.





- If the vehicle has been parked at right angles to the direction of travel: in area 2, select direction of travel 3.
- The vehicle path shown on the multimedia system display may differ from the actual vehicle path.
- Confirm direction of exit 3 to drive out of the parking space.
- The turn signal indicator is automatically switched on when the exiting procedure is started.

WARNING Risk of accident due to vehicle swinging out while parking or pulling out of a parking space

While parking or exiting a parking space, the vehicle swings out and can drive onto areas of the oncoming lane.

This could cause you to collide with objects or other road users

- Pay attention to objects and other road users.
- Where necessary, stop the vehicle or cancel the parking procedure with Active Parking Assist.
- If, for example, the Please Engage Forward Gear message appears in the multimedia system display: select the corresponding transmission position.

The vehicle moves out of the parking space. The turn signal indicator is automatically switched off.



Example: vehicles with 360° Camera

After the exiting procedure has been completed, the Parking Assist Finished, Take Control of Vehicle message appears in the display of the multimedia system. A warning tone and display

4 in the multimedia system prompt you to take over control of the vehicle. You have to accelerate, brake, steer and change gear yourself again.

#### **Function of Drive Away Assist**

Drive Away Assist can reduce the severity of an impact when pulling away. If an obstacle is detected in the direction of travel, the vehicle's speed is briefly reduced to approx. 1 mph (2 km/h). If a critical situation is detected, the

LIM symbol appears on the camera image of the multimedia system.

**WARNING** Risk of accident caused by limited detection performance of Drive Away Assist

Drive Away Assist cannot always clearly identify objects and traffic situations.

In such cases, Drive Away Assist might:

- Warn you without reason and limit the vehicle speed.
- Not warn you or not limit the vehicle speed.
- Always pay careful attention to the traffic situation; do not rely on Drive Away Assist alone.
- Be prepared to brake or swerve as necessary, provided the traffic situation permits and that it is safe to take evasive action.

Drive Away Assist is only an aid. It is not a substitute for your attention to the surroundings.



The responsibility for safe maneuvering and parking remains with you. Make sure that no persons, animals or objects etc. are in the maneuvering range.

A risk of a collision may arise in the following situations, for example:

- If the driver mixes up the accelerator and brake pedals.
- If the wrong gear is selected.

The Drive Away Assist function is active under the following conditions:

- If Parking Assist PARKTRONIC is activated.
- Every time the gear is changed to R or D when the vehicle is at a standstill.
- If the detected obstacle is less than approx.
   3.3 ft (1.0 m) away.
- If the maneuvering assistance function is activated in the multimedia system.

#### **System limitations**

Drive Away Assist is not available on inclines.

#### **Function of Cross Traffic Alert**

(i) Also read the instructions on Blind Spot Assist (→ page 203).



Vehicles with Blind Spot Assist: drivers can also be warned of any crossing traffic when backing up out of a parking space. If a critical situation is detected, symbol appears in the multimedia system display. If the driver does not respond to the warning, the vehicle's brakes can

DEALER EPROCESS

be applied automatically. To do this, the function uses the radar sensors in the bumper. The area adjacent to the vehicle is continually monitored.

If the radar sensors are obstructed by vehicles or other objects, detection is not possible.

The Cross Traffic Alert function is active under the following conditions:

- If Blind Spot Assist is activated.
- If the vehicle is backing up at walking pace.
- If the maneuvering assistance function is activated in the multimedia system.

#### **System limitations**

The Cross Traffic Alert function is not available on inclines.

# Deactivating/activating maneuvering assistance

Multimedia system:

- → Vehicle → ( Assistance
- ➤ Camera & Parking ➤ Maneuvering Assist.
- ▶ Activate or deactivate the function.

Maneuvering assistance must be active for the function of Drive Away Assist
 page 195) and Cross Traffic Alert
 page 196).

#### ATTENTION ASSIST

#### Function of ATTENTION ASSIST

ATTENTION ASSIST assists you on long, monotonous journeys, e.g. on highways and trunk roads. If ATTENTION ASSIST detects indicators of fatigue or increasing lapses in concentration on the part of the driver, it suggests taking a break.

ATTENTION ASSIST is only an aid. It cannot always detect fatigue or lapses in concentration in time. The system is not a substitute for a well-rested and attentive driver. On long journeys, take regular breaks in good time that allow for adequate recuperation.

You can choose between two settings.

- Standard: normal system sensitivity.
- Sensitive: higher system sensitivity. The driver is warned earlier and the attention

level detected by ATTENTION ASSIST is adapted accordingly.

If drowsiness or increasing lapses in concentration are detected, the ATTENTION ASSIST: Take a Break! warning appears in the Instrument Display. You can acknowledge the message and take a break where necessary. If you do not take a break and ATTENTION ASSIST continues to detect increasing lapses in concentration, you will be warned again after a minimum of 15 minutes.





You can have the following status information for ATTENTION ASSIST displayed in the assistance menu of the on-board computer:

- The length of the journey since the last break.
- The attention level determined by ATTENTION ASSIST.

If ATTENTION ASSIST is unable to calculate the attention level and cannot issue a warning, the System Suspended message appears.

If a warning is given in the Instrument Display, the multimedia system offers to search for a rest area. You can select a rest area and start navigation to this rest area. This function can be activated and deactivated in the multimedia system.

If ATTENTION ASSIST is deactivated, the symbol appears in the assistance graphic in the Instrument Display when the engine is running. ATTENTION ASSIST is activated automatically when the engine is re-started. The last selected sensitivity level remains stored.

#### System limitations

ATTENTION ASSIST is active in the 37 mph (60 km/h) to 124 mph (200 km/h) speed range.

The functionality of ATTENTION ASSIST is restricted, and warnings may be delayed or not occur at all in the following situations:

- If you have been driving for less than approximately 30 minutes.
- If the road condition is poor (uneven road surface or potholes).
- If there is a strong side wind.
- If you adopt a sporty driving style (high cornering speeds or high rates of acceleration).
- If the Steering Assist function of Active Distance Assist DISTRONIC is active.
- If the time has been set incorrectly.
- In active driving situations, if you change lanes and vary your speed frequently.

The ATTENTION ASSIST tiredness or alertness assessment is deleted and restarted when continuing the journey in the following situations:

• If you switch off the engine.

 If you unfasten your seat belt and open the driver's door (e.g. changing drivers or taking a break).

# **Setting ATTENTION ASSIST**

Multimedia system:

→ Vehicle → (♠) Assistance

>> ATTENTION ASSIST

#### **Setting options**

Select Standard, Sensitive or Off.

#### Suggesting a rest area


- Select Suggest Rest Area.
- Activate ✓ or deactivate the function ☐.

  If ATTENTION ASSIST detects fatigue or increasing lack of attention, it suggests a rest area in the vicinity.
- Select a suggested rest area: you are guided to the selected rest area.



#### **Traffic Sign Assist**

# **Function of Traffic Sign Assist**



Since Traffic Sign Assist also uses the data stored in the navigation system, it can update the display in the following situations without detecting traffic signs:

 When the vehicle changes roads, e.g. a freeway entry or exit road. • When a village or city boundary which is stored in the digital map is passed.

The camera also detects traffic signs with a restriction indicated by an additional sign (e.g. in wet conditions).

Traffic Sign Assist is only an aid. The driver is responsible for keeping a safe distance to the vehicle in front, for vehicle speed and for braking in good time. The maximum permissible speed also depends on factors such as the road surface and traffic conditions.

# Warning when the maximum permissible speed is exceeded

The system can warn you if you unintentionally exceed the maximum permissible speed. To do this, you can specify in the multimedia system by how much the maximum permissible speed can be exceeded before a warning is issued. You can specify whether the warning is to be just a visual warning or an acoustic one as well.

# Display in the Instrument Display

Traffic Sign Assist is not available in all countries. If it is unavailable, display 
is shown in the speedometer.

#### **System limitations**

The system may be impaired or may not function in the following situations:

- If there is poor visibility, e.g. due to insufficient illumination of the road, if there are highly variable shade conditions or in rain, snow, fog or heavy spray.
- If there is glare, e.g. from oncoming traffic, direct sunlight or reflections.
- If the windshield in the area of the multifunction camera is dirty, or if the camera is fogged up, damaged or covered.
- If the traffic signs are hard to detect, e.g. due to dirt or snow, or because they are covered or due to insufficient lighting.
- If the information in the navigation system's digital map is incorrect or out-of-date.
- If the signs are ambiguous, e.g. traffic signs on construction sites or in adjacent lanes.
- If you turn sharply when traffic signs are outside the camera's field of vision.



# **Setting Traffic Sign Assist**

Multimedia system:

→ Vehicle → (Assistance

>> Traffic Sign Assist

# Activating/deactivating automatic adoption of speed limits

Requirements:

- Active Distance Assist DISTRONIC is activated.
- Select Limit Adoption.
- Activate 

  or deactivate 

  the function. The speed limits detected by Traffic Sign Assist are automatically adopted by Active Distance Assist DISTRONIC.

# Displaying detected traffic signs in the media display

- Select Display in COMAND.
- Activate 

  ✓ or deactivate 

  the function.

#### Adjusting the type of warning

Select Visual & Audible, Visual or None.


### Adjusting the warning threshold

This value determines the speed at which a warning is issued when exceeded.

- Select Warning Threshold.
- Set the desired speed.

# **Night View Assist**

# **Function of Night View Assist**



With the aid of camera ②, Night View Assist helps you to recognize the course of the road or obstacles in the dark. The multifunction display then shows a monochrome image of the surrounding area in front of the vehicle. Infrared

DEALER EPROCESS

camera (1) helps detect pedestrians and animals.

Night View Assist is only an aid. The driver is responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in lane.

i As infrared light is not visible to the human eye, Night View Assist can remain activated when there is oncoming traffic.

The infrared headlamps switch on in the dark from speeds of approximately 5 mph (10 km/h). This means that, while stationary, you do not have the full visual range and cannot check whether Night View Assist is working.

#### **System limitations**

Night View Assist cannot display objects directly in front of or directly next to the vehicle. It may be the case that objects are highlighted as well as pedestrians or animals.

The system may be impaired or may not function in the following instances:

 in poor visibility, e.g. snow, rain, fog or heavy spray.

- the windshield is dirty in the vicinity of the camera.
- the camera is fogged up, damaged or covered.
- the infrared camera in the radiator grill is damaged, dirty, fogged up or covered.
- on bends, on hilltops or in dips.
- at high ambient temperatures.

#### Function of pedestrian and animal detection of Night View Assist


Night View Assist can detect pedestrians using typical characteristics, e.g. the body contours and posture of a person standing upright.

Large animals, e.g. deer, cows or horses, can also be detected. Smaller animals, e.g. dogs or cats, are not detected.

Pedestrian and animal detection is automatically switched on when the following requirements are fulfilled:

- Night View Assist is activated.
- The driving speed is at least 5 mph (10 km/h).

It is dark



- Night View Assist display
- Standby symbol for active pedestrian detection
- Highlighting
- Pedestrian detected


If pedestrian detection is active, standby symbol

2 appears. There is no separate symbol for animals. Detected pedestrians or animals are highlighted by a color frame.



# Activating or deactivating Night View Assist Requirements:

- The vehicle has been started or the ignition is switched on.
  - The light switch is in the AUTO or Dosition.
- Reverse gear has not been engaged.



- Press button ①. The appropriate Night View Assist display appears in the multifunction display.
- (i) The infrared headlamps are deactivated at speeds below 3 mph (5 km/h). The Night View image continues to be displayed until you switch it off by pressing button (i).

# Switching automatic activation on/off

#### Requirements:

- Pedestrian detection is active ( page 201).
- The roadway is not lit.
- The speed is at least 37 mph (60 km/h).

If all the requirements are fulfilled, the night vision image is automatically shown in the multifunction display as soon as people or animals are detected.

Multimedia system:


- → Vehicle → (Assistance)
- ➤ Aut. Night View Assist
- ▶ Activate or deactivate the function.

# Spotlight function

The spotlight function is an additional function for Night View Assist. It runs in the background and flashes the headlamps at detected persons with four short impulses. This attracts the driver's attention to approaching pedestrians.



# Display in the assistance graphic



- Spotlight function switched on but not operating
- Spotlight function switched on and operating

The pedestrian symbol in the assistance graphic indicates the status of the spotlight function. If the pedestrian symbol is displayed dark (1), the function is switched on. If the symbol is dis-

played bright (2), the conditions for the Spotlight function are also fulfilled.

#### System limitations

The spotlight function does not flash at animals.

The spotlight function is not active or is active only to a limited extent if:

- You are driving in city traffic.
- The pedestrians are located in the area of an oncoming vehicle or a vehicle in front.

#### Activating/deactivating the spotlight function

#### Requirements:

- · Pedestrian detection is active  $(\longrightarrow)$  page 201).
- The roadway is not lit.
- The speed is at least 37 mph (60 km/h).
- Adaptive Highbeam Assist Plus is switched on.

If all the requirements are fulfilled, the headlamp flashes four short pulses at a pedestrian detected on or near to the roadway.

#### Multimedia system:

- → Vehicle → 😝 → Light Settings Spotlight
- Activate or deactivate the function.

### **Blind Spot Assist and Active Blind Spot** Assist with exit warning

# **Function of Blind Spot Assist and Active** Blind Spot Assist with exit warning

Blind Spot Assist and Active Blind Spot Assist use two lateral, rear-facing radar sensors to monitor the area up to 130 ft (40 m) behind your vehicle and 10 ft (3 m) directly next to your vehicle.

If a vehicle is detected at speeds above approximately 8 mph (12 km/h) and this vehicle subsequently enters the monitoring range directly next to your vehicle, the warning lamp in the outside mirror lights up red.

If a vehicle is detected close to the side of your vehicle, the red warning lamp in the outside mirror flashes. If you switch on the turn signal indicator in the corresponding direction, a warning

tone sounds once. If the turn signal indicator remains switched on, all other detected vehicles are indicated only by the flashing of the red warning lamp.

If you overtake a vehicle quickly, no warning is given.

# **WARNING** Risk of accident despite Blind Spot Assist

Blind Spot Assist does not react to vehicles approaching and overtaking you at a greatly different speed.

As a result, Blind Spot Assist cannot warn drivers in this situation.

Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

Blind Spot Assist and Active Blind Spot Assist are only aids. They may fail to detect some vehicles and are no substitute for attentive driving. Always ensure that there is sufficient distance to the side for other road users and obstacles.



#### **Exit warning**

The exit warning is an additional function of Blind Spot Assist and can warn vehicle occupants about approaching vehicles when leaving the vehicle when stationary.

# **WARNING** Risk of accident despite exit warning

The exit warning reacts neither to stationary objects nor to vehicles approaching you at a greatly different speed.

As a result, the exit warning cannot warn drivers in these situations.

Always pay particular attention to the traffic situation when opening the doors and make sure there is sufficient clearance.

If there is a vehicle in the monitoring range, this is indicated in the outside mirror. If a vehicle occupant opens the door on the side with the warning, a warning tone sounds and the warning lamp in the outside mirror starts to flash.

This additional function is only available when Blind Spot Assist is activated and up to a maximum of three minutes after the ignition has been switched off. The exit warning is no longer available once the warning lamp in the outside mirror flashes three times.

The exit warning is only an aid and not a substitute for the attention of vehicle occupants. The responsibility for opening and closing the doors and for leaving the vehicle remains with the vehicle occupants.

#### System limitations

Blind Spot Assist and Active Blind Spot Assist may be limited in the following situations:

- if there is dirt on the sensors or the sensors are obscured
- in poor visibility, e.g. due to fog, heavy rain or snow
- if there are narrow vehicles, e.g. bicycles or motorbikes
- if the road has very wide or narrow lanes
- if vehicles are not driving in the middle of their lane

DEALER EPROCESS

Warnings may be issued in error when driving close to crash barriers or similar solid lane borders. Always make sure that there is sufficient distance to the side for other traffic or obstacles.

Warnings may be interrupted when driving alongside long vehicles, for example trucks, for a prolonged time.

Blind Spot Assist is not operational when reverse gear is engaged.

The exit warning may be limited in the following situations:

- When the sensors are covered by adjacent vehicles in narrow parking spaces.
- When people approach the vehicle.
- In the event of stationary or slowly moving objects.

# Function of brake application (Active Blind Spot Assist)

If Active Blind Spot Assist detects a risk of a side impact in the monitoring range, a course-correcting brake application is carried out. This is designed to help you avoid a collision.

The course-correcting brake application is available in the speed range between approximately 20 mph (30 km/h) and 125 mph (200 km/h).

**WARNING** Risk of accident despite brake application of Active Blind Spot Assist

A course-correcting brake application cannot always prevent a collision.

- Always steer, brake or accelerate yourself, especially if Active Blind Spot Assist warns you or makes a coursecorrecting brake application.
- Always maintain a safe distance at the sides.

**WARNING** Risk of accident despite Active Blind Spot Assist

Active Blind Spot Assist does not react to the following:

• If vehicles overtake too closely on the side, placing them in the blind spot area  Vehicles approaching and overtaking you at a greatly different speed

As a result, Active Blind Spot Assist may neither give warnings nor intervene in such situations.

Always pay careful attention to the traffic situation and maintain a safe distance at the side of the vehicle.

Active Blind Spot Assist is only an aid. It may fail to detect some vehicles and is not a substitute for attentive driving. Always ensure that there is sufficient distance to the side for other road users and obstacles.



If a course-correcting brake application occurs. the red warning lamp flashes in the outside mirror and a warning tone sounds. In addition, a display 1 indicating the danger of a side collision appears in the multifunction display.

In rare cases, the system may make an inappropriate brake application. This brake application may be interrupted at any time if you steer slightly in the opposite direction or accelerate.

#### **System limitations**

Either a course-correcting brake application appropriate to the driving situation, or none at all, may occur in the following situations:

- · Vehicles or obstacles, e.g. crash barriers, are located on both sides of your vehicle.
- A vehicle approaches too closely on the side.
- You have adopted a sporty driving style with high cornering speeds.
- You brake or accelerate significantly.
- A driving safety system intervenes, e.g. ESP® or Active Brake Assist.
- ESP® is deactivated.

 A loss of tire pressure or a faulty tire is detected.


#### Activating/deactivating Blind Spot Assist or Active Blind Spot Assist

Multimedia system:

- → Vehicle → (Assistance
- **▶ Blind Spot Assist**
- ▶ Activate or deactivate the function.

# **Active Lane Keeping Assist**

### **Function of Active Lane Keeping Assist**



Active Lane Keeping Assist monitors the area in front of your vehicle by means of multifunction camera ①. It serves to protect you against unintentionally leaving your lane. You will be warned by vibration pulses in the steering wheel and gui-

DEALER ePROCESS

ded by a course-correcting brake application back into your lane.

You are warned by vibration pulses in the steering wheel in the following circumstances:

- Active Lane Keeping Assist detects a lane marking.
- · A front wheel drives over this lane marking.

You will also be guided back into your lane by means of a course-correcting brake application if the following conditions are met:

- Active Lane Keeping Assist detects lane markings on both edges of the lane.
- A front wheel drives over a solid lane marking.

You can activate or deactivate the Active Lane Keeping Assist warning.

Active Lane Keeping Assist can neither reduce the risk of an accident if you fail to adapt your driving style nor override the laws of physics. It cannot take into account road, weather or traffic conditions. Active Lane Keeping Assist is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

Active Lane Keeping Assist can bring the vehicle back into the lane with a lane-correcting brake application. In the case of a broken lane marking being detected, a brake application will only be made if a vehicle has been detected in the adiacent lane. Oncoming traffic can be detected.

In addition, overtaking vehicles and vehicles in adjacent lanes can be detected.

Active Lane Keeping Assist is available in the speed range between 37 mph (60 km/h) and 124 mph (200 km/h).



If a lane-correcting brake application occurs, display **1** appears in the multifunction display.

# Sensitivity of Active Lane Keeping Assist

(i) The availability of the following function is country-dependent.

A lane-correcting brake application also occurs in the Sensitive setting in the following situations:

- Active Lane Keeping Assist detects a solid lane marking.
- A front wheel drives over this lane marking.

#### System limitations

No lane-correcting brake application occurs in the following situations:

- You clearly and actively steer, brake or accelerate.
- · You have switched on the turn signal indicator (situation-dependent).
- A driving safety system intervenes, such as ESP®, Active Brake Assist or Active Blind Spot Assist.

DEALER ePROCESS

- You have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- When FSP® is deactivated
- If a loss of tire pressure or a faulty tire has been detected and displayed.

The system may be impaired or may not function in the following situations:

- If there is poor visibility, e.g. due to insufficient illumination of the road, if there are highly variable shade conditions or in rain, snow, fog or heavy spray.
- If there is glare, e.g. from oncoming traffic, the sun or reflections.
- If the windshield in the area of the multifunction camera is dirty, or if the camera is fogged up, damaged or covered.
- If there are no lane markings, or several unclear lane markings are present for one lane, e.g. around roadworks.
- If the lane markings are worn, dark or covered.

- If the distance to the vehicle in front is too. short and thus the lane markings cannot be detected
- If the lane markings change quickly, e.g. lanes branch off, cross one another or merge.
- If the roadway is very narrow and winding.

Vehicles with Driving Assistance package or **Driving Assistance Plus package:** Active Lane Keeping Assist uses radar sensors to monitor several areas around the vehicle. If the radar sensors in the rear bumper are dirty or covered with snow, the system may be impaired or may not function. If an obstacle in the lane in which you are driving has been detected, no lane-correcting brake application occurs.

### Activating/deactivating Active Lane Keeping Assist (vehicles with Parking Assist PARKTRONIC)

**WARNING** Risk of accident despite Active Lane Keeping Assist warning

A lane-correcting brake application cannot always bring the vehicle back into the original lane.

Always steer, brake or accelerate yourself, especially if Active Lane Keeping Assist warns you or makes a lane-correcting brake application.

WARNING Risk of accident despite intervention of Active Lane Keeping Assist

Active Lane Keeping Assist does not detect traffic conditions or road users. In very rare cases, the system may make an inappropriate brake application, e.g. after intentionally driving over a solid lane marking.

The brake application can be interrupted at any time if you steer slightly in the opposite direction.

DEALER ePROCESS

Always make sure that there is sufficient distance to the side for other traffic or obstacles.


**WARNING** Risk of accident despite Lane **Keeping Assist** 

Lane Keeping Assist cannot always clearly detect lane markings.

In such cases, Lane Keeping Assist can:

- give an unnecessary warning
- not give a warning
- Always pay particular attention to the traffic situation and keep within the lane, especially if Active Lane Keeping Assist alerts you.

Be sure to observe the system limitations of Active Lane Keeping Assist.



- Press button 2. If indicator lamp 1 lights up, Active Lane Keeping Assist is activated, the lane markings are shown as light in the assistance graphic. When Active Lane Keeping Assist is active, the lane markings are shown in green in the assistance graphic.
- Depending on the country, you may have to press and hold the button to deactivate.

#### Setting the sensitivity of Active Lane Keeping Assist

Multimedia system:

→ Vehicle → ( Assistance

- >> Act. Lane Keep. Assist
- Select a setting.

### Activating/deactivating the warning

Switch Lane Depart. Warning on **✓** or off

You do not receive any warning when leaving a lane if the lane keeping warning system is deactivated.

# Vehicle towing instructions

The vehicle is not suitable for the use of tow bar systems that are used for flat towing or dinghy towing, for example. Attaching and using tow bar systems can lead to damage on the vehicle. When you are towing a vehicle with tow bar systems, safe driving characteristics cannot be guaranteed for the towing vehicle or the towed vehicle. The vehicle-trailer combination may swerve from side to side. Comply with the per-

DEALER ePROCESS

mitted towing methods ( $\longrightarrow$  page 364) and the instructions for towing with both axles on the ground ( $\longrightarrow$  page 366).

# **Instrument Display overview**

WARNING Risk of accident due to an instrument display malfunction

If the Instrument Display has failed or malfunctioned, you may not recognize function restrictions applying to safety relevant systems.


The operating safety of your vehicle may be impaired.

- Drive on carefully.
- Have the vehicle checked immediately at a qualified specialist workshop.

Mercedes-AMG vehicles: observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.

If the operating safety of your vehicle is impaired, park the vehicle safely as soon as possible. Contact a qualified specialist workshop.

# Instrument Display



- Speedometer
- Multifunction display
- Tachometer
- Coolant temperature gauge
- Fuel level and fuel filler flap location indicator
- This display is an example. Other displays are possible instead of tachometer 3.

The segments in speedometer (1) indicate the system status for the following:

DEALER ePROCESS

• Cruise control ( page 159)

Active Distance Assist DISTRONIC ( → page 162)

Vehicles with Traffic Sign Assist: Detected instructions and traffic signs will appear on the speedometer ( page 198).

**NOTE** Engine damage due to excessively high engine speeds

The engine will be damaged if you drive with the engine in the overrevving range.

Do not drive with the engine in the overrevving range.

The overrevving range is shown in red on tachometer 3. When the overrevving range is reached, the fuel supply will be interrupted to protect the engine.


During normal operating conditions, coolant temperature display 4 may rise to 248 °F (120 °C).

# WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service

#### Overview of the buttons on the steering wheel



- Back/Home button (press and hold), on-board computer
- Touch Control, on-board computer
- Control panel for cruise control or Active Distance Assist DISTRONIC
- Control panel for multimedia system:

★ Displays favorites

VOL: control knob, adjusts the volume or switches the sound off (press)

Makes/accepts a call

DEALER ePROCESS

- Rejects/ends a call
- Touch Control multimedia system
- Back button (press and hold)

# Operating the on-board computer


WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

Observe the legal requirements for the country in which you are currently driving when you operate the on-board computer.

The on-board computer displays appear on the multifunction display ( $\longrightarrow$  page 214).



The on-board computer can be operated using left-hand Touch Control 2 and left-hand back/ home button 1

The following menus are available:

- Service
- Assistance
- Trip
- Navigation
- Radio
- Media
- Phone
- HUD
- Designs

The menus can be called up from the menu bar on the multifunction display.

- To call up the menu bar: press the back button on the left 1 until the menu bar is displayed.
- **Vehicles without Active Distance Assist DISTRONIC:** press the f button to call up the menu bar of the on-board computer.





- To scroll in the menu bar: swipe left or right on left-hand Touch Control 2.
- To call up a menu or confirm a selection: press the left-hand Touch Control 2.
- To scroll through displays or lists on the menu: swipe upwards or downwards on lefthand Touch Control 2.
- To call up a submenu or confirm a selection: press left-hand Touch Control 2.
- To exit a submenu: press back button on the left 

  .

#### Setting the design

On-board computer:

¬→ Designs

This function is only available for vehicles with a Widescreen Cockpit.

The following designs can be selected:

- Classic
- Sport
- Progressive
- To select a design: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control. The Instrument Display is shown in the selected design.

# Setting the additional value range



Example: G-meter

- Additional value range
- Index points
- To select display content: swipe to the right on the left-hand Touch Control.
- Swipe upwards or downwards on the lefthand Touch Control to select display content. When display content is selected, additional value range 
  will briefly be highlighted.

Index points will display the selected list item.

The following display content can be selected in the Classic and Sport designs:

- Tachometer
- Navigation
- ECO display
- Consumption
- G-Meter

The following content can be selected in the Progressive design:

- Date
- Navigation
- ECO display
- Consumption
- G-Meter

# Overview of displays on the multifunction display




- Outside temperature
- Drive program
- Transmission position
- Time
- Display section
- Vehicles with an Instrument Display in the Widescreen Cockpit: the position of the displays will differ from those displayed here.

Further displays on the multifunction display:

- Gearshift recommendation  $(\longrightarrow)$  page 138)
- Active Parking Assist activated → page 192)
- Parking Assist PARKTRONIC deactivated P₩■ (—→ page 184)
- Cruise control (—— page 159)
- Active Distance Assist DISTRONIC  $(\longrightarrow)$  page 162)
- Active Brake Assist(——— page 159)
- Active Steering Assist(\(\bigsim\) page 167)
- Active Lane Keeping /**=**\ Assist( page 206)
- Active Lane Change 4/€/\▶ Assist(——> page 169)
- HOLD function ( $\longrightarrow$  page 173) HOLD
- Adaptive Highbeam Assist **■** —→ page 109)

Vehicles with Traffic Sign Assist: Detected 

#### Adjusting the instrument lighting



Turn brightness control ① up or down. The lighting of the Instrument Display and in the control elements of the vehicle interior is adjusted.



#### Menus and submenus

#### Functions on the Service menu of the onboard computer

#### On-board computer:

- → Service
- To select the function: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control.

#### Functions in the Service menu:

- Tires:
  - Checking the tire pressure with the tire pressure monitoring system  $(\longrightarrow)$  page 380)
  - Restarting the tire pressure monitoring system ( page 381)
- ASSYST PLUS: calling up the service due date ( $\longrightarrow$  page 336)

#### Calling up the assistant display

#### On-board computer:

- → Assistance
- When you have set the style to Classic, you can view the assistant display menu contents in the left-hand portion of the Instrument Display.

The following displays are available on the assistant display menu:

- Assistant display
- Attention level ( page 197)
- To switch between the displays: swipe upwards or downwards on the left-hand Touch Control.





Status displays on the assistant display:

- off: ATTENTION ASSIST deactivated
- ক্ট্রাল: Active Brake Assist deactivated
- · Light lane markings: Active Lane Keeping Assist activated
- Green lane markings: Active Lane Keeping Assist active

- Gray radar waves next to vehicle: Blind Spot Assist activated
- Green radar waves next to vehicle: Blind Spot Assist active
- Active Distance Assist DISTRONIC displays — page 162).

### Calling up displays on the Trip menu

On-board computer:



- (i) When you have the style set to Classic, you can view information on the journey in the left-hand area of the Instrument Display.
- To select a display: swipe upwards or downwards on the left-hand Touch Control.

Displays in the Trip menu:

- Standard display
- Range and current fuel consumption
   A recuperation display is also available for certain engines. If there is only a small amount of fuel left in the fuel tank, the dis-

play shows a vehicle being refueled instead of the range.

- ECO display (→ page 133)
- Trip computer From Start and From Reset
- · Digital speedometer
- (i) The digital speedometer only appears in the Sport and Supersport styles.



Example: standard display

- Trip distance
- 2 Total distance





Example: trip computer

- Total distance
- ② Driving time
- Average speed
- Average fuel consumption

#### Resetting values on the Trip menu of the onboard computer

On-board computer:

#### **¬→** Trip

The spelling may differ in the main menu displayed. Therefore, observe the menu overview for the Instrument Display  $(\longrightarrow)$  page 211).

You can reset the values of the following functions:

- Trip distance
- Trip computer "From start" and "From reset"
- ECO display
- To select the function to be reset: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control.
- Select Yes.
- Press the left-hand Touch Control.

If you press and hold the left-hand Touch Control, the function will be reset immediately.

#### Calling up navigation instructions on the onboard computer

On-board computer:


¬→ Navigation



Example: no change of direction announced

- Distance to the next destination
- Estimated arrival time
- Distance to the next change of direction
- Current road





Example: change of direction announced

- Road to which the change of direction leads
- Distance to the change of direction
- Change-of-direction symbol
- Recommended lane and new lane during a change of direction (white)
- Possible lane
- Lane not recommended (dark gray)

Further possible displays in the Navigation menu:

• Calculate New Route or Calculating Route...: a new route is being calculated.

- Road Not Mapped: the road is unknown, e.g. newly built roads.
- No Route: no route could be calculated to the selected destination.
- i you have reached the destination or an intermediate destination.
- To exit the menu: press the back button on the left.

In the Navigation menu, you can also start navigation to one of the previous destinations:

- Press the left-hand Touch Control.
- To select the destination: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control. Route guidance is started.

If route guidance has already been activated, a request will appear asking whether you wish to end the current route guidance.

- Select Yes.
- Press the left-hand Touch Control. Route guidance is started.

# Selecting radio stations using the on-board computer

On-board computer:

¬→ Radio



- Frequency range
- Station
- Name of track
- Name of artist

When you select a station in the memory presets, the preset appears next to the station name. When you select a saved station in the frequency range, an asterisk appears next to the station name.

DEALER ePROCESS

 To select a radio station: swipe upwards or downwards on the left-hand Touch Control.

# Selecting frequency range or station preset list

- Press the left-hand Touch Control.
- ➤ To select the frequency range/station preset list: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control.

lose control of the vehicle.

traffic situation permits.

traffic situation. This could also cause you to

Only operate this equipment when the

If you cannot be sure of this, stop the

When telephoning, you must observe the legal

requirements for the country in which you are

vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

# Media playback using the on-board computer

On-board computer:

**¬→** Media



- Media source
- Current track and track number
- Name of artist
- Name of album
- To change tracks in the active media source: swipe upwards or downwards on the left-hand Touch Control.

#### Changing the media source

- Press the left-hand Touch Control.
- trol.
- Press the left-hand Touch Control.

### Dialing telephone numbers using the onboard computer

#### Requirements:

• The mobile phone is connected to the multimedia system.

On-board computer:

¬→ Phone

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the

The most recent telephone connections (dialed, received and missed calls) are displayed in the

Phone menu.

currently driving.

- To select the telephone number: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control. If there is only one telephone number saved to an entry: the telephone number is selected.
- If there are multiple telephone numbers saved to an entry: swipe upwards or down-

- To select a media source: swipe upwards or downwards on the left-hand Touch Con-

wards on the left-hand Touch Control to select the desired telephone number.

Press the left-hand Touch Control. The telephone number is dialed.

The following displays may appear instead of the telephone numbers dialed:

- Please Wait...: the application is starting. When a Bluetooth® connection to the mobile phone is not established, the menu for authorizing and connecting a mobile phone is displayed on the multimedia system  $(\longrightarrow)$  page 287).
- Importing Contacts...: the contacts from the mobile phone or from a storage medium are being imported.

#### Accepting/rejecting a call

When you receive a call, the Incoming Call - message appears on the Head-up Display.

- Swipe upwards or downwards on the lefthand Touch Control and select (Accept) or (Reject).
- Press the left-hand Touch Control.

The call may be accepted/rejected using the or buttons on the steering wheel.

#### Adjusting the Head-up Display settings on the on-board computer


On-board computer:

¬→ HUD

The following characteristics of the Head-up Display can be adjusted:

- Position
- Brightness
- Display Content
- To select characteristics: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control.
- To adjust the value: swipe upwards or downwards on the left-hand Touch Control.
- Press the left-hand Touch Control.





- Setting currently selected
- Digital speedometer
- Traffic Sign Assist
- Navigation displays


#### Head-up Display

#### Function of the Head-up Display

Mercedes-AMG vehicles: observe the notes in the Supplement. Otherwise, you may not recognize dangers.

The Head-up Display projects information from the navigation system, the driver assistance systems and some warning messages above the cockpit into the driver's field of vision.

### Display elements



- Navigation messages
- Current speed

- Detected instructions and traffic signs
- Set speed in the driver assistance system (e.g. cruise control)

When you receive a call, the Incoming Call message will appear on the Head-up Display.


#### **System limitations**

The visibility is influenced by the following conditions:

- Seat position
- The positioning of the display image
- Light conditions
- Wet roads
- Objects on the display cover
- Polarization in sunglasses
- In extreme sunlight, sections of the display may appear washed out. You can correct this by switching the Head-up Display off and on again.



# Switching the Head-up Display on/off



Press button 1.

# Notes on operating safety

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.
- **WARNING** Risk of distraction from operating mobile communication equipment while the vehicle is in motion

If you operate mobile communication equipment when driving, you will be distracted

from the traffic situation. This could also cause you to lose control of the vehicle.

Only operate this equipment when the vehicle is stationary.

For your own safety, always observe the following points when operating mobile communications equipment and especially your voice control system:


- Observe the legal requirements for the country in which you are driving.
- While driving, only operate mobile communications equipment and your voice control system when the traffic conditions permit it. You may otherwise be distracted from the traffic conditions and cause an accident, injuring yourself and others.
- If you use the voice control system in an emergency your voice can change and your telephone call, e.g. an emergency call, can thereby be unnecessarily delayed.
- Familiarize yourself with the voice control system functions before starting the journey.

#### Operation

Overview of operation of the Voice Control System on the multifunction steering wheel

The Voice Control System is operational approximately thirty seconds after the ignition is switched on.





- Press the rocker switch up: starts the Voice Control System
- Press the control knob: \( \sqrt{} \) switches the sound off or on (ends the Voice Control System)

Turn the control knob up/down: increases/ decreases the volume

Press the rocker switch up: makes/ accepts a call

Press the rocker switch down: rejects/ ends a call (ends the Voice Control System)

#### Conducting a dialog with the Voice Control System

- To start or continue a dialog: on the multifunction steering wheel, press the [ [ [ ] rocker switch up.
  - You can say a voice command after an acoustic signal.
- To correct an entry: say the Correction voice command.
- To select an entry from the selection list: say the line number or the contents.
- To browse the selection list: say the Next or Back voice command.
- To interrupt the dialog: say the Pause voice command.
- To cancel the dialog: say the Cancel voice command.

#### **Operable functions**

You can use the Voice Control System to operate the following equipment depending on the features:

- Telephone
- Text messages
- Navigation
- Address book
- Radio
- · Audio (memory card, Media Interface, USB and Bluetooth® audio)
- Vehicle

# Overview of types of voice command

A distinction is made between the following voice commands:

Global voice commands can be said at any time and regardless of the current application, e.g. the voice commands Navigate to, Call or Text message to.



 Application-specific voice commands are only available for the active application.

Once the Voice Control System is started an autocue is shown. Apart from the available voice commands for the application currently active, this also cites example voice commands for other applications which are not active. In this way, you will be familiar more quickly with the available voice commands. The list can be scrolled or it can be operated by speech or the controller/touchpad.

# Information on the language setting

You can change the language of the Voice Control System via the system language settings. If the set system language is not supported by the Voice Control System, English will be selected.

The Voice Control System is available in English, French, Portuguese and Spanish.

# Using the Voice Control System effectively Features of audible help functions

You receive information and help for the following topics:

- Optimum operation: say the brief instruction voice command.
- Current application: on the multifunction steering wheel, press the tocker switch up and say the Help voice command.
- Continued dialog: say the Help voice command during a voice dialog.
- Specific function: say voice commands for the desired function, e.g. Help telephone.

# Notes on how to improve speech quality

If the Voice Control System does not understand you:

• only operate the Voice Control System from the driver's seat.



- say the voice commands coherently and clearly, but do not exaggerate the words.
- avoid loud noises that cause interference while making a voice command entry, e.g. the blower.

A voice tag in the address book is not recognized:

- only create sensible address book entries in the system/mobile phone, e.g. enter surname and first name in the correct field.
- do not use any abbreviations, unnecessary spaces or special characters.

If a station list entry is not recognized:

say the Read out station list voice command.

# Essential voice commands

#### Overview of switch voice commands

Switch voice commands can be used to open certain applications. The voice command selection can be used regardless of the application that is currently active.

### Switch voice commands

Voice command	Function
Navigation	To switch to navigation mode
Мар	To switch to map display
Address book	To switch to address book
Telephone	To switch to telephone mode
Text message	To switch to text messages
Radio	To switch to radio mode
Media	To switch to media mode
USB	To switch to USB
Memory card	To switch to memory card
Internet application <name></name>	To start a Mercedes-Benz online application. The application must be called up by touch once prior to use.
Mercedes-Benz Apps	To switch to Mercedes-Benz Apps
Connect	To switch to Internet mode

DEALER ePROCESS

# 226 Voice Control System

Voice command	Function
Vehicle menu	To switch to vehicle settings
System settings menu	To switch to system settings

# Overview of navigation voice commands

Using navigation voice commands, you can enter POIs or conventional addresses as well as directly change important navigation settings.

### Navigation voice commands

Voice command	Function
Navigate to <address contact="" poi=""></address>	Universal search for all types of destinations. A search is conducted in the address book contacts, the navigation database and on the Internet (POIs). The order of the details, e.g. city, street or house number, can be changed.
Address in <country></country>	Destination entry in a desired country, e.g. address in France
Home	Starts navigation to home address
Work	Starts navigation to your workspace

DEALER ePROCESS

Voice command	Function
POI <poi></poi>	Destination entry for a POI, e.g. the POI Brandenburg Gate. A search is performed in the navigation database and on the Internet.
POI online search <poi></poi>	Conducts a POI search on the Internet only
Navigate to contact <name></name>	Destination entry to a contact in the address book
Enter country Enter city Enter district Enter street Enter intersection Enter house number Enter ZIP code	Enters a country/city/district/street/intersection/house number/ZIP code
Nearest restaurant Nearest parking lot Nearest rest area with restrooms Nearest gas station	Searches for nearby restaurants, parking spaces, rest areas with restrooms and gas stations



Voice command	Function
Restaurant along the route Parking along the route Rest area with restrooms along the route Gas stations along the route	Searches for restaurants, parking spaces, rest areas with restrooms and gas stations along the route
Restaurant at destination Parking at destination Rest area with restrooms at destination Gas station at destination	Searches for restaurants, parking spaces, rest areas with restrooms and gas stations at the destination
Last destinations	Selects a destination from the list of last entered destinations
Alternative routes	Switches route guidance to another route
Start route guidance	Starts route guidance after entering a valid destination
Cancel route guidance	Cancels route guidance
Guidance instructions on Guidance instructions off	Switches the route guidance voice output on/off



Voice command	Function
Show traffic map Hide traffic map	Switches the traffic map on/off
Switch on POI symbols Switch off POI symbols	Switches the POI symbols display on the map on/off

## Overview of telephone voice commands

You can use the telephone voice commands to make phone calls or search through the address book.

# Telephone voice commands

Voice command	Function
Call <name></name>	Makes a phone call. All address book names are available.
Search for contact <name></name>	Searches for and displays a contact. All address book names are available.
Outgoing calls	Displays the last call
Redial	Selects the last phone number dialed

#### Overview of radio voice commands

Radio voice commands can also be used when the radio application is running in the background.

#### Radio voice commands

Voice command	Function
Station <name></name>	To call up receivable or saved stations
<frequency></frequency>	To enter a frequency directly
Next station	To switch to the next available station
Previous station	To switch to the previous station
Save station	To save a station in the station list
Show station list	To display the names of all receivable stations
Read out station list	To listen to the names of all receivable stations



Voice command	Function
Traffic information on Traffic information off	To switch the traffic information service on/off
Radio info on Radio info off	To switch the current station information on/off

# Overview of media player voice commands

Media player voice commands can also be used when the media player is running in the background.



# Media player voice commands

Voice command	Function
Play <tracks> Play <albums> Play <artists> Play<composers> Play <genres> Play <play < td=""><td>The names of all available tracks, albums, artists, composers, genres or playlists are accepted during the search.</td></play <></genres></composers></artists></albums></tracks>	The names of all available tracks, albums, artists, composers, genres or playlists are accepted during the search.
Media search <track/> Media search <albums> Media search <artists> Media search <composers> Media search <genres> Media search <playlists></playlists></genres></composers></artists></albums>	The names of all available tracks, albums, artists, composers, genres or playlists are accepted during the search.



Voice command	Function
Show all albums Show all artists Show all composers Show all genres Show all tracks Show all playlists	Available albums, artists, composers, genres, tracks or playlists are searched for.
Next track	To select the next track
Previous track	To select the previous track
Random track list on Random track list off	To switch the random track list on/off

# Overview of message voice commands

Text messages can be created, edited and listened to using the message voice commands.



# Message voice commands

Voice command	Function
Text message to <name></name>	To create a message. All address book names are available.
Reply	To reply to a message
Forward text message	To forward a message

#### Overview of vehicle voice commands

You can use the vehicle voice commands to directly call up the corresponding menus for the vehicle settings.

#### Vehicle voice commands

Voice command	Function
Ambient light menu	To display ambient light settings
Ambient light "blue"	To switch ambient light to blue
Display and styles menu	To show display settings
Assistance menu	To display assistance settings

DEALER ePROCESS



To set the seat heating for the front passenger seat to level 2

Seat heating front passenger level "2"

# 236 Voice Control System

Voice command	Function
Consumption menu	To display consumption
Vehicle data	To display vehicle data



#### Overview and operation


#### Overview of the multimedia system

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.



- Touch Control Multimedia system button group on the steering wheel ( page 211)
- Multimedia system display
- Main function button group → page 241)
- (b) button

Switches multimedia system on/off

DEALER EPROCESS

For Mercedes-AMG vehicles

button Active Parking Assist

- Control knob Adjusts the volume ( $\longrightarrow$  page 244) Switches the mute function on /off  $(\longrightarrow)$  page 243) For Mercedes-AMG vehicles Turn: adjusts the volume Press: switches the multimedia system on/off
- Touchpad
- Controller

### Notes on the media display

**NOTE** Scratches on the display

The display has a highly sensitive, high-gloss surface. There is a risk of it becoming scratched.


- Avoid touching the display.
- Observe the notes on cleaning.

Observe the notes on caring for the interior ( page 350).

Automatic temperature-controlled switchoff feature: if the temperature is too high, the brightness is initially reduced automatically. The display may then switch off completely for a while.

(i) If you are wearing polarized sunglasses, it may be difficult to read the display.


#### Central control elements overview



- Touch Control
- 2 Controller
- Touchpad

#### **Touch Control**

#### **Operating Touch Control**



To call up main functions: press button ①.

or

- Press and hold button 3.
- ► To call up favorites: press button ①.
- Swipe down on Touch Control 2.



- To open a list: press Touch Control 2.
- To close a list: press button 3.

or

- Swipe right on Touch Control 2.
- To select a menu item: swipe up, down, left or right on Touch Control 2.
- Press Touch Control 2.
- To move the digital map: swipe in any direction.

### Setting the sensitivity for the Touch Control Multimedia system:

- ¬→ System → Input
- >> Touch Control Sensitivity
- Select Fast, Medium or Slow.

#### Operating the controller



- button Press briefly: returns to the previous display Press and hold: calls up main functions
- Controller



Calls up the main functions

To call up favorites: when the main functions are displayed, slide controller **2** down.

Controller 2 operating options:

- Turn ((()) counter-clockwise or clockwise.
- Slide ← (○) → left or right.
- Slide **†**⊙**↓** up or down.
- Slide \( \) diagonally.
- Press (5) briefly or press and hold.

#### **Touchpad**


### Activating/deactivating the touchpad Multimedia system:

- ¬→ System → ¬¬ Input
- Activate **✓** or deactivate □ the Touchpad.

### Operating the touchpad

#### Requirements:

• The touchpad is switched on  $(\longrightarrow)$  page 239).



- button
   Press briefly: returns to the previous display
   Press and hold: calls up main functions
- Touchpad

button
 Calls up the control menu of the last active audio source

You can navigate in menus and lists via the touch-sensitive surface of touchpad ② by using a single-finger swipe.

- ► To open or close lists: swipe left or right.
- ► To select the menu item: swipe up, down, left or right.
- Press touchpad ②.
- To move the digital map: swipe in any direction.

Use the following functions with a two-finger swipe:

- To call up main functions and favorites: swipe down with two fingers. The swipe must start in the upper area of the touchpad.
- To zoom in and out of the map: move two fingers together or apart.
- To call up the control menu of the last active audio source: swipe up with two fin-

gers. The swipe must start in the lower area of the touchpad.

Setting the sensitivity for the touchpad Multimedia system:

- ¬→ System → 🤚 Input
- Select Touchpad Sensitivity.
- Select Fast, Medium or Slow.
- ➤ To set the pressure sensitivity: switch Touchpad Tap on ☑ or off ☐. If the function is switched on ☑, a tap on the touchpad is enough to select a menu item.

Handwriting recognition: switching the readaloud function on/off

Multimedia system:

- → System → Audio
- >> System Feedback
- Switch Read Out Handwriting Recognition on ✓ or off □.



# Activating/deactivating haptic operating feedback on the touchpad

Multimedia system: ¬→ System → ¬ Input

The function supports you when making entries on the touchpad and when selecting menus.

Switch Haptic Operating Feedback on **✓** or off  $\square$ .

When the function is activated, a tactile feedback in the form of a vibration is effected when the touchpad is operated.

#### Selecting a station and track using the touchpad


Press the button on the touchpad.

- Swipe up with two fingers. The swipe must start in the lower area of the touchpad. The control menu appears for the audio source that was last selected.
- Use one finger to swipe up or down. Radio: the previous or the next station is set. Media source: the previous or the next music track is selected.

To hide the control menu: swipe down with two fingers. The swipe must start in the upper area of the touchpad.

#### Main functions

### Calling up the main functions



- NAVI button Calls up navigation
- RADIO button Calls up the radio
- MEDIA button Calls up media DEALER EPROCESS

- TFI button Calls up the telephone
- **⇔** button Sets vehicle functions
- Alternatively: press the button on the central control element. The main functions are displayed.
- Select a main function.

#### **Favorites**

#### Overview of favorites

Favorites offer you guick access to frequently used applications. It is possible to create 20 favorites in total.

The following functions are available:

- add pre-defined favorites from the following categories ( $\longrightarrow$  page 242):
  - **Navigation**
  - Entertainment
  - Phone
  - Connect

#### 242 Multimedia system

- Vehicle
- System Settings
- add your own favorites (——— page 242)
- rename favorites (——> page 242).
- move favorites ( page 242).
- delete favorites (——— page 243).
- reset all favorites (→ page 243)

#### Calling up favorites

- Press the button.
  The main functions are displayed.
- Navigate downwards once. Navigating means:
  - Swiping on the Touch Control or the touchpad
  - Sliding the controller

#### Leaving the favorites menu

▶ Press the button.

#### **Adding favorites**

#### Adding predefined favorites

- Press the button.
  The main functions are displayed.
- Navigate downwards twice.
   The Favorites menu appears.
- Select New Favorite. The categories are displayed.
- Select a category.The favorites are displayed.
- Select a favorite.
- Store the favorite at the desired position. If a favorite has already been added at this position, it will be overwritten.

#### Example: adding your own favorites

- Select Vehicle.
- Select Full Screen: Consumption.
- Press and hold the button until the favorites are displayed.
- Store the favorite at the desired position.

If No function available for saving, is shown, the selected function cannot be added.

#### Renaming favorites

- Press the 🛕 button.
  The main functions are displayed.
- Navigate downwards once.
- Select a favorite.
- Navigate downwards once.
   The Favorites menu appears.
- Select Rename.
- Enter the characters.
- To confirm the entry: select ok.

#### Moving favorites

- Press the button.
  The main functions are displayed.
- Navigate downwards once.
- Select a favorite.
- Navigate downwards once.
   The Favorites menu appears.
- Select Move.




Move the favorite to the desired position. If a favorite has already been added at this position, it will be overwritten.

#### **Deleting favorites**


- Press the n button. The main functions are displayed.
- Navigate downwards once.
- Select a favorite.
- Navigate downwards once. The Favorites menu appears.
- To delete: select Delete.
- Select Yes.
- To restore all favorites: select Reset All. A prompt appears.
- Select Yes. The favorites are reset to the factory settings.

#### Switching the sound on/off



On the multifunction steering wheel






On the multimedia system

**To mute:** press volume control **1**. The symbol appears in the status line of the media display.


You will also hear traffic announcements and navigation announcements even when the sound is muted.

To switch on: change the media source or turn volume control (1).

#### Adjusting the volume



On the multifunction steering wheel



On the multimedia system

Turn volume control . The volume of the current radio or media source is set. The volume of other audio sources can be adjusted separately.

Adjust this in the following situations:

- during a traffic announcement
- during a navigation announcement

DEALER EPROCESS

The volume of the navigation announcement changes in accordance with the volume of the current media source.

- during a telephone call
- when entering or exiting a parking space while using Active Parking Assist

or

- Select System in the multimedia system.
- Select Audio.
- Select a volume setting.
- Set the volume.

#### **Entering characters**

# Using the character input function

▲ WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Use the character input function in the following situations, for example:

- Renaming a favorite
- Entering a POI or address
- Making a phone call

The following functions are available:

- Selecting a character in the character bar
- Writing a character on the touchpad

Character input can be started with a control element and resumed with another.

- On the Touch Control and controller: select the characters in the character bar. Depending on the target entry, the following characters are available:
  - The full set of characters is shown
  - Only those characters which are useful for the current input string are shown Other characters are grayed out.
- On the touchpad: select the characters in the character bar.

Write the characters on the touch-sensitive surface of the touchpad. Handwriting recognition supports you by means of character suggestions and a readaloud function.

#### Examples of character entry:

- Renaming a favorite
- Entering a POI or an address using free or step-by-step search
- Entering a web address DEALER EPROCESS

# Entering characters using the controller **Example: renaming favorites**



- Call up the "Renaming favorites" function  $(\longrightarrow)$  page 242).
- To enter a character: turn ((()), slide t(()) and press the controller.

The character is entered in the input line.

Use the following entry functions:

To delete a character: press the control-

To delete an entry: press and hold the controller until the entire entry is deleted.

# 246 Multimedia system

- To switch to special characters and symbols.
- ☐ To switch to upper-case or lower-case letters.
- To switch the language.
- To switch to character entry on the touchpad.
- The available editing functions depend on the editing task, the language set and the character level.
- To confirm the entry: select ok.

# Example: entering a destination (navigation)

► Enter the POI or address (→ page 260).

#### Entering characters on the touchpad

#### Requirements:

- The touchpad is switched on (→ page 239).
- The entered or selected character should be read out: the handwriting recognition readaloud function is switched on ( page 240).

### **Example: renaming favorites**



- To enter a character: use your finger to write characters on the touchpad. The character is entered in the input line. If different interpretations are possible, character suggestions are displayed.
- To select a character suggestion: swipe up or down on the touchpad.
- Resume character input.
- To enter a space: swipe right when the cursor is located in the input line.

DEALER ePROCESS

- To delete a character: swipe left when the cursor is located in the input line.
- ► To confirm the entry: press the touchpad.
- To finish character entry: swipe upwards.

or

➤ Press the 🛨 button.

### Example: entering a destination (navigation)

► Enter the POI or address (———— page 260).

# System settings

# **Display**

# Configuring display settings

Multimedia system:

→ System → Display and Designs

#### Styles

- Select Designs.
- ► Select Sport, Classic or Progressive.

### Adapting the ambient lighting for the style

Select Adjust Amb. Lighting. Activate or deactivate the function. This function adjusts the ambient lighting for the selected display style.

#### Setting the display brightness

- Select Display Brightness.
- Select a brightness value.

#### Switching the display off/on

- Off: select Display Off.
- **On:** press a button, TEL, for example.

#### Display design

- Select Day/Night Design.
- Select Automatic, Day Design or Night Design.

#### Additional display area

Depending on the vehicle, various items of additional information can be shown. The additional display area comprises the left-hand or righthand third of the display.

Select Additional Disp. Area.

The following display content can be selected:

Dynamic

- Navigation Map
- Consumption
- Time and Date

#### Time and date

#### Setting the time and date automatically Multimedia system:

- → System → Time and Date
- Deactivate ☐ Manual Time Adjustment. The time and date are set automatically for the selected time zone and summer time option.
- The correct time is required for the following functions:
  - Route guidance with time-dependent traffic guidance.
  - Calculation of expected time of arrival.



#### Setting the time zone

Multimedia system:

→ System → Time and Date

>> Time 7one:

The list of countries is displayed.

- Select a country •. Depending on the country, time zones are displayed.
- Select a time zone The time zone set is displayed after Time Zone:

#### Setting summer time

The Automatic Daylight Saving Time and Daylight Saving Time options cannot be selected in all countries.

Multimedia system:

¬→ System → Time and Date

# Automatically

Switch Automatic Daylight Saving Time on  $\overline{\checkmark}$  or off  $\square$ .

#### Manually

- ▶ Deactivate ☐ Automatic Daylight Saving Time.
- Select Daylight Saving Time.
- Select On or Off.

# Setting the time and date format Multimedia system:

- → System → Time and Date
- >> Set Format
- Set the date and time format •.

#### Setting the time manually

#### Requirements:

 The Manual Time Adjustment function is switched on.

#### Multimedia system:

- → System → Time and Date
- >> Set Time
- Set the hours.
- Navigate to the right to set the minutes.
- Set the minutes.

- Confirm changes when exiting the menu.
- The date is set automatically via GPS.

# Connectivity

# Switching transmission of the vehicle position on/off

Multimedia system:

- ¬→ System → ☐ Connectivity
- Select Transmit Vehicle Pos..
- ➤ Activate ✓ or deactivate ☐ the function.

#### Bluetooth®

#### Information about Bluetooth®

Bluetooth® technology is a standard for short-range wireless data transfer up to approximately 32.8 ft (10 m).

You can use Bluetooth® to connect your mobile phone to the multimedia system and use the following functions, for example:

hands-free system with access to the following options:

DEALER ePROCESS

- contacts ( page 292)
- call lists (→ page 295)
- text messages
- Internet connection
- listening to music via Bluetooth® audio (———) page 322)
- transferring business cards (vCards) into the vehicle

Bluetooth® is a registered trademark of Bluetooth Special Interest Group (SIG) Inc.

(i) Internet connection via Bluetooth® is not available in all countries.

# Activating/deactivating Bluetooth®

# Requirements for switching off Bluetooth®:

Apple CarPlay™ is not active.

Multimedia system:

- ¬→ System → ♠ Connectivity
- ▶ Activate or deactivate Bluetooth®.

If Android Auto is active, a prompt appears asking whether Bluetooth® should be deactivated.

Select Yes. Android Auto is closed and Bluetooth® is deactivated.

#### Wi-Fi

#### Wi-Fi connection overview

You can use Wi-Fi to establish a connection with a Wi-Fi network and to access the Internet or other network devices.

The following connection options are available:

- Wi-Fi connection The Wi-Fi connection to a Wi-Fi-capable device, e.g. the customer's mobile phone or a tablet PC is established.
- Multimedia system as a Wi-Fi hotspot Using this function, a tablet PC or notebook can be connected, for example.

To establish a connection, you can use the following methods:

WPS PIN

The connection to a secure Wi-Fi network is made via a PIN.

WPS PBC

The connection to a secure Wi-Fi network is made by pressing a button (push button).

Security key

The connection to a secure Wi-Fi network is made via a security key.

#### Setting up Wi-Fi

#### Requirements:

• The device to be connected supports one of the three means of connection described  $(\longrightarrow)$  page 249).

Multimedia system:

→ System >> 🛜 Connectivity

### Activating/deactivating Wi-Fi

If Wi-Fi is deactivated □, communication via Wi-Fi to all devices is interrupted. This also means that a connection to the HERMES communication module cannot be estab-

DEALER EPROCESS

lished. Then functions such as dynamic route guidance with Live Traffic Information are not available.

#### Connecting the multimedia system with a device via Wi-Fi

This function is available if a HERMES communication module is not installed.

The type of connection established must be selected on the multimedia system and on the device to be connected.

- The connection procedure may differ depending on the device. Follow the instructions that are shown in the display. Further information (see the manufacturer's operating instructions).
- Select Internet Settings.
- Select Search for Wi-Fi Networks.

#### Using a security key

- Select a Wi-Fi network in the list.
- Have the security key displayed on the device to be connected (see the manufacturer's operating instructions).

- Enter this security key on the multimedia system.
- Confirm the entry with **ok**.
- (i) All devices support a security key as a means of connection.

#### Using a WPS PIN

- Highlight a Wi-Fi network in the list.
- Select Connect via WPS PIN Input. The multimedia system generates an eightdigit PIN.
- Enter this PIN on the device to be connected.
- Confirm the entry.

#### Using a button

- i This function is only available in a Wi-Fi frequency of 2.4 GHz.
- Highlight a Wi-Fi network in the list.
- ► Select Connect via WPS PBC.
- Select "Connect via WPS PBC" in the options on the device to be connected.
- Press the WPS button on the device to be connected.

Select Continue in the multimedia system.

#### Device has already been connected:

- To automatically connect: highlight a Wi-Fi network in the list.
- ► Activate Connect Automatically .
- To connect: highlight a Wi-Fi network in the list.
- Select Connect. The connection is established again. These functions are possible when the device has already been connected to the Wi-Fi network.

# Setting up a Wi-Fi hotspot

Multimedia system:

¬→ System → Connectivity

# Configuring the multimedia system as a Wi-Fi hotspot

The type of connection established depends on the device to be connected. The function must be supported by the multimedia system and by the device to be connected. The type of connection established must be selected on the multimedia system and on the device to be connected.

- Select Set Up Hotspot.
- Highlight Connect Device to Vehicle Hotspot.

#### Generating a WPS PIN

- Select Connect via WPS PIN Generation.
- Enter the PIN shown in the media display on the device to be connected and confirm.

#### Connecting using a WPS PIN

- ► Select Connect via WPS PIN Input.
- Select Enter WPS PIN.
- Enter the PIN that is shown on the external device's display on the multimedia system.
- Select Continue.

#### Connecting using a button

Requirements

- This function is only available in a Wi-Fi frequency of 2.4 GHz.
- Select Connect via WPS PBC.



- Press the WPS button on the device to be connected or select Connect
- Select Continue in the multimedia system.

### Connecting using a security key

- Select Connect Device to Vehicle Hotspot. A security key is displayed.
- Select the vehicle from the device to be connected. The vehicle is displayed with the SSID MB Hotspot XXXXX.
- Enter the security key which is shown in the media display on the device to be connected.
- Confirm the entry.

### Connecting using NFC

- Select Connection via NFC.
- Activate NFC on the mobile device (see the manufacturer's operating instructions).
- Bring the mobile device into the NFC area of the vehicle ( page 290).
- Select Done. The mobile device is now connected to the multimedia system hotspot via NFC.

### Generating a new security key:

- Select Set Up Hotspot.
- Select Generate Security Key. A connection will be established with the newly created security key.
- To save a security key: select Save. When a new security key is saved, all existing Wi-Fi connections are then disconnected. If the Wi-Fi connections are being re-established, the new security key must be entered.

### **Managing COMAND Touch devices**

### Requirements:

- The COMAND Touch app is installed on the external device (e.g. tablet or smartphone).
- Wi-Fi is activated ( page 249) and the multimedia system is configured as a Wi-Fi hotspot ( $\longrightarrow$  page 250).



### Multimedia system:

¬→ System → COMAND Touch

### Connecting and authorizing a new device

- Select Authorize a New Device.
- Select Connect New Device.
- Enter the security key in the external device. The Please start COMAND Touch on your device and follow the instructions. message appears.
- Select Continue.
- Accept the connection request from the new device.
- Enter the PIN shown on the external device. The device is authorized.

### Authorizing a connected device

- Select Authorize a New Device. The devices already connected are displayed.
- Select Continue Using Connected Devices. The Please start COMAND Touch on your device and follow the instructions. message appears.

- Select Continue.
- The connection request from the device Accept.
- Enter the PIN shown on the external device. The device is authorized.

### De-authorizing the device

- Select an authorized device from the list. A prompt will appear asking whether you would like to de-authorize the selected device.
- Select Yes. The device is de-authorized.

# Activating/deactivating child safety lock

Multimedia system:

→ System → Parental Control

### Locking an external device

- Select an external device.
- Select Lock.
  The device connected via the COMAND
  Touch app is locked ✓ or unlocked □.

### System language

### Notes on the system language

This function allows you to determine the language for the menu displays and the navigation announcements. The selected language affects the characters available for entry. The navigation announcements are not available in all languages. If a language is not available, the navigation announcements will be in English.

# Setting the system language

Multimedia system:

¬→ System → Language

- Set the language.
- i If you are using Arabic map data, the text information can also be shown in Arabic on the navigation map. To do so, select العربية as the language from the language list. Navigation announcements are then also made in Arabic.



### Setting the distance unit

Multimedia system:

¬→ System → Imm Units

- Select km or mi.
- In the multifunction display of the Instrument Display, switch the Additional Speedometer display on <a>✓</a>.

# Data import and export

### Data import/export function

The following functions are possible:

- Transferring data from one system or vehicle to another system or vehicle.
- Creating a backup copy of your personal data and loading it again.
- Protecting your personal data against unwanted export with PIN protection.
- Please note that the NTFS file system is not supported. The FAT32 file system is recommended.

- ! NOTE Loss of data due to premature removal
- Do not remove the data storage medium when data is being exported.

Mercedes-Benz is not liable for any loss of data.

### Requirements:

- The vehicle is stationary.
- The ignition is switched on or the vehicle has been started.
- The SD card is inserted ( >> page 314) or the USB device is connected ( >> page 316).

Multimedia system:

- → System → System Backup
- Select Import Data or Export Data.

### **Importing**

- Select a data storage medium.
   A prompt appears asking whether you really wish to overwrite the current data. If data
  - wish to overwrite the current data. If data originates from another vehicle, this is recognized during data reading.

The multimedia system is restarted once the data has been imported.

(i) Current vehicle settings can be edited after the import.

# **Exporting**

If PIN protection is activated, your PIN is requested.

- Enter the four-digit PIN.
- Select a data storage medium. The data is exported. The data export may take several minutes.

### **Activating/deactivating PIN protection**

Multimedia system:

¬→ System → PIN Protection

### Setting the PIN

- Select Set PIN.
- Enter a four-digit PIN.
- Enter the four-digit PIN again.
  If both PINs match, PIN protection is active.

# Changing the PIN

Requirements

- · A current PIN must be set.
- Select Change Settings.
- Enter the current PIN.
- Select Change PIN.
- Set a new PIN.

### Activating PIN protection for data export

Select Change Settings. Confirm with the PIN.



### 254 Multimedia system

### Unblocking the PIN

### Requirements:

- There is an Internet connection.
- A Mercedes me account exists at http:// www.mercedes.me.
- The Personalization service is active (→ page 254).

If the PIN has been entered incorrectly three times, the PIN will be blocked. You can have a single-use password sent to you via the Mercedes me connect online portal to reset the PIN protection.

- Select Unblock PIN.
- Enter the single-use password. PIN protection is reset, and you can set a new PIN.
- Alternatively, you can have PIN protection reset at an authorized Mercedes-Benz Center.

### User profile

# Setting a user profile

Multimedia system:

¬→ System → Personalization

### Displaying a user profile when starting

If this function is active, a prompt appears when starting the system asking which user profile to use.

- Select Display Profile Selection after Start.
- ► Activate ✓ or deactivate ☐ the function.

### Selecting a user profile

- ▶ Select Guest Profile or individual profile •.
- (i) Some settings from the user profile are only loaded when the vehicle is stationary or when the ignition is switched on.

### **Automatic synchronization**

Each time the ignition is switched off or on, the individual user profiles are synchronized on the multimedia system and on the server. This ensures that the latest user profiles are always available.

DEALER ePROCESS

- ► Select Automatic Synchronization.
- ➤ Activate ✓ or deactivate ☐ the function.
- For more information about importing/ exporting user profiles ( page 254).

# Creating a user profile

Multimedia system:

→ System → Personalization

- >> Create Profile
- Enter a name.
- Select OK.

The following information is saved in the user profile, for example:

- System settings
- Settings in the TV tuner's channel list
- Navigation and traffic information

The settings differ depending on the vehicle equipment.

### Importing/exporting user profiles

### Requirements:

· There is an Internet connection .

- A Mercedes me account exists at http:// www mercedes me
- The Personalization service is active.

### Multimedia system:

→ System → Personalization ➤ Manual Export/Import

This function is not available in all countries.

Only individual profiles can be imported or exported.

The individual profiles are always collectively imported or exported.

- **Import:** select Import Profiles from Server. The The profile data import overwrites all existing profile data. Do you want to continue? message appears.
- Select Yes. User profiles are imported.
- **Export:** select Export Profiles to the Server. User profiles are exported.
- Certain settings, such as address book entries or previous destinations from the navigation system, are not exported.

# Setting user profile options

Multimedia system:

→ System → Personalization

- Highlight a profile.
- Select options.

The following options are available:

- Rename
- Delete
- Reset
- The guest profile cannot be deleted or renamed.

### Software update

### Information on software updates

The multimedia system provides a message when an update is available.

Depending on the source, you can perform various updates:



### Software update

Source of the update	Update type
Updates via mobile phone	Navigation map, system updates, Digital Operator's Manual
Updates via an exter- nal storage medium, e.g. a USB flash drive	Navigation maps

(i) Updates via mobile phone require an active Internet connection for the vehicle. This is not available in all countries. For further information on connecting to the Internet, see ( $\longrightarrow$  page 307).

### Advantages of updating software

Thanks to the software update, your vehicle status is up-to-date.

In order to constantly improve the quality of our services you will receive future updates for your multimedia system, the Mercedes me connect services and your vehicle's communication module. These will conveniently be sent to you via

the mobile phone connection in your vehicle and, as an option, installed automatically. You can monitor the status of your updates on the Mercedes me portal and find information about potential innovations.

Your advantages at a glance:

- · conveniently receive software updates via the mobile phone network
- · improves the quality and availability of Mercedes me connect services
- keeps your multimedia system and communication module up-to-date

Further information about software updates can be found at http://me.mercedes-benz.com

### Performing a software update

### Requirements:

- There is an Internet connection.  $(\longrightarrow)$  page 307).
- For automatic updates: your vehicle has a permanently installed communication module.

Multimedia system:

¬→ System → Software Update

### **Automatic update**

Switch Automatic Online Update on . Updates are performed. The current status of the updates is displayed.

### Manual update

- Deactivate ☐ Automatic Online Update.
- Select an update from the list and start the update.

### Activating the software update

Restart the system.

### Function of important system updates

Important system updates may be necessary for the security of your multimedia system's data. Please install these updates, or else the security of your multimedia system cannot be ensured.

(i) If automatic software updates are activated, the system updates will be downloaded automatically ( $\longrightarrow$  page 256).

later time ( $\longrightarrow$  page 256).

If the download is completed and the update is ready for installation, you will be informed of this after the next ignition cycle, for example.

(i) Park the vehicle safely in a suitable location before starting the installation.

Requirements for the installation:

- · The ignition is switched on.
- The engine is not running.

The update will be downloaded in the background.

Details

Download

display.

Information about the pending system update is displayed.

You have the following selection options:

As soon as an update is available for download,

a corresponding message appears on the media

Later

The update can be downloaded manually at a

DEALER ePROCESS

· The parking brake is applied.

If all requirements are met, the update will be installed. The multimedia system cannot be operated while the update is being installed and vehicle functions are restricted.

If errors should occur during the installation, the multimedia system automatically attempts to restore the previous version. If restoration of the previous version is not possible, a symbol appears on the center console display. Please consult a qualified specialist workshop to resolve the problem.

### Reset function

Multimedia system:

¬→ System → Reset

Personal data is deleted, for example:

- Station presets
- · Connected mobile phones
- Select Yes.

If PIN protection is activated, a prompt appears asking if you also wish to restore this to the factory settings during a reset.

Select Yes.

Enter the current PIN.
The PIN is reset.

or

Select No.
 The current PIN stays the same after resetting.

i If you have forgotten your PIN, an authorized Mercedes-Benz Center can deactivate the PIN protection for you.

A prompt appears again asking whether you really wish to reset.

Select Yes.

The multimedia system is reset to the factory settings.

### Fit & Healthy

**ENERGIZING** comfort



# **ENERGIZING comfort program overview Program overview**

Program	Function
Refresh	Can make targeted changes to the interior climate to refresh vehicle occupants. Cooling airflow and ionization purify the air. The vehicle interior is illuminated with cool colors and the seats are ventilated.
Warmth	Can increase the comfort level of the occupants. The vehicle's panel, seat and steering wheel heater produce a cozy warmth. The air is purified using ionization and a pleasant fragrance is released. The vehicle interior is illuminated with warm lighting.
Vitality	Can counteract fatigue in monotonous driving situations. Fast-paced music and a vitalizing massage provide invigorating stimulation for the vehicle occupants. The air is purified using ionization and a pleasant fragrance is released. The vehicle interior is illuminated in a stimulating hue and the seat is ventilated.
Pleasure	Can promote a positive mood in the occupants. Moderately fast music is played and a massage program is activated. The air is purified using ionization and a pleasant fragrance is released. The vehicle interior is illuminated with amicable lighting.
Well being	Can aid the physical and mental relaxation of occupants. A back massage combined with local warmth provide relaxation. The air is purified using ionization and a pleasant fragrance is released. The music player plays selections of calming music and the vehicle interior is illuminated with pleasant lighting.
Training	Can counteract the onset of muscle tension, limbs falling asleep or stress with targeted relaxation or stimulation exercises. The exercises are demonstrated in short videos. The air is purified using ionization and a pleasant fragrance is released. The vehicle interior is illuminated with lighting appropriate to the exercise.

Please note that the available programs and the associated functions are dependent on your vehicle equipment. Depending on your equipment, fewer functions may be available.

# Starting the ENERGIZING comfort program

### Requirements:

- The ignition is switched on.
- ENERGIZING comfort is available approximately five minutes after starting the multimedia system.

Multimedia system:

→ Vehicle → FNFRGIZING Comfort

### Selecting a seat

- Select Seat Selection.
- Select the desired seat or All Seats .

### Starting a program

Select Refresh, Warmth, Vitality, Enjoyment or Well-being.

The selected program will run for ten minutes.

### Configuring a program

- Call up further options for the desired program.
- Switch the functions included in the program on  $\mathbf{\nabla}$  or off  $\square$ .

### Starting training

- Select Training.
- Select Muscle Relaxation, Muscle Stimulation or Balance.

The selected training video starts and is displayed in the media display.

- Select Full Screen: Video. The training video is displayed in full screen.
- For more information on pausing or skipping through videos, see ( $\longrightarrow$  page 316).

If, during an active program, a function requirement is no longer met, a corresponding message appears. The active program is canceled.




### Navigation

### Switching navigation on

Multimedia system:

**¬→** Navigation



Alternatively: press the NAVI button. The map appears and shows current vehicle position (1).

i) If a climate control setting is changed, a climate bar appears briefly.

# Showing/hiding the navigation menu

### Requirements:

The map displays the current vehicle position.

### Multimedia system:

**¬→** Navigation



To show: swipe left on the touchpad or the Touch Control.

or

- Slide the controller to the left.
- To hide: swipe right on the touchpad or the Touch Control.



or

- Slide the controller to the right.
- To show or hide lower menu levels, swipe or slide to the left or right as many times as necessary.

# **Destination entry**

### Entering a POI or address

A

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road

and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.


### Requirements:

- For the online search: Mercedes me connect is available.
- You have a user account for the Mercedes me portal.
- The service is available.
- The service has been activated at an authorized Mercedes-Benz Center.

Further information can be found at: http:// www.mercedes.me

Multimedia system:

- ¬→ Navigation
- Show the navigation menu.
- Select Enter Destination .



The state or province in which the vehicle is located is set 1.

There are two available methods of destination entry:

- Free search ②
- Search step-by-step (3)

### Method 1: free search

Enter the POI or address in ②. The entries can be made in any order. During destination entry, suggestions are made by the multimedia system. A selection of destinations appears in a list.



Enter these address elements, for example:

- City, street, house number
- Street, city
- ZIP code
- POI name
  - POI category, e.g. Gas Station
- City, POI name
- To switch to handwriting recognition: select | 15 | 65.
- Write the character on the touchpad.
- To switch to character selection: press the **≐** button.

- Press the touchpad.
- To delete an entry: select \( \omega \) (if available).

Use the following options:

- Press briefly: deletes the last character entered or the last suggestion adopted.
- Press and hold: deletes the entire entry.
- To set the language: select (18)

### 262 Multimedia system

- Select the language.
- (i) This function is useful for countries in which several character sets are supported. An example is Russia, which uses Cyrillic and Latin characters.
- > To call up the online search function:
  select Online Search .
  Once an Internet connection is established, a
  list appears. It shows online destinations
  related to the previous entry.

Online destinations are provided by the Internet service provider.

Select the online destination.

ΩI

or

- Enter the online destination or a 3 word address in the input line.
- i Enter a 3 word address (→ page 266).
   Online search is not available in all countries.
- ► To call up the list: press the 🛨 button.

If the top line of the character bar is highlighted, navigate upwards.

- Select the destination in the list.
- ► To adopt a destination: select ② Select Destination.

If there are several listings for a destination, a list appears.

Select the destination.
 The destination address is shown.

### Method 2: search step-by-step

▶ Press 🛨 button.

or

- If the top line of the character bar is highlighted, navigate upwards.
  The character bar is hidden. City or ZIP is highlighted. Additional entry fields, e.g. for POI, are available.
- Select City or ZIP.The character bar appears.
- Enter the city or the ZIP code.

  During destination entry, suggestions are made by the multimedia system. A selection of destinations appears in a list.

The address entries can be made in any order, for example:

- City or ZIP, Street, House No.
   Enter an intersecting street, if available.
- Street, City or ZIP
- · POI, e.g. Gas Station, City or ZIP
- i During destination entry, use the following functions:
  - Switching to handwriting recognition
  - Switching to character selection
  - Deleting an entry

An entry, e.g. POI, can be deleted with in a step-by-step search. Navigate to the left to do so.

- Calling up the online search function (if available)
- Calling up a list

The functions are described in the free search.

➤ To change the state/province: select the state or the province.



- Enter the state or the province. You only need to enter the first character.
- Select the state or the province in the list.
- To change the country: select the country.
- Enter the country. You only need to enter the first character.
- Select the country on the list.
- To adopt a destination: select Select Destination.

If there are several listings for a destination, a distance-orientated list appears.

Select the destination. The destination address is shown.

# Selecting previous destinations

Multimedia system:

**¬→** Navigation

▶ Previous and Other Destinations

- Select Previous Destinations.
- Select the destination. The destination address is shown.

If favourites have been saved already ( page 275), select From My Favorites.

- Select the favourite.
  - The destination address is shown.

### Selecting a POI

Multimedia system:

¬→ Navigation

- ▶ Previous and Other Destinations
- >> POIs
- Select the category.

or

Select All Categories and the category. If route guidance is not active: the search begins in the vicinity of the current vehicle position. The list is sorted by distance in ascending order.

The POIs show the following information:

- name of POI
- linear distance to the POL
- the direction of the linear distance to the POI (arrow) is displayed when searching for the vehicle's current position

DEALER EPROCESS

- Select the POI
- Route guidance is active: select the search position prior to choosing a POI (see example).
- If intermediate destinations are set, these can also be selected as the search position after selecting Near Destination.

### Filtering displays for POIs

- Enter the search term in Search:. The results list shows relevant POIs.
- Select ok. The first POI in the list is highlighted.
- Select the POL

### Example: setting the search position for the parking category during active route guidance

- Select In the Vicinity, Near Destination or Along the Route.
  - The list shows the located POIs or opens an overview of the route destination after selecting Near Destination.
- Select the POL

or

Select Near Destination: select the intermediate destination or the destination.

### Starting an automatic gas station search

### Requirements:

The automatic gas station search is activated
 ✓ (→ page 270).

### **Driving situation**

Route guidance is active. The fuel level in the fuel tank reaches the reserve fuel level.

The Reserve Fuel Do you want to start a search for surrounding gas stations? message is shown.

Select Yes.

The automatic gas station search begins. The available gas stations along the route or in the vicinity of the vehicle's current position are displayed.

- Select the gas station. The address of the gas station is displayed.
- If route guidance is not active, select Start Route Guidance.

The selected gas station is set as the destination. Route guidance begins.

or

▶ If route guidance is active, select Start New Route Guidance or Set as Next Way Point. Start New Route Guidance: the selected gas station is set as a new destination. The previous destinations and intermediate destinations are deleted. Route guidance to the gas station begins.

Set as Next Way Point: the selected gas station is set as the next intermediate destination. Route guidance begins.

If there are already four intermediate destinations: select Yes in the prompt.

The selected gas station is entered into position 1 of the intermediate destinations menu. Intermediate destination 4 is deleted. Route guidance begins.

# Entering an intermediate destination

### Requirements:

· A destination is entered.



### Multimedia system:

- → Navigation → Way Points and Info
- Select Search for Way Point.
- Select the intermediate destination.
- Select Set as Destination.

or

- Select an intermediate destination using
   Enter Destination during route guidance.
- Select Set as Next Way Point after entering the destination.

### **Editing intermediate destinations**

### Requirements:

 The destination and at least one intermediate destination have been entered.

### Multimedia system:

- → Navigation → Way Points and Info
- To call up the map: highlight the destination or the intermediate destination.

- ► Move the map (→ page 280).
- Select destination on the map (———) page 266).
- To change the order of destinations: highlight the destination or the intermediate destination.
- ➤ Select 🔀 Move .
- Move the intermediate destination to the desired position.
- Press the Touch Control, the controller or the touchpad.
- ➤ To delete a destination: highlight the destination or the intermediate destination.
- ➤ Select 🖼 Delete.

# Calculating a route with intermediate destinations

### Requirements:

• The destination and at least one intermediate destination have been entered.

### Multimedia system:

- → Navigation → Way Points and Info
- Select Start New Route Guidance. The route is calculated with the set intermediate destinations.

# Selecting a contact for destination entry

### Requirements:

- A mobile phone is connected to the multimedia system ( page 287).
- Contacts have been downloaded ( page 293).

### Multimedia system:

- **¬→** Navigation
- ▶ Previous and Other Destinations
- Contacts
- Select the contact.
  The contact details are displayed.
- Select the address.

### Filtering displays for contacts

 Enter a name or telephone number, for example, into the search field.

### DEALER ePROCESS

- Select **ok**.
  The first contact in the list is highlighted.
- Select the contact.
- Select the address.

# **Entering geo-coordinates**

Multimedia system:

- **¬→** Navigation
- ▶ Previous and Other Destinations
- >> Geo-coordinates
- Enter geo-coordinates as latitude and longitude coordinates in degrees, minutes and seconds.
  - The map shows the position.
- Confirm the entry.
- To calculate a route: select Start Route Guidance.
- If a route has already been created, select Start New Route Guidance or Set as Way Point.

# Entering the destination as a 3 word address

### Requirements:

- Searching for a destination using 3 word addresses is possible in the online search ( page 260).
- There is an Internet connection.
- (i) Searching for a destination using 3 word addresses is not possible in all countries.

### Multimedia system:

- → Navigation → Destination
- Select Online Search.
- Enter the destination address as a 3 word address. Separate each of the words with a full stop.

The search results are displayed.

- Select the destination in the list. The destination address is shown. The route can be calculated.
- (i) 3 word addresses from what3words are an alternative addressing system for multilingual georeferencing of global locations with a resolution of three meters. Using this grid,

locations on the Earth's surface are included which do not have a building address such as street and house number, for example.

The Empire State Building in New York has the following language dependent 3 word address, for example:

- English: parade.help.bleat
- French: commun.verbe.bisquer
- Spanish: suertes.diga.pesca

3 word addresses are unique, easy to remember and suffice for most routine applications.

The bidirectional conversion of 3 word addresses can be carried out here:

- at the website http://what3words.com
- in the what3words apps

# **Selecting a destination on the map** Multimedia system:



- If the map is displayed in full screen mode, press the central control element. The map menu appears.
- Select "move map" in map menu ② (———) page 279).
- Swipe in any direction on the Touch Control or touchpad.

or

- Slide the controller in any direction. The map moves in the corresponding direction under the crosshair. The more you move your finger away from the starting position on the touchpad, the faster the map moves.
- Press the Touch Control, the controller or the touchpad.

If several destinations are located around the crosshair, a list shows the available POIs and roads.

If a destination is located exactly on the crosshair, the destination address is displayed.

Select the destination in the list. The destination address is shown.

### Setting the map orientation to 2D or 3D

- Highlight Map Orientation: 2D/3D.
- Press the Touch Control, the touchpad or the controller.

The map will be displayed in the selected map orientation.

### Showing traffic messages in the vicinity of the map

- Select Traffic Messages for the Vicinity. The map appears.
- Swipe left or right on the touchpad.

or

- Slide the controller to the left or right. The previous or next traffic incident is highlighted on the map. Information on the traffic incident is displayed.
- Traffic reports are not available in all countries.

# Showing POIs in the vicinity of the map

- Select POIs in the Vicinity.
- Swipe left or right on the touchpad.

- Slide the controller to the left or right. The previous or next POI is highlighted on the map. The name or the address is shown.
- To filter the display by POI category: swipe down on the Touch Control or the touchpad.

or

- Slide the controller down.
- Select the POI category.
- User Defined allows personal POI symbols to be selected ( $\longrightarrow$  page 281).

### Route

# Calculating a route

### Requirements:

- The destination has been entered.
- The destination address is shown.
- If route guidance is not active, select Start Route Guidance.

The route to the destination is calculated. The map shows the route. Route guidance then begins.

DEALER ePROCESS

or

If route guidance is active, select Start New Route Guidance or Set as Next Way Point. Start New Route Guidance: the selected destination address is set as a new destination. The previous destinations and intermediate destinations are deleted. Route guidance to the new destination begins.

Set as Next Way Point: the selected destination address is set as the next intermediate destination. Route guidance begins.

### Taking alternative routes into consideration

Select an alternative route (→ page 269).

### Other menu functions

- To save the destination: select Store in "Previous Destinations".
- To display on the map: select Map.
- To call a telephone number: select Call (if available).
- To call up an Internet address: select www (if available).

# Selecting a route type

Multimedia system:

→ Navigation → 🗥 Route and Position

- Select Route Settings.
- Select the route type.
  If route guidance is active, the new route is calculated with the new route type.

If route guidance is not active, the next route is calculated with the new route type.

You can choose from the following route types:

### Eco Route

An economical route is calculated. The journey time may be somewhat longer than for quicker routes.

The symbol for the current vehicle position is displayed in green.

### Fast Route

A route with a quick journey time is calculated.

### · Short Route

A route with a short driving distance is calculated.

The Automatic Traffic Jam Avoidance and Ask in the Event of Traffic Jam Avoidance settings are not available in every country.

The settings enable the following:

### • Automatic Traffic Jam Avoidance

The route is calculated with the currently set route type.

Traffic reports via Live Traffic Information are taken into account.

Live Traffic Information is not available in all countries.

### · Ask in the Event of Traffic Iam Avoidance

A prompt appears when a new route is detected with a shorter journey time based on traffic reports. You can continue to use the current route or use the dynamic route instead.



### Selecting route options

Multimedia system:

¬→ Navigation → ¬¬¬ Route and Position

# Avoid OptionsAvoiding areas

Select Areas (→ page 282).

# Avoiding highways, ferries, motorail trains, tunnels, unpaved roads

### Using toll roads

- Select Use Toll Roads.
- Select Cash or Electronic Billing or Off.
   The route takes into account roads that require the payment of a usage fee (toll).

   If Off is selected, toll roads are not taken into account.

The selected route options cannot always be implemented. Therefore, a route may include a ferry, for instance, even though the avoid Ferries option is enabled. A message appears and you will hear a corresponding message.

### Using carpool lanes

- Select Number of Occupants in the Vehicle.
- Select number

When using carpool lanes, observe the applicable legal requirements as well as any conditions pertaining to when and where such lanes may be used. Carpool lanes may only be used if certain conditions are met.

These route options are not available in every country.

### Selecting notifications

Multimedia system:

ments:

- → Navigation → Options
- Announcements
- You can choose from the following announce-
- Announce Traffic Warnings This function is not available in all countries.
- Announce Street Names

The multimedia system announces the names of the roads that will follow the upcoming change of direction.

This function is not available in all countries and languages.

### Displaying destination information

### Requirements:

A destination is entered.

Multimedia system:

- ¬→ Navigation
- Select Way Points and Info.

The following information is displayed:

- Intermediate destinations and destination The route can also include up to four intermediate destinations.
- · Name, address
- Remaining driving distance
- Time of arrival



### Selecting an alternative route

Multimedia system:

- → Navigation → 🔼 Route and Position
- Select Alternative Route.

The routes are displayed in accordance with the setting made in the route settings.

The currently selected route is shown with a dark blue line.

Select the alternative route.

# Activating a commuter route

### Requirements:

 Your home and work addresses are saved as destinations in the favorites  $(\longrightarrow)$  page 275).

### Multimedia system:

- ¬→ Navigation → ¬¬¬ Route and Position
- Select Activate Commuter Route . Navigation automatically recognizes that the vehicle is located on the route between "home" and "work" or vice versa. It automatically starts a route guidance without voice output.

If the destinations for home and work have not yet been created, a prompt appears.

For the daily commuter route, traffic incidents on the route are also reported when driving without route guidance.

# Switching the automatic gas station search on/off

Multimedia system:

- → Navigation → Options
- Switch Reserve Fuel on or off . Switched on : when the fuel reserve level is reached, a prompt appears asking whether you want to start searching for gas stations.

### Using automatic gas station search

### Requirements:

The automatic gas station search is activated  $\checkmark$  ( $\rightarrow$  page 270).

The prompt Reserve Fuel Do you want to start a search for surrounding gas stations? appears.

Select Yes.

The automatic gas station search begins. The available gas stations along the route or in the vicinity are displayed.

- Select the gas station.
- When there is no route, the gas station is set as the destination.

or

When there is a route, the gas station is set as the next intermediate destination.

# Starting the automatic service station search

### Requirements:

 ATTENTION ASSIST and the Suggest Rest Area function are activated ( page 198).

### **Driving situation**

The ATTENTION ASSIST Do you want to search for a rest area? message is shown.

- Select Yes.
  - The service station search starts. The available service stations along the route or in the

vicinity of the vehicle's current position are displayed.

Select the service station.

The service station address is displayed.

If route guidance is not active, select Start Route Guidance.

The selected service station is set as a destination. Route guidance begins.

or

If route guidance is active, select Start New Route Guidance or Set as Next Way Point. Start New Route Guidance: the selected service station is set as a new destination. The previous destination and all intermediate destinations are deleted. Route guidance to the service station begins.

Set as Next Way Point: the selected service station is set as the next intermediate destination. Route guidance begins.



### Route guidance

### Notes on route guidance

WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

Route guidance begins once a route has been calculated.

The road and traffic rules and regulations always have priority over multimedia system driving instructions.

The following driving instructions can be used:

- Navigation announcements
- Route guidance displays
- Lane recommendations

If you do not follow the driving instructions or if you leave the calculated route, a new route is calculated automatically.

Driving instructions may differ from the actual road and traffic conditions if:

- The route is diverted.
- The direction of a one-way street has been changed

For this reason, you must always observe road and traffic rules and regulations during your journey as well as the prevailing traffic conditions.

The route may differ from the ideal route due to the following:

Roadworks



Incomplete digital map data

### Notes on GPS reception

The correct function of the navigation system depends amongst other things on GPS reception. In certain situations GPS reception can be impaired, defective or even not possible, e.g. in tunnels or in parking garages.

### Changing direction overview



There are three phases when changing direction:

Preparation phase

If there is enough time between the changes of direction, the multimedia system prepares you for the upcoming change of direction. A navigation announcement is issued, e.g. "Prepare to turn right".

The map appears in full-screen mode.

Announcement phase

The multimedia system announces the upcoming change of direction, e.g. by announcing "Turn right in 300 ft (100 m)".

The display is split into two parts. The map is displayed on the left; on the right, there is a detailed image of the intersection or a 3D image of the upcoming change of direction.

Change-of-direction phase

The multimedia system announces the imminent change of direction, e.g. by announcing "Now turn right".

The display is split into two parts.

The vehicle has successfully changed direction when the light-color bar on the right

drops down to 0 feet (0 m) and the current vehicle position symbol has reached the highlighted change-of-direction point.

When the change of direction is complete, the map appears in full-screen mode.

(i) Changes of direction are also shown in the Instrument Display.

### Lane recommendations overview

This display appears for multi-lane roads.

If the digital map contains the relevant data, the multimedia system can display lane recommendations for the next two changes of direction.





- Recommended lane
- Possible lane
- 3 Lanes not recommended

The following lanes are displayed:

 Recommended lane 

 In this lane, you will be able to complete both the next change of direction and the one after that.

- Possible lane ② In this lane, you will only be able to complete the next change of direction.
- Lane not recommended (3) In this lane, you will not be able to complete the next change of direction without changing lane.

During the change of direction, new lanes may be added.

Lane recommendations can also be displayed in the Instrument Display and in the Head-up Display.

### Overview of destination reached

Once the destination is reached, you will see the checkered flag. Route guidance is finished.

When an intermediate destination has been reached, you will see the intermediate destination flag with the number of your intermediate destination. After this, route guidance is continued.

# Switching navigation announcements on /off

### Requirements:

- Route guidance is active.
- To switch off: press the volume control on the multifunction steering wheel during a navigation announcement ( $\longrightarrow$  page 243).

or

Press the volume control on the center console during a navigation announcement  $(\longrightarrow)$  page 243). The Voice Guidance has been deactivated.

- Show the navigation menu ( $\longrightarrow$  page 260).
- Select **Man** Voice Guidance. The symbol changes to [].

message appears.

To activate: select Voice Guidance. The current navigation announcement is played.



- In the following situations, navigation announcements are switched on automatically:
  - A new route guidance is started.
  - . The route is recalculated.
- You can add and call up this function as a favorite under Voice Guidance On/Off.

### Switching navigation announcements on/off during a phone call

- Select System.
- Select Audio.
- Select Navigation and Traffic Announcements.
- Switch Voice Guidance During Call on **▼** or off  $\square$ .

### Adjusting the volume of navigation announcements

### Requirements:

- · Route guidance is active.
- On the multifunction steering wheel or on the multimedia system: turn the volume

control on the multifunction steering wheel during a navigation announcement.

- Turn the volume control on the center console during a navigation announcement  $\longrightarrow$  page 244).
- In the following situations, the volume is raised to the maximum volume or lowered to the minimum volume:
  - A new route guidance is started.
  - The route is recalculated.
- The minimum volume can be individually set at an authorized Mercedes-Benz Center.
- Via system settings: select System.
- Select Audio.
- Select Navigation and Traffic Announcements.
- Select Voice Guidance Volume.
- Set the volume.
- To switch audio fadeout on/off during navigation announcements: select System.
- Select Audio.

- Select Navigation and Traffic Announcements.
- Switch Audio Fadeout During Voice Guidance on  $\mathbf{\nabla}$  or off  $\square$ .

# Repeating navigation announcements

### Requirements:

- A route has already been created.
- Route guidance is active.

### Multimedia system:

**¬→** Navigation

- Select **Many** Voice Guidance.
- Select Voice Guidance. The current navigation announcement is repeated.
- You can add and call up this function as a favorite under Repeat Voice Guidance.

### Canceling route guidance

### Requirements:

- · A route has already been created.
- · Route guidance is active.

# Multimedia system:

¬→ Navigation

Select X Cancel Route Guidance.

### Overview of route guidance to an off-road destination

An off-road destination is within the digital map. The map contains no roads that lead to the destination.

You can enter geo-coordinates or a three word address for off-road destinations on the map. Route guidance guides you for as long as possible with navigation announcements and displays on roads that are known to the multimedia system.

Shortly before you reach the last known position on the map, you will hear the "Please follow the direction arrow" announcement. The display shows a direction arrow and the linear distance to the destination.



### Overview of route guidance from an off-road location to a destination

Off-road position: the current vehicle position is located within the digital map on roads that are not available.

When route guidance begins the following displays appear:

- The Road Not Mapped message is shown.
- A direction arrow showing the linear direction to the POI.

When the vehicle is back on a road known to the multimedia system, route guidance continues as normal.

### Overview of off-road status during route guidance

Due to roadworks, for example, there may be differences between the data on the digital map and the actual course of the road. In such cases, the multimedia system will temporarily be unable to locate the vehicle's current position on the digital map. The vehicle is off-road.

When the vehicle is off-road, the following displays are shown:

- the Road Not Mapped message
- a direction arrow showing the linear direction to the POI

When the vehicle is back on a road known to the multimedia system, route guidance continues as normal.

### Destination

### Saving the current vehicle position Multimedia system:

¬→ Navigation

- If the map is displayed in full screen mode, press the central control element. The map menu appears.
- Select 1 on the map menu → page 279).

The current vehicle position is saved to the "Previous destinations" memory.



### Storing a map position

Multimedia system:

**¬→** Navigation

The map is in full-screen mode.

- Press the Touch Control, the controller or the touchpad.
- Select "move map" in map menu 2  $(\longrightarrow)$  page 279).
- Select a position on the map. If multiple entries are available for a map position, a list appears.
- Highlight an entry.
- Select Store in "Previous Destinations".

The map position is saved to the "Previous destinations" memory.

# Editing the previous destinations

Multimedia system:

- ¬→ Navigation
- ▶ Previous and Other Destinations
- >> Previous Destinations
- Highlight one of the previous destinations.

To save as a favorite: select Save My Favorite.

The favorites are displayed.

- Move the favorite to the desired position. If a favorite has already been added at this position, it will be overwritten.
- ➤ To save as "Home" address: select Save as "Home".
- To save as "Work" address: select Save as "Work".
- To delete a single or all destinations: select Delete or Delete All.

  A prompt appears.
- Select Yes.
- To display destination information: select Details.

### Using external destinations and routes

External destinations and routes can be received from the following sources:

- Mercedes-Benz Apps
- door-to-door navigation with Companion app (USA)

(i) Received destinations are saved in the previous destinations.

A prompt appears on the media display.

- A destination has been received without picture information: select Yes.
- If route guidance is not active, select Start Route Guidance.

The route to the destination is calculated. The map shows the route. Route guidance then begins.

or

If route guidance is active, select Start New Route Guidance or Set as Next Way Point. Start New Route Guidance: the received destination address is set as a new destination. The previous destinations and intermediate destinations are deleted. Route guidance to the new destination begins.

Set as Next Way Point: the received destination address is set as the next intermediate destination. Route guidance begins.



A destination has been received with picture information: select Start Route Guidance.

 Route guidance starts.
 A route has been received: select Start Route Guid. from Beginning of Route.

or

Select Start Route Guidance from Current Position.

Route guidance starts from the selected position.

# Route guidance with current traffic reports

### Traffic information overview

Traffic reports are received using Live Traffic Information and are used for route guidance.

This service is unavailable in some countries.

There may be differences between the traffic reports received and the actual road and traffic conditions.

Important information on Live Traffic Information:

- Current traffic reports are received via the Internet connection.
- The traffic situation is updated at short, regular intervals.
- The subscription information shows the status ( $\longrightarrow$  page 277).

Information on the vehicle's position is regularly sent to Daimler AG. The data is immediately rendered anonymous by Daimler AG and forwarded to the traffic data provider. Using this data, traffic reports relevant to the vehicle's position are sent to the vehicle. The vehicle acts as a sensor for the flow of traffic and helps to improve the quality of the traffic reports.

If you do not wish to transmit your vehicle position, you can have this service deactivated at an authorized Mercedes-Benz Center.

# Displaying subscription information

### Requirements:

 The vehicle is equipped with Live Traffic Information.

Multimedia system:

# → Navigation → Options

The subscription expiration date is automatically displayed:

- one month before the expiration date.
- one week before the expiration date.
- on the expiration date.
- To display manually: select Live Traffic Subscription Info.

Depending on the status, one of the following messages appears:

- the period of validity for the subscription is displayed.
- the subscription has expired.
- The subscription can be extended:
  - at an authorized Mercedes-Benz Center
  - via an MB Info call to the Mercedes-Benz **Customer Assistance Center**



### Displaying the traffic map

### Requirements:

- For Live Traffic Information: the vehicle is equipped with a communication module featuring an activated, integrated SIM card.
- · When the vehicle is started, the communication module automatically establishes an Internet connection. Traffic information is made available shortly afterwards.

Multimedia system:

→ Navigation → Options

# Map Menu

- Alternatively: if the map is displayed in full screen mode, press the Touch Control, the controller or the touchpad. The map menu appears.
- Activate **₽ ✓**.

The traffic map shows the following information, for example:

- traffic incidents, for example:
  - roadworks
  - road blocks

warning messages

The symbols for traffic incidents are displayed in color (on the route) or gray (off the route).

- traffic flow information:
  - traffic jam (red line)
  - slow-moving traffic (orange line)
  - heavy traffic (yellow line)
  - free-flowing traffic (green line)
- display for traffic delays on the route lasting at least one minute
- · warning message symbols:
  - 🕦 symbol
  - additional road safety notes when approaching a traffic incident, e.g. the end of a traffic jam

# Displaying traffic incidents

Multimedia system:

→ Navigation → Options

- ▶ Map Content
- Activate Traffic Incidents.
   Roadworks, road blocks, local area reports (e.g. fog) and warning messages are displayed.

### Activating free flow and traffic display

- Activate Free Flowing Traffic and Traffic Delays.
- i The traffic delay is displayed for the current route. Traffic delays lasting one minute or longer are taken into consideration.

### Displaying details

- ▶ Displays the traffic map (→ page 277).
- Moves the map (→ page 280).
- When a traffic report symbol is under the crosshair, press on the central control element.

The traffic report details are displayed.

DEALER ePROCESS

- Press on the central control element.
- Select Information on Traffic Reports. The map shows the traffic report symbols in the vicinity.

Traffic report information is displayed in the status line:

- · Traffic report symbol
- Reason for the traffic report, e.g. traffic congestion
- Warning message (highlighted in red)
- To select a traffic report symbol: select Next or Previous.
- Press on the central control element. The traffic report details are displayed.

# Issuing hazard warnings

Multimedia system:

- → Navigation → Options
- >> Announcements

or

### Map and compass

### Map and compass overview



- Saves the current vehicle position
- Moves the map
- Selects the map orientation and map view
- Selects the function depending on the equipment:
  - Sends a hazard warning via Car-to-X.

- Filters the display of POIs in the vicinity according to POI category
- Switches the display of personal POI symbols on the map on or off
- Switches one of the following displays on or off depending on the equipment:
  - Weather information
  - Satellite map
  - Traffic incidents
- Switches the traffic map display on or off

The map and satellite images are shown in globe projection. This allows for a realistic map display in all map scales. The map uses elevation modeling.

Depending on the map data, important buildings in many cities are depicted realistically on the map in small map scales (e.g. 1/32 mi (20 m), 1/16 mi (50 m)). Other buildings are shown as models.

(i) You can set the unit of measurement of the map scale ( $\longrightarrow$  page 252).

If online information is available, fuel prices and the availability of parking spaces in parking garages are displayed, for example.

- Requirements:
  - Mercedes me connect is available.
  - You have a user account for the Mercedes me portal.
  - The service has been activated at an authorized Mercedes-Benz Center.

Further information can be found at: http:// www.mercedes.me

The online information is not available in all countries.

If Display in COMAND is activated in Traffic Sign Assist (\rightarrow\rightarrow\text{page 199}), speed limits and overtaking restrictions are displayed on the map.

(i) Company logos displayed on the map are trademarks of the respective companies and used solely for the purpose of indicating the locations of these companies. The use of such logos on the map does not indicate approval of, support of or advertising by these companies for the navigation system itself.

# Setting the map scale

### Requirements:

The map is shown.

Multimedia system:

- **¬→** Navigation
- To zoom in: swipe down on the Touch Control.

or

► Turn the controller counter-clockwise.

or

- Move two fingers apart on the touchpad.
- To zoom out: swipe up on the Touch Control.

Turn the controller clockwise.

or

- Move two fingers together on the touchpad.

# Moving the map

Multimedia system:

→ Navigation → Options

The map menu appears.

- ▶ Map Menu
- Alternatively, if the map is displayed in full screen mode, press the central control element.
- Select "Move map" in map menu (2) (———) page 279).
- Swipe in any direction on the Touch Control or touchpad.

or

Slide the controller in any direction.
 The map moves in the corresponding direction under the crosshair. The further you move your finger away from the starting posi-

tion on the touchpad, the faster the map moves.

# **Selecting the map orientation** Multimedia system:

→ Navigation → 🐧 Options

- Map Menu
- Alternatively, if the map is displayed in full screen mode, press the central control element.
- In map menu ③, select N, 2D or 3D(→ page 279).

The map menu appears.

- N: the 2D map view is displayed so that north is always at the top.
- 2D: the 2D map view is aligned to the direction of travel.
- 3D: the 3D map view is aligned to the direction of travel.

or



### Selecting POI symbols

Multimedia system:

→ Navigation → Options

Map Content

POIs include gas stations and hotels which can be displayed as symbols on the map, for example. Not all POIs are available everywhere.

- Select POI Symbols.
  - The dot indicates the current setting.

Standard displays symbols of predefined categories on the map.

User Defined allows you to personally select the symbols for the available categories.

None switches the display off.

- Select a setting.
- User Defined: select categories. The POI symbols of the selected categories are displayed  $\mathbf{\nabla}$  or not displayed  $\square$ .

### Selecting the display of text information in the map

Multimedia system:

→ Navigation → Options

- >> Text Information
- Select text information.

Current Street shows the street you are currently driving on at the bottom of the display.

When the map is moved, the following information appears under the crosshair:

- Street name
- POI name
- Area name

Geo-coordinates displays the following information:

- Longitude and latitude
- Elevation

The elevation shown may deviate from the actual elevation.

Number of satellites from which a signal can be received

DEALER EPROCESS

When the map is moved, this information does not appear.

Climate Control displays the current climate control settings.

None switches the display off.

# Displaying the next intersecting street

### Requirements:

• Route guidance is not active.

Multimedia system:

- ¬→ Navigation → Options
- Activate Next Intersecting Street. The name of the next intersecting street will be displayed at the upper edge of the display.

# Displaying the map version

Multimedia system:

- → Navigation → Options
- Select Map Version.
- Select Details.

i Information about new versions of the digital map can be obtained from an authorized Mercedes-Benz Center.

### Overview of avoiding an area

You can define areas along a route that you would like to avoid.

The route can include an area that is to be avoided in the following situations:

- the destination is located in an area that is to be avoided
- if freeways are located within the area that is to be avoided

Freeways are always taken into account for the route.

· there is no sensible alternative route

# Avoiding a new area

Multimedia system:

- → Navigation → 🔼 Route and Position
- ➤ Avoid Options ➤ Areas
- Select Avoid New Area.
- ► To search for an area via the map: select Using Map.

Move the map

or

- To search for an area using an address: select Address Entry.
- Enter the address.
- Select Select Destination.

The map appears.

- ➤ To display an area: press the Touch Control, the touchpad or the controller.

  A red rectangle appears. This designates the area that should be avoided.
- To change the size of the area: swipe up or down on the Touch Control or the touchpad.

or

- Slide the controller up or down.
  The map scale is enlarged or reduced and changes the size of the area.
- ➤ To set the area: press the Touch Control, the touchpad or the controller.

  The area is entered into the list.



# Changing an area

Multimedia system:

- → Navigation → 🔼 Route and Position
- ➤ Avoid Options ➤ Areas
- Highlight an area in the list.
- ➤ Select 🖼 Edit.

### Moving the area on the map

Swipe in any direction on the Touch Control or touchpad.

or

Slide the controller in any direction.

### Changing the size of the area

- ➤ **To start**: press the Touch Control, the touchpad or the controller.
- To change: swipe up or down on the Touch Control or the touchpad.

or

- Slide the controller up or down.
  - **To stop:** press the Touch Control, the touchpad or the controller.

### Taking the area for the route into account

Avoid an area in the list. If route guidance is active, a new route is calculated.

If there is no route yet, the setting is carried over to the next route guidance.

# Deleting one or all areas

Multimedia system:

- → Navigation → 🔼 Route and Position
- ➤ Avoid Options ➤ Areas
- Highlight an area in the list.
- Select Delete or Delete All.
- Confirm the prompt with Yes. One or all areas are deleted.

### Map data update overview

### Updating at the authorized Mercedes-Benz Center

The digital maps generated by the map software become outdated in the same way as conventional road maps. Optimal route guidance can only be provided by the navigation system in conjunction with the most up-to-date map data.

Information about new versions of the digital map can be obtained from an authorized Mercedes-Benz Center.

You can receive updates to the digital map there.

### Online map update

The online map update service from Mercedes me connect can be used to update map data.

(i) The online map update service is not available in all countries.

The following options are available for the update:

- the automatic map update updates map data for one region.
  - For automatic map updates Automatic Online Update must be activated in the system settings ( $\longrightarrow$  page 256).
- the manual map update updates map data for several or all regions.

Further information on the online map update is available at an authorized Mercedes-Benz Center or at http://www.mercedes.me.

DEALER ePROCESS

Further information on updates: http:// manuals.daimler.com/baix/cars/connectme/ en GB/index.html.

### Overview of map data

Your vehicle is supplied with map data at the factory. Depending on the country, map data for your region is either pre-installed or the map data is supplied on a data storage medium.

If the map data on your vehicle has been installed at the factory and you wish to reinstall it, you do not need to enter the activation code

For map data that you have purchased in the form of a data storage medium, you must enter the accompanying activation code.

(i) If you save the map data on a data storage medium with the online map update service, no entry is required. The activation code is stored on the data storage medium during the downloading process.

Observe the following when entering the activation code:

 The activation code can be used for one vehicle

### 284 Multimedia system

- The activation code is not transferable
- The activation code has six digits

In the event of the following problems, please contact an authorized Mercedes-Benz Center:

- The multimedia system does not accept the activation code
- You have lost the activation code

# Displaying the compass

Multimedia system:

- → Navigation → 🔼 Route and Position
- Select Compass.

The compass display shows the following information:

- the current direction of travel with bearing (360° format) and compass direction
- longitude and latitude coordinates in degrees, minutes and seconds
- · height (rounded)
- number of GPS satellites from which a signal can be received

# Setting the map scale automatically

Multimedia system:

→ Navigation → Options

The map scale is set automatically depending on your driving speed.

For journeys in cities with detailed city models, a map view from the driver's perspective is used.

- ► Switch Auto Zoom on **✓** or off □.
- The automatically selected map scale can be changed manually for a short time. The setting is reset automatically after a few seconds.

# Displaying the satellite map

Multimedia system:

- → Navigation → Options
- >> Map Content
- ➤ Switch Satellite Map on ✓ or off □.



Switched on **!**: satellite maps are displayed in map scales of 2 mi (2 km) or less.

Switched off □: satellite maps are not displayed in map scales from 2 mi (2 km) to 10 mi (10 km).

(i) Satellite maps for these map scales are not available in all countries.

# Displaying weather information

### Requirements:

- · Mercedes me connect is available.
- You have a user account for the Mercedes me portal.
- The service is available.
- The service has been activated at an authorized Mercedes-Benz Center.

Further information can be found at: http://www.mercedes.me

### Multimedia system:

- → Navigation → Options
- Map Content
- Activate Weather Information .

or

- If weather information display (6) is available in the map menu, activate  $\bigcirc$  (  $\longrightarrow$  page 279) it. Current weather information is displayed on the navigation map, e.g. temperature or cloud cover.
- Weather information is not available in all countries.

### Calling up the Digital Operator's Manual (navigation)

### Calling up information on navigation Multimedia system:

- → Navigation → Options
- >> Navigation Info
- Select the topic.

### Telephone

### Telephony

### Notes on telephony

WARNING Risk of distraction from operating integrated communication equipment while the vehicle is in motion

If you operate communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.



WARNING Risk of distraction from operating mobile communication equipment while the vehicle is in motion

If you operate mobile communication equipment when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

Only operate this equipment when the vehicle is stationary.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

Further information can be obtained from an authorized Mercedes-Benz Center or at: http:// www.mercedes-benz.com/connect.



### Telephone menu overview



- Bluetooth® device name of the currently connected mobile phone
- Signal strength of the mobile phone network for the currently connected and selected mobile phone
- Battery status of the currently connected and selected mobile phone

- (telephone ready) or (call active)
- $\bigcirc$  Contacts ( $\longrightarrow$  page 292)
- Text Message
- One mobile phone connected: Active Call.



Two mobile phones connected: changes view between telephone 1 and 2 or Active Call

- Devices ( page 287)
- Options

Symbols 1 to 4 are not shown until after a mobile phone has been connected to the multimedia system. The symbols depend on your mobile phone and your mobile phone network provider.

#### Bluetooth® profile overview

Bluetooth® profile of the mobile phone	Function
PBAP (Phone Book Access Profile)	Contacts are automatically displayed in the multimedia system
MAP (Message Access Profile)	Message functions can be used

## Telephony operating modes overview

Depending on your equipment, the following telephony operating modes are available:

· A mobile phone is connected to the multime-

• Two mobile phones are connected with the multimedia system via Bluetooth® (two phone mode) ( $\longrightarrow$  page 288).

#### Information on telephony

The following situations can lead to the call being disconnected while the vehicle is in motion:

- There is insufficient network coverage in the area
- You move from one GSM or UMTS transmitter/receiver area (cell) into another and no communication channels are free
- The SIM card used is not compatible with the network available
- A mobile phone with "Twincard" is logged into the network with the second SIM card at the same time

The multimedia system supports calls in HD Voice® for improved speech quality. A requirement for this is that the mobile phone and the mobile phone network provider of the person you are calling support HD Voice®.

Depending on the quality of the connection, the voice quality may fluctuate.

### Connecting a mobile phone (Bluetooth® telephony)

### Requirements:

- Bluetooth<sup>®</sup> is activated on the mobile phone (see the manufacturer's operating instructions).
- Bluetooth<sup>®</sup> is activated on the multimedia. system ( $\longrightarrow$  page 248).

#### Multimedia system:

→ Phone → ★ Devices

### Searching for a mobile phone

- Select Connect New Device.
- Select Start Search on System.

The available mobile phones are displayed. If a new mobile phone is found, it is indicated by the 🔳 symbol.



# Connecting a mobile phone (authorization using Secure Simple Pairing)

- Select the mobile phone.
   A code is displayed in the multimedia system and on the mobile phone.
- If the codes match: confirm the code on the mobile phone.

# Connecting a mobile phone (authorization by entering a passkey)

- Select the mobile phone.
- Choose a one to sixteen-digit number combination as a passkey.
- On the multimedia system: enter the passkey and select OK.
- On the mobile phone: enter the passkey again and confirm.
- i Up to 15 mobile phones can be authorized on the multimedia system.

  Authorized mobile phones are reconnected automatically.

# Connecting a second mobile phone (two phone mode)

#### Requirements:

At least one mobile phone is already connected to the multimedia system via Bluetooth<sup>®</sup>.

#### Multimedia system:

- ¬→ Phone → \* Devices
- Select Connect New Device.
- Select Start Search on System. The available mobile phones are displayed.
- Select the mobile phone.
- Answer the How would you like to connect the new device? prompt.
- ➤ To replace the currently connected mobile phone: select Phone 1.

  The currently connected mobile phone is replaced by the new mobile phone.

or

To connect the second mobile phone:
 select Phone 2.
 The new mobile phone is connected as Phone 2. If two mobile phones have already

been connected, the second telephone is replaced by the new mobile phone.

or

- (i) A mobile phone can be operated both as an audio source as well as telephone in parallel.

# Functions of the mobile phone in two phone mode

#### **Functions overview**

Mobile phone in the foreground	Mobile phone in the background
Full range of functions	Incoming calls



#### Interchanging mobile phones (two phone mode)


#### Requirements:

· The mobile phones are authorized  $(\longrightarrow)$  page 287).

#### Multimedia system:

- ¬→ Phone → \* Devices
- In the device overview, select a mobile phone which has already been authorized and set as Phone 1 or Phone 2.

After interchanging the mobile phones, the mobile phone in the foreground is replaced by the mobile phone in the background.



- Bluetooth® device name of the currently connected mobile phone
- Connects a mobile phone as Phone 1
- Connects a mobile phone as Phone 2
- Connects a mobile phone as Audio Source



- Disconnecting a mobile phone( $\longrightarrow$  page 289)
- De-authorizing a mobile phone( $\longrightarrow$  page 289)
- (i) If a new mobile phone is connected and defined as Phone 1, for example, this overwrites the previously connected mobile phone in the foreground of the system.

# Disconnecting a mobile phone

Multimedia system:

- ¬→ Phone → \* Devices
- Select the symbol in the line of the mobile phone.

The disconnection of the mobile phone takes place without a confirmation prompt. The mobile phone remains authorized in the system.

# De-authorizing a mobile phone

Multimedia system: → Phone → \* Devices

Select the **x** symbol in the line of the mobile phone.

Answer the confirmation prompt with Yes. The mobile phone is deauthorized and deleted from the system.

# Information on Near Field Communication (NFC)

NFC enables short-range wireless data transfer or (re)connection of a mobile phone with the multimedia system.

The following functions are available without having authorized a mobile phone:

- Transferring a URL to be viewed in the multimedia system (see the manufacturer's operating instructions).
- Setting up the vehicle's Wi-Fi access data via the system settings ( >> page 250).


Further information can be found at: http://www.mercedes-benz.com/connect

# Using the mobile phone with Near Field Communication (NFC)

### Requirements:

• NFC is activated on the mobile phone (see the manufacturer's operating instructions)

 The mobile phone's screen is switched on and unlocked (see the manufacturer's operating instructions)



► To connect a mobile phone: open the cover of the armrest on the center console.



Place the NFC area of the mobile phone (see manufacturer's operating instructions) on NFC logo .

The mobile phone is connected to the multimedia system.

➤ To change mobile phones: place the NFC area of the mobile phone on NFC logo ①. If the mobile phone has already been authorised on the multimedia system, it is now connected.

If the mobile phone is authorised on the multimedia system for the first time, it is connected after confirming the mobile phone instructions (see the manufacturer's operating instructions).

Further information can be found at: http://www.mercedes-benz.com/connect

Setting the reception and transmission volume

### Requirements:

A mobile phone is authorized
 page 287).

#### Multimedia system:

→ Phone → Options → Phone

This function ensures optimal language quality.

- Select Reception Volume or Transmission Volume.
- Set the volume.

Further information on the recommended reception and transmission volume: http:// www.mercedes-benz.com/connect

### Adjusting the call and ringtone volume Multimedia system:

- ¬→ System → Audio → Phone
- Select Call Volume or Ringtone Volume.
- Set the volume.

#### Starting/stopping mobile phone voice recognition

### Requirements:

• The mobile phone is connected to the multimedia system ( page 287).

### Starting mobile phone voice recognition

- Press and hold the button on the multifunction steering wheel for more than one second.
- You can use mobile phone voice recognition.

## Stopping mobile phone voice recognition

Press the 🔯 or 🕿 button on the multifunction steering wheel.

#### Calls

# Using the telephone

Multimedia system:

→ Phone → Contacts

### Making a call

- Select Numerical Keypad.
- Enter the number.
- Select . The call is made.

### Accepting a call

Select Accept.



#### Rejecting a call

Select Reject.

## Ending a call

Select

## Activating functions during a call

To show all functions, navigate down.

The following functions are available during a call:

- End Call
- Make Additional Call
- Keyboard (show to send DTMF tones)
- Private Mode (an active call in hands-free mode is transferred over to the telephone)

# Conducting calls with several participants

### Requirements:

- There is an active call (——— page 291).
- · Another call is being made.

#### Switching between calls

➤ Select call •.

The selected call is active. The other call is on hold.

### Activating or ending a call on hold

Select Continue Call or End Call.

#### Conducting a conference call

 Select Create Conference Call in the telephone menu.

The new participant is included in the conference call.

#### Ending an active call

- Select \_\_\_\_\_.
- (i) On some mobile phones, the call on hold is activated as soon as the active call is ended.

## Accepting/rejecting a waiting call

### Requirements:

There is an active call (→ page 291).

If you receive a call while already in a call, a message is displayed. An acoustic signal also sounds.

Select Accept.
 The incoming call is active.

If only one mobile phone is connected with the multimedia system, the previous call will be put on hold.

If during a call you accept a call with the other mobile phone when in two phone mode then the existing call is ended.

- Select Reject.
- This function and behavior depends on your mobile phone network provider and the mobile phone (see the manufacturer's operating instructions).

#### **Contacts**

#### Information about the contacts menu

The contacts menu contains all contacts from existing data sources, e.g. mobile phone or memory card. You can store up to 6,000 contacts.

DEALER EPROCESS

Depending on the data source, you have the following number of contacts:

- Permanently saved contacts: 3,000 entries
- Contacts loaded from the mobile phone: 3,000 entries

From the contacts menu, you can perform the following actions:

- Using the telephone:
  - Calling a contact (→ page 294)
  - Calling a new number (→ page 291)
- Navigation (→ page 265)
- Compose messages (→ page 296)

If a mobile phone is connected to the multimedia system ( page 287) and automatic calling up ( page 293) is activated, the mobile phone's contacts are displayed in the address book.

#### Downloading mobile phone contacts Multimedia system:

→ Phone → Options → Contacts

#### Automatically

Switch Synchronize Contacts Automatically on 🗹.

#### Manually

- Deactivate ☐ Synchronize Contacts Automatically.
- Select Synchronize Contacts.

# Calling up contacts

Multimedia system:

¬→ Phone → □ Contacts

Depending on the character set, the following options can be used to search for contacts:

- searching by initials
- searching by name
- · searching by phone number

- Enter characters into the search field A selection of possible contacts appears. Entering more characters into the search field narrows down the number of possible selections.
- Select the contact.

A contact can contain the following details:

- phone numbers
- navigation addresses
- geo-coordinates
- Internet address

#### Editing the format of a contact's name Multimedia system:

→ Phone → Options → Contacts

DEALER ePROCESS

>> Name Format

The following options are available:

- Last Name, First Name
- Last Name First Name
- First Name Last Name
- Select an option.

#### Overview of importing contacts

#### Contacts from various sources

Source	Requirements
Memory card	The SD memory card is inserted.
USB device	The USB device is inserted in the USB port.

Source	Requirements
Bluetooth® connection	If the sending of vCards via Bluetooth® is supported, vCards can be received on mobile phones or netbooks, for example.
	Bluetooth® is activated in the multimedia system and on the respective device (see the manufacturer's operating instructions).
Mobile phone	The mobile phone is connected to the multimedia system.

# Importing contacts into the contacts menu Multimedia system:

- → Phone → Options → Contacts
- Select Import.
- Select an option.

## Saving a mobile phone contact

Multimedia system:

- → Phone → Contacts
- Select the mobile phone contact .
- ➤ Select 🔳.
- Select Save to Vehicle.

The contact saved in the multimedia system is identified by the \_\_\_\_ symbol.

# Calling a contact

Multimedia system:

→ Phone → Contacts

- Enter characters into the search field.
- Select the contact.
- Select the telephone number. The number is dialed.

# Selecting further options in the contacts menu

Multimedia system:

- → Phone → Contacts
- Select a contact.
- Select . DEALER ePROCESS

Depending on the stored data, the following options are available:

- Call
- Send Text Message
- Show Website (if an Internet address has been stored)
- Navigate (if an address has been stored)
- · Save My Favorite
- Send DTMF Tones (for a number with DTMF tones)
- Select an option.

# Deleting a contact

Multimedia system:

You can delete contacts stored in the vehicle.

- Search for the contact.
- Select the contact.
- ➤ Select 🔳.
- Select Delete Contact.
- Select Yes.

#### Call list

#### Call list overview

Depending on whether your mobile phone supports the PBAP Bluetooth® profile or not, this can have different effects on the presentation and functions of the call list.

If the PBAP Bluetooth® profile is supported, the effects are as follows:

- The call lists from the mobile phone are displayed in the multimedia system.
- When connecting the mobile phone, you may have to confirm the connection for the PRAP Bluetooth® profile.

If the PBAP Bluetooth® profile is not supported, the effects are as follows:

- The multimedia system generates its own call lists.
- The call list is not synchronized with the call lists in the mobile phone.

# Making a call from the call list

Multimedia system:

- → Phone → Recent Calls
- Select a number. The call is made.

#### Text messages

### Overview of text message functions

If the connected mobile phone supports the MAP Bluetooth® profile, the text message functions can be used on the multimedia system.

You can obtain further information about settings and supported functions of Bluetooth®capable mobile phones from an authorized Mercedes-Benz Center or at: http:// www.mercedes-benz.com/connect

Some mobile phones require further settings after being connected to the multimedia system (see manufacturer's operating instructions).

New messages are identified by the symbol in the media display and an audible signal.



Depending on the mobile phone, the multimedia system only displays new incoming text messages or the 100 newest text messages.

#### Configuring the text messages displayed Multimedia system:

→ Phone → Options → Text Message

- ➤ Message Display
- Select .

A menu with the following options is shown:

- All Messages
- New and Unread Messages
- New Messages
- Off (The text messages are not displayed) automatically.)
- Select an option.
- The setting may not be active until the mobile phone is reconnected.

#### Reading text messages Multimedia system:

→ Phone → Text Message

### Reading a text message

Select a text message.The message text is displayed.

### Using the read-aloud function

- Select a text message.
- Select Read Aloud. The text message is read aloud.

# Composing and sending a text message Multimedia system:

→ Phone → Text Message

Select Write New Text Message.

### Adding a recipient

- Select Press to Add Recipient.
- Select the contact.

#### Dictating text

Select Press to Dictate.

- To start the dictation function: press on the central control element.
  - The app for the dictation function is loaded. If there was no prior Internet connection, a connection is now established.
- Say the message.
   The dictation ends automatically after you have finished speaking.

After the voice message has been processed, it is shown as text.

To replace a message: select Replace message.

The text that has been dictated and shown on the display is reset and can be dictated again.

#### **Editing text**

- Select the word.
- To call up the correction menu: press on the central control element.

The following options are available:

 Adjusting the capitalization of words (if supported by the character set) • Expanding the choice of words

- · Deleting the selection
- · Recording a new dictation
- To leave the menu: select Done.

### Sending text messages

Select Send Text Message.

# Replying to a text message Multimedia system:

- → Phone → Text Message
- Open the text message.
- Select .
- Select Reply.

# Calling a text message sender Multimedia system:

- → Phone → Text Message
- Open the text message.
- ➤ Select 🔳.
- Select Call Sender.



#### Deleting text messages

Multimedia system:

→ Phone → Text Message

Select .

To delete a text message: select Delete.

Outbox

Select Drafts.

#### Mercedes-Benz link

#### Overview of Mercedes-Benz Link

Using Mercedes-Benz Link, various functions and selected mobile phone apps can be transferred to the media display.

The Mercedes-Benz Link control box supplementary equipment is required for this. You can obtain this at an authorized Mercedes-Benz Center.

The Mercedes-Benz Link control box uses the Android operating system.

The service provider is responsible for these apps and the services and content connected to it

#### Connecting Mercedes-Benz Link with the multimedia system

- Connect the Mercedes-Benz Link control box with the USB port of the multimedia connection unit using a suitable connecting cable.
- A suitable connecting cable is available separately at an authorized Mercedes-Benz Center.

#### Using Mercedes-Benz Link

#### Requirements:

 The Mercedes-Benz Link control box is connected with the multimedia system using the USB port.

Multimedia system:

¬→ Connect

Select Mercedes-Benz Link.



Select MB Link

The mobile phone functions and apps are available and shown on the media display.

You can find more information in the Mercedes-Benz Link control box operating instructions.

#### **Ending Mercedes-Benz Link**

Multimedia system:

→ Connect ➤ Mercedes-Benz Link

Select Disconnect. The connection is ended.

The mobile phone continues to be supplied with electricity.

or

- Disconnect the connecting cable between the Mercedes-Benz Link control box and the multimedia system.
- Mercedes-Benz recommends disconnecting the connecting cable only when the vehicle is stationary.

#### Apple CarPlay™

#### Overview of Apple CarPlay™

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

iPhone® functions can be used via the multimedia system using Apple CarPlay™. They are operated using the central control element or the

Siri® voice-operated control system. You can activate the voice-operated control system by pressing and holding the button on the multifunction steering wheel.

When using Apple CarPlay™ via the voice-operated control system, the multimedia system can still be operated via the Voice Control System  $(\longrightarrow)$  page 222).

Only one mobile phone at a time can be connected via Apple CarPlay™ to the multimedia system.

The availability of Apple CarPlay™ may vary according to the country.

The service provider is responsible for this application and the services and content connected to it.

## Information on Apple CarPlay™

While using Apple CarPlay™ various functions of the multimedia system, e.g. telephony or the media sources Bluetooth® audio and iPod®, are unavailable.

Only one route guidance can be active at a time. If route guidance is active on the multimedia system, it is closed when route guidance is started on the mobile phone.

# Connecting an iPhone<sup>®</sup> via Apple CarPlay™

### Requirements:

- Apple® operating system version iOS 8.3 or above is installed on the iPhone®.
- An Internet connection is required for the full range of functions for Apple CarPlay™.
- The iPhone<sup>®</sup> is connected to the multimedia. system via the USB port using a suitable cable ( $\longrightarrow$  page 316).

Multimedia system:

→ Connect → Apple CarPlay

#### Setting automatic or manual start

A message appears when connected for the first time.

Automatic start: select Automatically. Start Automatically is activated **.** Apple CarPlay™ will now start immediately after the iPhone® is connected to the multi-

media system using a USB cable.



- Manual start: select Manually.
- Select the iPhone® in the device list.

#### Accepting/rejecting the data protection regulations

A message with the data protection regulations appears.

Select Accept & Start.

or

Select Decline & End.

#### Exiting Apple CarPlay™

- Press the houtton on the multifunction steering wheel, for example.
- If Apple CarPlay™ was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Apple CarPlay™ in the main menu.

### Calling up Apple CarPlay™ sound settings Multimedia system:

→ Connect → Apple CarPlay → Sound

Select the tone menu (→ page 333).

## Ending Apple CarPlay™

Multimedia system:

→ Connect → Apple CarPlay

Select Disconnect. The connection is ended

> The mobile phone continues to be supplied with electricity.

Disconnect the connecting cable between the mobile phone and multimedia system. Mercedes-Benz recommends disconnecting the connecting cable only when the vehicle is stationary.

#### **Android Auto**

#### Android Auto overview

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle

DEALER ePROCESS

when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system. Mobile phone functions can be used with Android Auto using the Android operating system on the multimedia system. It is operated using the central control element or the voice control. You can activate the voice-operated control system by pressing and holding the 3 button on the multifunction steering wheel.

When using Android Auto via the voice-operated control system, the multimedia system can still be operated via the Voice Control System  $(\longrightarrow)$  page 222).

Only one mobile phone at a time can be connected via Android Auto to the multimedia system.

The availability of Android Auto and Android Auto Apps may vary according to the country.

The service provider is responsible for this application and the services and content connected to it.

#### Information on Android Auto

While using Android Auto, various functions of the multimedia system, for example the media source Bluetooth® audio, are not available.

Only one route guidance can be active at a time. If route guidance is active on the multimedia system, it is closed when route guidance is started on the mobile phone.

# Connecting a mobile phone via Android Auto

#### Requirements:

- The first activation of Android Auto on the multimedia system must be carried out when the vehicle is stationary for safety reasons.
- The mobile phone supports Android Auto from Android 5.0.

- The Android Auto app is installed on the mobile phone.
- In order to use the telephone functions, the mobile phone must be connected to the multimedia system via Bluetooth<sup>®</sup> (——> page 287).

If there was no prior Internet connection, this is established with the use of the mobile phone with Android Auto.

- The mobile phone is connected to the multimedia system via the USB port page 316).
- An Internet connection is required for the full range of functions for Android Auto.

#### Multimedia system:

→ Connect → Android Auto

Select the mobile phone from the device list.

# Accepting/rejecting the data protection regulations

A message with the data protection regulations appears.

► Select Accept & Start.

DEALER EPROCESS

or

Select Decline & End.

#### **Activating automatic start**

▶ Select Start Automatically <a>
▼</a>.

### Starting manually

Select the mobile phone from the device list.

#### **Exiting Android Auto**

- Press the button on the multifunction steering wheel, for example.
- i If Android Auto was not displayed in the foreground before disconnecting, the application starts in the background when reconnected. You can call up Android Auto in the main menu.

# Calling up the Android Auto sound settings Multimedia system:

→ Connect → Android Auto → Sound

Select the tone menu (→ page 333).

### **Ending Android Auto**

Multimedia system:

- ¬→ Connect → Android Auto
- Select Disconnect.

The connection is ended.

The mobile phone continues to be supplied with electricity.

Disconnect the connecting cable between the mobile phone and multimedia system. Mercedes-Benz recommends disconnecting the connecting cable only when the vehicle is stationary.

## Transferred vehicle data with Android Auto and Apple CarPlay™

#### Overview of transferred vehicle data

When using Android Auto or Apple CarPlay™, certain vehicle data is transferred to the mobile phone. This enables you to get the best out of selected mobile phone services. Vehicle data is not directly accessible.

The following system information is transmitted:

- Software release of the multimedia system
- System ID (anonymized)

The transfer of this data is used to optimize communication between the vehicle and the mobile phone.

To do this, and to assign several vehicles to the mobile phone, a vehicle identifier is randomly generated.

This has no connection to the vehicle identification number (VIN) and is deleted when the multimedia system is reset ( $\longrightarrow$  page 257).

The following driving status data is transmitted:

- Transmission position engaged
- Distinction between parking, standstill, rolling and driving
- Day/night mode of the instrument cluster

DEALER EPROCESS

The transfer of this data is used to alter how content is displayed to correspond to the driving situation.

The following position data is transmitted:

- Coordinates
- Speed
- Compass direction
- Acceleration direction

This data is only transferred while the navigation system is active in order to improve it (e.g. so it can continue functioning when in a tunnel).

#### Mercedes me connect

#### Notes on Mercedes me connect

Mercedes me connect provides the following services:

- · Accident and breakdown management (me button)
- Concierge Service (when the service is activated), appointment requests or similar (me button)
- Mercedes-Benz emergency call system (automatic emergency call or SOS button)

The Mercedes-Benz Customer Center and the Mercedes-Benz emergency call center are available for you around the clock.

Observe the conditions of use for Mercedes me connect and other services. These can be obtained in the Mercedes me portal: https://me.secure.mercedes-benz.com

# Calling the Mercedes-Benz Customer Center using the multimedia system

#### Requirements:

- You have access to a GSM network.
- The contract partner's GSM network coverage is available in the respective region.
- The ignition is switched on so that vehicle data can be transferred automatically.

#### Multimedia system:

- Call Mercedes me connect.
   The call is made.


Then, you can select a service and be connected to a specialist at the Mercedes-Benz Customer Center.

# Making a call via the overhead control panel

#### Requirements:

- · You have access to a GSM network.
- The contract partner's GSM network coverage is available in the respective region.

 The ignition is switched on so that vehicle data can be transferred automatically.



- Service call button (me button)
- SOS button cover
- SOS button
- To make a service call: press button ①.



- To make an emergency call: press SOS button cover 2 briefly to open.
- Press and hold SOS button (3) for at least one second.

If a service call is active, an emergency call can still be triggered. This has priority over all other active calls.

Service calls are only possible if a mobile phone network is available.

#### Information about the service call using the me button

A call to the Mercedes-Benz Customer Center has been initiated via the me button in the overhead control panel or the multimedia system.

In the event of a breakdown, you will get support:

• A qualified Mercedes-Benz technician provides breakdown assistance on site and/or the vehicle will be towed to the nearest authorized Mercedes-Benz Center.

You may be charged for these services.

You can find information on the following topics:

- Activation of Mercedes me connect
- Operating the vehicle
- Nearest authorized Mercedes-Benz Center
- Other products and services from Mercedes-Benz

Data is transferred during the connection to the Mercedes-Benz Customer Center  $(\longrightarrow)$  page 304).

## Information on Mercedes me connect accident management

The Mercedes me connect accident management is an extension of the Mercedes-Benz emergency call system ( page 304).

An emergency call is made to the Mercedes-Benz emergency call center after an accident:

- · A voice connection is made to a contact person at the Mercedes-Benz emergency call center.
- · If necessary, the contact person at the Mercedes-Benz emergency call center for-

DEALER ePROCESS

wards the call to Mercedes me connect accident management.

Forwarding the call is not possible in all countries.

 If necessary, the vehicle will be towed to an authorized Mercedes-Benz Center.

#### Arranging a service appointment via Mercedes me connect

If you have activated the maintenance management service, relevant vehicle data is transferred automatically to the Mercedes-Benz Customer Center. You will then receive individual recommendations regarding the maintenance of your vehicle.

Regardless of whether you have consented to the maintenance management service, the multimedia system reminds you after a certain amount of time that a service is due. A prompt appears asking if you would like to make an appointment.

To arrange a service appointment: select Call.

After your agreement the vehicle data is sent and a Mercedes-Benz Customer Center

employee deals with your appointment. The information is then sent to your desired service outlet.

This service outlet will then contact you within 24 hours.

i If you select Later after the service message appears, the message is hidden and reappears after a certain period of time.

# Transferred data during a service call

Observe the conditions of use for Mercedes me connect and other services. These can be obtained in the Mercedes me portal: https://me.secure.mercedes-benz.com

When you make a service call via Mercedes me connect, data will be transmitted.

The following data is transmitted if a service call is made via Mercedes me connect:

- Vehicle identification number
- · Reason for the initiation of the call

#### Mercedes-Benz emergency call system

# Information on the Mercedes-Benz emergency call system

Your vehicle is equipped with the Mercedes-Benz emergency call system ("eCall"). This feature can help save lives in the event of an accident. eCall in no way replaces assistance provided from dialing 911.

The Mercedes-Benz emergency call system is available for at least ten years starting from the manufacturing date.

Mercedes-Benz eCall only functions in areas where mobile phone coverage is available from the wireless service providers. Insufficient network coverage from the wireless service providers may result in an emergency call not being transmitted.

DEALER ePROCESS

To disable eCall, a customer must visit an authorized Mercedes-Benz Service department to deactivate the vehicle's communication module.

Deactivation of this module prevents the activation of any and all Mercedes me connect services. After the deactivation of eCall, automatic emergency call and manual emergency call will not be available.

The ignition must be switched on before an automatic emergency call can be made.

- (i) eCall is activated at the factory.
- i eCall can be deactivated by an authorized Mercedes-Benz dealer. Please note that in the event ownership of the vehicle is transferred to another owner in its deactivated state, eCall will remain deactivated unless the new owner visits an authorized Mercedes-Benz dealership to reactivate the system.

# Overview of the Mercedes-Benz emergency call system

eCall can help to reduce the time between an accident and the arrival of emergency services

at the site of the accident. It helps locate an accident site in places that are difficult to access. However, even if a vehicle is equipped with eCall, this does not mean the system is ON. As such, eCall does not replace dialing 911 in the event of an accident.

The emergency call can be made automatically  $(\longrightarrow)$  page 305) or manually  $(\longrightarrow)$  page 305). Only make emergency calls if you or others are in need of rescue

Only make emergency calls if you or others are in need of rescue. Do not make an emergency call in the event of a breakdown or a similar situation.

#### Displays in the media display:

SOS READY: eCall available

SOS NOT READY: the ignition is not on or eCall is not available.

During an active emergency call, \(\mathbb{sos}\) appears in the display.

You can find more information on the regional availability of eCall system at: http:// www.mercedes-benz.com/connect ecall.

If there is a malfunction in the emergency call system (e.g. a malfunction with the speaker, microphone, airbag, SOS button), a corresponding message appears in the multifunction display of the instrument cluster.

# Triggering an automatic emergency call

### Requirements

- . The ignition is switched on.
- The starter battery is sufficiently charged.

If restraint systems such as airbags or Emergency Tensioning Devices have been activated after an accident, the Mercedes-Benz emergency call system may automatically initiate an emergency call.

The emergency call has been made:

- A voice connection is made to the Mercedes-Benz emergency call center.
- A message with accident data is transmitted to the Mercedes-Benz emergency call center. The Mercedes-Benz emergency call center

can transmit the vehicle position data to one of the emergency call centers.

The SOS button in the overhead control panel flashes until the emergency call is finished.

It is not possible to immediately end an automatic emergency call.

If no connection can be made to the emergency services either, a corresponding message appears in the media display.

Dial the local emergency number on your mobile phone.

If an emergency call has been initiated:

- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call center operator.
- Based on the call, the operator decides whether it is necessary to call rescue teams and/or the police to the accident site.
- If no vehicle occupant answers, an ambulance is sent to the vehicle immediately.

### Triggering a manual emergency call

Press and hold the SOS button in the overhead control panel for at least one second.



The emergency call has been made:

- A voice connection is made to the Mercedes-Benz emergency call center.
- A message with accident data is transmitted to the Mercedes-Benz emergency call center.
   The Mercedes-Benz emergency call center can transmit the vehicle position data to one of the emergency call centers.
- Remain in the vehicle if the road and traffic conditions permit you to do so until a voice connection is established with the emergency call center service provider.
- On the basis of the call, the service provider decides whether it is necessary to call rescue teams and/or the police to the accident site.

If no connection can be made to the emergency services either, a corresponding message appears in the media display.

Dial the local emergency number on your mobile phone.

#### Ending an unintentional emergency call

Select on the multifunction steering wheel. Depress button for several seconds.

# Data transfer of the Mercedes-Benz emergency call system

In the event of an automatic or manual emergency call the following data is transmitted, for example:

- Vehicle's GPS position data
- GPS position data on the route (a few 300 feet (hundred meters) before the incident)
- · Direction of travel
- · Vehicle identification number
- · Vehicle drive type
- Number of people determined to be in the vehicle
- Whether Mercedes me connect is available or not
- Whether the emergency call was initiated manually or automatically
- Time of the accident



• Language setting on the multimedia system

Data transmitted is vehicle information. For any questions about the collection, use and sharing of the eCall system data, please contact MBU-SA's Customer Assistance Center at 800-FOR-MERC.

For Canada, please contact MBC's Customer Assistance Center at 1-800-387-000.

Customer requests for covered information should be submitted via the same channels.

For accident clarification purposes, the following measures can be taken up to an hour after the emergency call has been initiated:

- The current vehicle position can be called up
- A voice connection to the vehicle occupants can be established

# Online and Internet functions

#### Internet connection

#### Information on connecting to the Internet

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

WARNING Risk of distraction from operating mobile communication equipment while the vehicle is in motion.

If you operate mobile communication equipment when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle.

Only operate this equipment when the vehicle is stationary.

You must observe the legal requirements for the country in which you are currently driving when operating mobile communication equipment in the vehicle.

The Internet functions can only be used to a limited degree whilst driving.

#### Function of the communication module

On vehicles with a built-in communication module, the Internet connection is established via an integrated SIM card.



To use Internet access via the communication module the following conditions must be met:

- The vehicle is equipped with a permanently installed communication module.
- Mercedes me connect is active and ready for operation.
- Mercedes me connect is activated for Internet access.
- · Country dependent: data volume via Mercedes me connect is available.

If the data volume limit is reached, the availability of Mercedes me connect services is limited. The data volume must be purchased via Mercedes me connect.

Contact an authorized Mercedes-Benz Center to find out whether it is possible to purchase data volume in your country.

#### **Establishing an Internet connection** Multimedia system:

¬→ Connect

For example, select (\$) Browser.

- i The multimedia system usually establishes the Internet connection automatically. If the multimedia system is not connected to the Internet, the Internet connection is established when an Internet application is used.
- (i) The availability of web browsers is country-dependent.

#### **Connection status**

#### Connection status overview



Display of existing connection

# **Displaying the connection status** Multimedia system:

- Select Internet Status.
- i In the case of a connection via the communication module the following status information is shown:
  - Type of network
  - Status online/offline

### **Mercedes-Benz Apps**

### Calling up Mercedes-Benz Apps

#### Requirements:

- The registration for the use of Mercedes-Benz Apps has been completed.
- The general terms and conditions have been confirmed.

#### Multimedia system:

→ Connect → Mercedes-Benz Apps

Select an app.

an app.

The available features are country-dependent.
 License fees may be applicable.

# Operating Mercedes-Benz Apps using voice control

#### Requirements:

- The registration for the use of Mercedes-Benz Apps has been completed.
- The general terms and conditions have been confirmed.

The symbol indicates that a Mercedes-Benz app can be used via voice control.

- Select a Mercedes-Benz app. The app menu is displayed.
- ► To use voice control: select ♣ Language.
- Say the question or command.
- (i) Voice control is not available in all countries and languages.

#### Web browser

#### Calling up a web page

WARNING Risk of distraction from information systems and communications equipment

If you operate information and communication equipment integrated in the vehicle when driving, you will be distracted from the traffic situation. This could also cause you to lose control of the vehicle

- Only operate this equipment when the traffic situation permits.
- If you cannot be sure of this, stop the vehicle whilst paying attention to road and traffic conditions and operate the equipment with the vehicle stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the multimedia system.

#### Multimedia system:

- → Connect → Browser
- **▶** Enter URL
- Enter a web address.
- The function is country-dependent.
- To finish the entry and call up the website: select ok .

Showing/hiding the web browser menu If you call up a website by selecting a link, for example, the web browser menu is hidden.

- **To show/hide:** press the **□** button.
- The web browser supports video playback.
- No websites or videos are displayed while the vehicle is in motion.



#### Web browser overview



- **URL** entry
- Bookmarks
- Web page, back
- Web page, forwards
- Options
- Closes the browser

# Calling up web browser options

Multimedia system:

→ Connect → S Browser
→ Options

The following functions are available:

- Refresh Page/Cancel
- Zoom
- Browser Settings
- Delete Browser Data
- Select an option.
- Make the desired changes to the settings.

# Calling up the web browser settings

Multimedia system:

Connect ➤ Browser

→ Options ➤ Browser Settings

The following functions are available:

- Block Pop-Ups
- Activate Javascript
- Allow Cookies
- ▶ Activate or deactivate the function.

## Deleting browser data

Multimedia system:

→ Connect → Browser

▶ Options ► Delete Browser Data

The following options are available:

- All
- Cache
- Cookies
- Entered URLs
- Form Data
- Select an option.
- Select Yes.

# Managing bookmarks

Multimedia system:

→ Connect → Browser

**▶** Bookmarks

#### Selecting a bookmark

Select an entry.



### Creating a bookmark

- Select Add New Bookmark.
- Enter a URL and a name.
- Select ok.

## Editing a bookmark

- Highlight a bookmark.
- Select <a> .</a>
- Select Edit.
- Enter a URL and a name.
- Select ok.

## Deleting a bookmark

- Highlight a bookmark.
- Select <a>\_</a>
- Select Delete.
- Select Yes.

# Closing the browser

Multimedia system:

- → Connect → 🕟 Browser
- ➤ Select ← Close Browser.

#### Internet radio

#### Calling up Internet radio

#### Requirements:

- The Internet radio service is activated.
- The data volume is available.
  - Depending on the country, data volume may need to be purchased.
- · A fast Internet connection for data transmission free of interference.


The services are country-dependent.

For more information, consult an authorized Mercedes-Renz Center

#### Multimedia system:

- ¬→ Radio → 🗐 Radio Source
- Select TuneIn Radio. The Internet radio display appears. The last station set starts playing.
- The connection quality depends on the local mobile phone reception.

#### Internet radio overview



- Internet radio provider
- Selected category
- Display (if connected to private user account)
- Data transfer rate
- Current station is stored as a favorite
  - Additional information on the current station

#### DEALER EPROCESS

#### Selecting and connecting Internet radio stations

Multimedia system:

- Radio >> F Radio Source
- >> TuneIn Radio >> P Search
- Select a category.
- Select a station. The connection is established automatically.

or

- Select Enter Address or POL
- Enter a station name using the entry field.
- A relatively large volume of data can be transmitted when using Internet radio.

#### Saving/deleting an Internet radio station as a favorite

Multimedia system:

- ¬→ Radio → 🖠 Radio Source
- >> TuneIn Radio
- Select a station.

### 312 Multimedia system

Press and hold the central control element until an audible signal sounds.

The symbol appears by the station

The symbol appears by the station name.

Select Favorites.
The list of saved favorite stations appears.

or

 Create an account for the online provider (TuneIn radio) and then log in on the multimedia system.

Your favorites are imported to the multimedia system.

#### **Deleting favorites**

- ➤ Select ★ Favorites.
- Select a station.
- Press and hold the central control element until an audible signal sounds.

The symbol by the station name disappears.

# **Setting Internet radio options**

Multimedia system:

Radio ➤ Radio Source
Tuneln Radio ➤ Options

The following options are available:

- Select Stream: select the stream quality.
- Login to TuneIn Account: log in to your TuneIn user account.
- Log Out of Account: log out of your TuneIn user account.
- Select an option.

#### Media

#### Audio mode

#### Information on the audio mode

**WARNING** Risk of distraction when handling data storage media

If you handle a data storage medium while driving, your attention is diverted from the

DEALER ePROCESS

traffic conditions. This could also cause you to lose control of the vehicle.

Only handle a data storage medium when the vehicle is stationary.

#### Permissible file systems:

- FAT32
- exFAT
- NTFS

#### Permissible data storage medium:

- SD card
- USB storage device
- iPod<sup>®</sup>/iPhone<sup>®</sup>
- MTP devices
- Bluetooth<sup>®</sup> audio equipment
- i) Observe the following notes:
  - The multimedia system supports a total of up to 50,000 files.
  - Data storage media up to 2 TB are supported (32-bit address space).

#### Supported formats:

- MP3
- WMA
- AAC
- WAV
- FLAC
- ALAC
- (i) Observe the following notes:
  - Due to the large variety of available music files regarding encoders, sampling rates and data rates, playback cannot always be guaranteed.
  - Due to the wide range of USB devices available on the market, playback cannot be guaranteed for all USB devices.
  - Copy-protected music files or DRM encrypted files cannot be played back.
  - MP3 players must support Media Transfer Protocol (MTP).



Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories.





Gracenote, the Gracenote logo and logotype, "Powered by Gracenote", MusicID and Playlist Plus are either registered trademarks or trademarks of Gracenote, Inc. in the United States and/or other countries.

#### Notes on copyright

Audio files that you create or reproduce yourself for playback are generally subject to copyright protection. In many countries, reproductions, even for private use, are not permitted without the prior consent of the copyright holder. Make sure that you know about the applicable copyright regulations and that you comply with these.

# Activating media mode Multimedia system:

→ Media → Media Sources

Select a media source.
 Playable music files are played back.

### Inserting/removing an SD card

**DANGER** Risk of fatal injury from swallowing SD cards

SD cards are small parts.

They could be swallowed and lead to choking.

- Keep SD cards out of the reach of children.
- Seek medical attention immediately if an SD card has been swallowed.
- ! NOTE Damage due to high temperatures

High temperatures may damage the SD card.

Remove the SD card after use and take it out of the vehicle.

#### Multimedia system:

→ Media → Media Sources

Mem. Card

### Inserting

The multimedia connection unit is located in the stowage compartment under the armrest.


Insert the SD memory card into the SD card slot until it engages. The side with the contacts must face downwards. Playable music files are played back.

#### Removing

- Press the SD card.
- Remove the SD card.



#### Overview of the audio mode



- Active data storage medium
- Album cover
- Track, artist, album
- Track number and number of tracks in the track list

- Search
- Playback Control
- Media Sources
- Sound

- Full Screen (for video playback)
- Options



#### Connecting USB devices

NOTE Damage caused by high temperatures

High temperatures can damage USB devices.

Remove the USB device after use and take it out of the vehicle.

The multimedia connection unit is found in the stowage compartment under the armrest and has two USB ports.

Depending on the vehicle's equipment, additional USB ports can be found in the stowage compartment of the center console and in the rear passenger compartment.

- Connect the USB device to the USB port. Playable music files are played back only if the corresponding media display is activated.
- i Use the USB port identified by □ to use Apple CarPlay™ and Android Auto.
- (i) Depending on the vehicle equipment there is an additional USB port in the rear passenger compartment. Ports that are labeled with a

battery symbol can only be used to charge USB devices.

Selecting a track in the media playback Multimedia system:

**¬→** Media

Selecting a track by skipping to a track

To skip backwards or forwards to a track: navigate up or down.

### Selecting a track using the current track list

- Select [>.
- Select Current Track List.
- Select a track.

# **Selecting playback options** Multimedia system:

→ Media → Options

#### Playing back similar tracks

Select Play Similar Tracks.
A track list with similar tracks is created and played back.

DEALER ePROCESS

#### Playback mode

- Select Random Mode Current Playlist.
   The current track list is played in random order.
- Select Random Mode Current Medium.
   All tracks on the active data storage medium are played in random order.
- Select Normal Track Sequence. The current track list is played in the order it appears on the data storage medium.

# Controlling media playback

Multimedia system:

→ Media → Playback Control

A bar with playback controls is shown.

- ➤ To pause playback: select and confirm

  ➤ II with the central control element.

  The II symbol is displayed.
- To resume playback: select and confirm
  again with the central control element.
  The symbol is displayed.

### To fast forward/rewind

Move II on the timeline.

#### To hide the playback controls

▶ Press the button.

#### Video mode

# Switching to video mode

Multimedia system:

- → Media **>>** Media Sources
- Select a data storage medium.
- Search for and select video files or playlists with video files. Playable video files are played back.

The multimedia system supports the following formats:

- MPEG
- AVI. DivX. MKV
- MP4, M4V
- WMV
- (i) If the vehicle is traveling faster than 3 mph (5 km/h) the video image is hidden from the driver. If available, the channel and program information is continuously displayed. Due to the large variety of available video files regarding encoders, sampling rates and data transfer rates, playback cannot be guaranteed.

Videos up to FullHD (1920x1080) are supported.

Copy-protected video files or DRM (Digital Rights Management) encrypted files cannot be played back.



#### Overview of video mode



- Active data storage medium
- Album cover
- 3 Track, artist, album
- Track number and number of tracks in the track list

- Search
- O Playback Control
- Media Sources
- Sound

- Full Screen (for video playback)
- Options



# Activating/deactivating full-screen mode Multimedia system:

→ Media → Media Sources

Select a data storage medium.
Playable video files are played back.

To activate full-screen mode: select 
Full Screen.

To deactivate full-screen mode: press the touchpad.

# Changing video settings

Multimedia system:

→ Media → Options

>> Picture Format

The following picture formats are available:

- Automatic
- 16:9
- 4:3
- Zoom
- Select a picture format.

### Adjusting the brightness manually

If the Automatic picture format is switched off, you can adjust the brightness yourself.

- Select Brightness.
- Adjust the brightness.

#### Media search

# Starting the media search

Multimedia system:

→ Media **>>** 🔎 Search

Depending on the connected media sources and files, the following categories are listed:

- Current Track List
- Keyword Search
- Playlists
- Artists
- Albums
- Tracks
- FoldersMusic GenresYear

- Composers
- Videos
- Podcasts (Apple<sup>®</sup> devices)
- Audiobooks (Apple<sup>®</sup> devices)
- Select a category.
- The categories are available as soon as the entire media content has been read in and analyzed.

#### **Media Interface**

#### Information about the Media Interface

Media Interface is a universal interface for the connection of mobile audio equipment. The multimedia system has two USB ports. The USB ports are located in the stowage compartment under the armrest.

### Supported devices

The Media Interface allows you to connect the following data storage media:

- iPod<sup>®</sup>
- iPhone<sup>®</sup>

### 320 Multimedia system

- MP3 player
- USB devices

For details and a list of supported devices, visit our website at http://www.mercedes-benz.com/connect. Follow the instructions in the "Media Interface" section.

# **Switching to Media Interface** Multimedia system:

→ Media → Media Sources

- Connect a data storage medium to the USB port ( page 316).
- Select a media device.
  Playable music files are played back.



#### Overview of Media Interface



- Active data storage medium
- Album cover
- Artist, track and album
- Track number and number of tracks in the track list

- Search
- Playback Control
- Media Sources
- Sound

- Full Screen (video playback only)
- Options



## Bluetooth® audio

Information about Bluetooth® audio

Before using your Bluetooth<sup>®</sup> audio equipment with the multimedia system for the first time, you will need to authorize it (—>> page 323).

#### Bluetooth® audio overview



- Active data storage medium
- 2 Album cover

3 Track, artist, album



Track number and number of tracks in the track list

- Search
- Playback Control

### Searching for and authorizing a Bluetooth® audio device

#### Requirements:

- Bluetooth® is activated on the multimedia system and audio equipment  $\longrightarrow$  page 248).
- The audio equipment supports the Bluetooth® audio profiles A2DP and AVRCP.
- The audio equipment is "visible" for other devices.

### Multimedia system:

- → Media → Media Sources
- ▶ Bluetooth Audio

# Authorizing a new Bluetooth® audio device

- Select 🖳.
- Select Add New Bluetooth Audio Device.

- Media Sources
- Sound
- Select Start Search on System. Detected audio equipment is displayed in the device list
- Select a Bluetooth® audio device. Authorization starts. A code is displayed on the multimedia system and on the mobile phone.
- If the codes are identical, confirm on the audio equipment. The audio equipment is connected and playback starts.

### Selecting previously authorized Bluetooth® audio equipment

- Select 🖳.
- Select a Bluetooth® audio device.

# Establishing a connection from the Bluetooth® audio equipment

The Bluetooth® device name of the multimedia system is MB BLUETOOTH XXXXX.

DEALER ePROCESS

- Full Screen (video playback only)
- Options
- Select Search from Device
- Start the authorization on the audio equipment (see manufacturer's operating instructions).
- A code is displayed on the multimedia system and on the audio device.
- Confirm on both devices if the codes are identical.
  - The audio equipment is connected and playback starts.

With some audio equipment, playback must be initially started on the device itself so that the multimedia system can play the audio files.

Device-specific information on authorizing and connecting Bluetooth®-capable mobile phones can be obtained at http:// www.mercedes-benz.com/connect or from an authorized Mercedes-Benz Center.

# Activating Bluetooth® audio

Multimedia system:

→ Media → Media Sources

➤ Select ■ Bluetooth Audio.

The multimedia system activates the connected Bluetooth® audio equipment.

# Selecting the media player on the Bluetooth® audio device

Multimedia system:

→ Media → 🔎

- Select the Bluetooth Audio Players category. If multiple media players are present on the Bluetooth® audio equipment a list appears.
- Select a media player. Playback starts.
- i The function is not supported by every mobile phone.

# Searching for a music track on the Bluetooth® audio device

Multimedia system:

→ Media **>>** Media Sources

**▶** ■ Bluetooth Audio

- Select 🔎 .
- Select a category.A track list appears.
- Select a track.
- The function is only available when the mobile phone and the media player selected on the mobile phone support this function.

# Switching Bluetooth® audio equipment via NFC

### Requirements:

- Observe the notes on using NFC ( page 290).
- The Bluetooth<sup>®</sup> audio overview is displayed ( page 322).



 Lightly press the NFC area on the mobile phone (see the manufacturer's operating instructions).

If the mobile phone has already been authorized on the multimedia system as Bluetooth® audio equipment, it is now connected.

If the mobile phone is authorized on the multimedia system as Bluetooth® audio equipment for the first time, it is connected after confirming the instructions for the mobile phone (see the manufacturer's operating instructions).

# **Disconnecting Bluetooth**® audio equipment Multimedia system:

→ Phone → Media Sources

Select the symbol in the line of the mobile phone.

The disconnection of the mobile phone takes place without a confirmation prompt. The mobile phone remains authorized in the system.

#### Radio

# Switching on the radio

# Multimedia system:

**¬→** Radio

► Alternatively: press the RADIO button. The radio display appears. You will hear the last station played on the last frequency band selected.



#### Radio overview



- Active frequency band
- Station name or set frequency
- 3 Artist, title, album and radio text

- Station list
- O Presets
- Radio Source

- Sound
- Options



# Switching the HD Radio function on/off

Multimedia system:

¬→ Radio → Options → HD Radio



- Switch the function on  $\mathbf{\nabla}$  or off  $\square$ .
- HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.

### Setting the waveband

Multimedia system:

Radio Radio Source

HD Radio FM HD Radio AM and SiriusXM Radio can be selected.

Select a frequency band.

# Selecting a radio station

Multimedia system:

¬→ Radio

Navigate up or down.

# Calling up the radio station list

Multimedia system:

¬→ Radio → P

Select a station.



# Searching for radio stations using station names or direct frequency entry

Multimedia system:

¬→ Radio → P → P

- Enter a station name or frequency.
- Select OK. The search results are displayed.
- Select a station.

# Storing radio stations

Multimedia system:

¬→ Radio → Presets

Select Store Current Station in the Presets.

# **Editing radio station presets**

Multimedia system:

¬→ Radio → Presets

# Moving stations:

Highlight a preset entry and navigate to the left.

- Select Move Highlighted Station.
- Select a memory preset.

### **Deleting stations:**

- Highlight a preset entry and navigate to the left.
- Select Delete Highlighted Station.
- Select Yes.

# **Tagging music tracks**

Multimedia system:

#### ¬→ Radio

If radio stations provide the relevant information, this function allows you to transfer information on the music track currently playing to an Apple<sup>®</sup> device. You can then purchase the audio file from the iTunes Store<sup>®</sup>.

- ► Select  $\mathfrak{D} \rightarrow \mathsf{Tag} \; \mathsf{This} \; \mathsf{Song}.$ 
  - The track information is saved.

# Activating/deactivating radio text

Multimedia system:

- Radio Pige Options
  Display Radio Text Information
- ► Activate ✓ or deactivate ☐ the function.

#### Satellite radio

#### Information on the satellite radio

SIRIUS XM® satellite radio offers more than 175 digital-quality radio channels providing 100% commercial-free music, sports, news and entertainment, for example. SIRIUS XM satellite radio employs a fleet of high-performance satellites to broadcast around the clock throughout the USA and Canada. The satellite radio program is available for a monthly fee. Information about this can be obtained from a Sirius XM® Service Center and at http://www.siriusxm.com (USA) or http://www.siriusxm.ca (Canada).

 Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. and its subsidiaries. All other marks, channel

DEALER SPROCESS

names and logos are the property of their respective owners. All rights reserved.

#### Satellite radio restrictions

Satellite radio mode may be temporarily unavailable or interrupted for a variety of reasons. These include environmental or topographical conditions beyond the control of Mercedes-Benz USA, LLC. Thus, operation at certain locations may not be possible.

# Registering satellite radio

#### Requirements:

- Satellite radio equipment
- Registration with a satellite radio provider
- If registration is not included when purchasing the system, your credit card details will be required to activate your account

# Multimedia system:

- ¬→ Radio → † Radio Source
- ➤ SiriusXM Radio ➤ Options
- Select Service Information.

The service information screen appears showing the radio ID and the current subscription status.

- Establish a telephone connection.
- Follow the service staff's instructions. The activation process may take up to ten minutes.
- (i) You can also have the satellite service activated online. To do so, please visit http://

www.siriusxm.com (USA) or http:// www.siriusxm.ca (Canada).

### Switching on satellite radio Multimedia system:

- Radio >> | Radio Source
- Select SiriusXM Radio.



#### Overview of the satellite radio



- Active frequency band
- 2 Logo or album art (if available)
- 3 Category
- Channel name

- Artist, track and album
- SiriusXM Radio Channels
- Presets
- Radio Source

- Sound
- Playback Control
- Options



# Selecting a satellite radio category Multimedia system:

¬→ Radio → 🕴 Radio Source

- SiriusXM Radio
- Select a category.

# Selecting a satellite radio channel Multimedia system:

- ¬→ Radio → † Radio Source
- SiriusXM Radio
- Navigate up or down.

# Saving or deleting a satellite radio channel Multimedia system:

- Radio Source ¬→ Radio → †
- SiriusXM Radio → Presets
- Select Store Current Station in the Presets.

# Moving a channel

- Select Options.
- Select Move Highlighted Station.
- Select a memory preset.

### Deleting a channel

- Select Delete Highlighted Station.
- Select a memory preset.

### Displaying EPG information for the current channel

Multimedia system:

- Radio Radio Source
- ➤ SiriusXM Radio ➤ Options
- Select EPG Information about Current Channel.

#### Setting parental control for radio Multimedia system:

→ Radio → Radio Source

- ➤ SiriusXM Radio ➤ Options
- >> Parental Control
- Activate the function  $\mathbf{\nabla}$ .
- Determine a four-digit character sequence and select ok.

All channels with adult content are locked.



#### Unlocking a channel

- Enter the four-digit character sequence and select ok.
  - All channels with adult content are unlocked.

# Music and sport alerts function

This function enables you to program an alert for your favorite artists, tracks or sporting events. Music alerts can be saved whilst a track is being played and sport alerts can be saved during a live game. You can also specify sport alerts via the menu option. The system then continuously searches through all the channels. If a match is found with a stored alert, you will be informed.

# Setting music and sport alerts

Multimedia system:

- ¬→ Radio → † Radio Source
- ➤ SiriusXM Radio ➤ Options
- ➤ Alert for Artist, Song & Sporting Event

### Setting a music alert

Select Add New Alert.

or

Select Manage Artist & Song Alerts.

Select Options.

The following options are available:

- Mark This Entry
- Unmark This Entry
- Mark All Entries
- Unmark All Entries
- Delete This Entry
- Delete All Entries
- Select an option.
- ▶ Activate Artist & Song Alerts <a>✓</a>.

The alert is set for the current artist or track. If a match is found, a prompt appears asking whether you wish to change to the station.

# Setting a sport alert

Select Add New Alert.

or

- Select Manage Sports Alerts.
- Select Select New Alerts.

01

- Select Edit Alerts.
- Select a team from a league.

▶ Activate Sports Alerts <a>✓</a>.

# Information on Smart Favorites and Tune Start

Stations in the station presets can be added as Smart Favorites. Smart Favorites stations are automatically saved to temporary storage in the background. If you change to a Smart Favorites station, you can replay, pause or actively skip forward or back to broadcasts which you have missed. If Tune Start is activated and you change to another Smart Favorites station, the music track currently playing on the station is automatically restarted from the beginning of the track.

# **Adding a channel to Smart Favorites** Multimedia system:

Radio Nadio Source

- >> SiriusXM Radio
- Select the active frequency band.
- Highlight an entry.
- ➤ Select 🖃.
- Select Add Highlighted Channel to Smart Favorites.

DEALER ePROCESS

# Activating/deactivating TuneStart Multimedia system:

→ Radio → Options → TuneStart

➤ Activate 🗹 or deactivate 🗌 the function.

# Controlling playback

Multimedia system:

¬→ Radio → Playback Control

You can pause the playback of the current station or skip forward or backward in the timeline. This leaves live mode to access the internal temporary storage.

- To fast forward/rewind: turn the controller counter-clockwise or clockwise/swipe left or right on the touchpad.
- ➤ To jump to the previous/next song: press the controller left or right/swipe left or right on the touchpad.
- To pause playback: select II.
- ➤ To return to live mode: navigate to the end of the timeline.

# Displaying satellite radio service information Multimedia system:

- Radio >> | Radio Source ➤ SiriusXM Radio ➤ Options
- Select Service Information.

#### Sound

### Tone settings

### Information about the sound system

The sound system has a total output of 100 W and is equipped with 10 speakers. It is available for all functions in the radio and media modes.

# Calling up the sound menu

Multimedia system:

→ Media → J Sound

The following functions are available:

- Equalizer
- Balance and Fader
- Automatic Volume Adjustment
- Other Sound Settings

Select a sound menu.

# Adjusting treble, mid-range and bass settings

Multimedia system:

- → Media → Sound → Equalizer
- Select Treble, Mid Range or Bass.
- Change the settings.

### Activating/deactivating automatic volume adiustment

Multimedia system:

- → Media → J Sound
- ➤ Automatic Volume Adjustment

Automatic volume adjustment compensates for differing volumes when changing between audio sources.

▶ Activate or deactivate the function.

# Adjusting the balance/fader

Multimedia system:

- → Media >> \ \\_\_ Sound
- → Balance and Fader
- Adjust the balance and fader.

DEALER ePROCESS

► To exit the menu: press the 🛨 button.

# Burmester® surround sound system

# Information about the Burmester® surround sound system

The Burmester® surround sound system has a total output of 590 W and is equipped with 13 speakers. It is available for all functions in the radio and media modes.

# Calling up the sound menu in the Burmester® surround sound system Multimedia system:

→ Media → Sound

The following functions are available:

- Equalizer
- Balance and Fader
- Automatic Volume Adjustment
- Surround Sound
- Sound Focus
- Other Sound Settings
- Select a function.

Adjusting the treble, mid and bass settings on the Burmester® surround sound system Multimedia system:

- → Media → J Sound → Equalizer
- ► Select Treble, Mid Range or Bass.
- Set the desired values.

Activating/deactivating volume adjustment in the Burmester® surround sound system Multimedia system:

- → Media → \ Sound
- ➤ Automatic Volume Adjustment

Automatic volume adjustment compensates for differing volumes when changing between audio sources.

▶ Activate or deactivate the function.

Adjusting the balance/fader in the Burmester® surround sound system Multimedia system:

- → Media → J Sound
- Balance and Fader
- Adjust the balance and fader.

▶ To exit the menu: press the 🛨 button.

Switching surround sound on/off in the Burmester® surround sound system Multimedia system:

- → Media → Sound
- >> Surround Sound
- ► Activate ✓ or deactivate ☐ the function.

Adjusting the sound focus in the Burmester  $^{\footnotesize @}$  surround sound system

Multimedia system:

- → Media → 「 Sound → Sound Focus
- Adjust the sound focus.

Burmester® high-end 3D surround sound system

Information on the Burmester  $^{\tiny{\circledR}}$  high-end 3D surround sound system

The Burmester® high-end 3D surround sound system has a total output of 1560 watts and is equipped with 25 speakers. It is available for all functions in the radio and media modes.

DEALER EPROCESS

Calling up the sound menu in the Burmester® high-end 3D surround sound system

Multimedia system:

→ Media → 「」 Sound

The following functions are available:

- Equalizer
- · Balance and Fader
- Automatic Volume Adjustment
- VIP Seat (seat-based sound optimization)
- Sound Profiles
- · Other Sound Settings
- Select a sound menu.

Adjusting the treble, mid-range and bass settings on the Burmester® high-end 3D surround sound system

Multimedia system:

→ Media → Sound → Equalizer

- Select Treble, Mid Range or Bass.
- Set the desired values.

# Activating/deactivating volume adjustment in the Burmester® high-end 3D surround sound system

Multimedia system:

→ Media → Sound

➤ Automatic Volume Adjustment

Automatic volume adjustment compensates for differing volumes when changing between audio sources.

▶ Activate or deactivate the function.

# Adjusting the balance/fader in the Burmester® high-end 3D surround sound system

Multimedia system:

- → Media → 「」 Sound
- Balance and Fader
- Adjust the balance and fader.
- **To exit the menu:** press the \_\_\_\_ button.

# Adjusting the seat-based sound optimization in the Burmester® high-end 3D surround sound system

Multimedia system:

→ Media → I Sound → VIP Seat

This setting optimizes the sound playback for the selected seat position.

- Activate the function  $\mathbf{\nabla}$ .
- Select a seat position.

Selecting the sound profile in the Burmester® high-end 3D surround sound system

Multimedia system:

→ Media → Sound → Sound Profiles

The following profiles are available:

- Pure
- Easy Listening
- Live
- Surround
- 3D-Sound
- Select a sound profile



# **ASSYST PLUS** service interval display

# Function of the ASSYST PLUS service interval display

The ASSYST PLUS service interval display on the Instrument Display provides information on the remaining time or distance before the next service due date.

You can hide this service message using the back button on the left-hand side of the steering wheel.

Depending on how the vehicle is used, the ASSYST PLUS service interval display may shorten the service interval, e.g. in the following cases:

- Mainly short-distance driving
- · When the engine is often left idling for long periods
- In the event of frequent cold start phases

Mercedes-Benz recommends avoiding such operating conditions.

You can obtain further information concerning the servicing of your vehicle from a qualified

specialist workshop, e.g. an authorized Mercedes-Benz Center.

# Displaying the service due date

On-board computer:

¬→ Service → ASSYST PLUS

The next service due date is displayed.

To exit the display: press the back button on the left-hand side of the steering wheel.

Make sure to observe the following further related subject:

· Operating the on-board computer  $(\longrightarrow)$  page 211).

# Information on regular maintenance work

**NOTE** Premature wear through failure to observe service due dates

Service work which is not carried out at the right time or incompletely can lead to increased wear and damage to the vehicle.



- Always observe the prescribed service intervals.
- Always have the prescribed service work carried out at a qualified specialist workshop.

# Special service requirements

The prescribed service interval is based on normal operation of the vehicle. Maintenance work will need to be performed more often if the vehicle is operated under arduous conditions or increased loads.

The ASSYST PLUS service interval display is only an aid. The driver of the vehicle bears responsibility as regards to whether maintenance work needs to be performed more often than specified based on the actual operating conditions and/or loads.

Examples of arduous operating conditions:

- regular city driving with frequent intermediate stops
- mainly short-distance driving

- frequent operation in mountainous terrain or on poor road surfaces
- when the engine is often left idling for long periods
- operation in particularly dusty conditions and/or if air-recirculation mode is frequently used

In these or similar operating conditions, have the interior air filter, engine air cleaner, engine oil and oil filter etc. changed more frequently. The tires must be checked more frequently if the vehicle is operated under increased loads. Further information can be obtained at a qualified specialist workshop.

# **Battery disconnection periods**

The ASSYST PLUS service interval display can only calculate the service due date when the battery is connected.

Note down the service due date displayed on the instrument display before disconnecting the battery ( $\longrightarrow$  page 336).

# **Engine compartment**

Active hood (pedestrian protection)

#### Operation of the active hood (pedestrian protection)

In certain accident situations, the risk of injury to pedestrians can be reduced by the actuation of the active hood. The rear area of the hood is raised by approximately 80 mm.

For the drive to the workshop, reset the triggered active hood yourself. After the active hood has been triggered, pedestrian protection may be limited.

A qualified specialist workshop must re-instate the full functionality of the active hood.

The active hood is not available in all countries.


### Resetting the active hood

WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

DEALER ePROCESS

Allow the engine to cool down and only touch component parts described in the following.



- With your hand flat, push down active hood 1 in the area around the hinges on both sides (arrows).
  - The hood must engage in position.
- If the active hood can be raised slightly at the rear in the area of the hinges, repeat the step until it engages correctly.

# Opening/closing the hood

WARNING Risk of accident if the engine hood is unlatched while driving

An unlocked engine hood may open up when the vehicle is in motion and block your view.

- Never unlatch the engine hood while driving.
- Before every trip, ensure that the engine hood is latched.

WARNING Risk of accident and injury when opening and closing the engine hood

When opening or closing the engine hood, it may suddenly drop into the end position.

There is a risk of injury for anyone in the engine hood's range of movement.

Only open or close the engine hood when there are no persons in the engine hood's range of movement.

WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

# WARNING Risk of injury due to moving parts

Certain components in the engine compartment may continue to move or suddenly move again even after the ignition has been switched off, e.g. the cooler fan.

Make sure of the following before performing tasks in the engine compartment:

Switch the ignition off.

- Never touch the danger zone surrounding moving component parts, e.g. the rotation area of the fan.
- Remove jewelry and watches.
- Keep items of clothing and hair away from moving parts.

# WARNING Risk of injury from touching component parts under voltage

The ignition system and the fuel injection system work under high voltage. If you touch component parts which are under voltage, you could receive an electric shock.

Never touch component parts of the ignition system or the fuel injection system when the ignition is switched on.

# WARNING Risk of burns from hot component parts in the engine compartment


Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.




- Allow the engine to cool down and only touch component parts described in the following.
- WARNING Risk of injury from using the windshield wipers while the engine hood is open

When the engine hood is open and the windshield wipers are set in motion, you can be trapped by the wiper linkage.

Always switch off the windshield wipers and ignition before opening the engine hood.



To open: pull lever 1 to release the hood.



- Push handle (1) of the hood catch upwards and lift the hood by approximately 15 in (40 cm).
- To close: lower the hood and let it fall from a height of approximately 8 in (20 cm).
- If the hood can still be lifted slightly, open the hood again and close it with a little more force until it engages correctly.



### **Engine oil**

# Checking the engine oil level with an onboard computer

### Requirements:

The engine oil level is determined during driving. Determining the engine oil level can take up to 30 minutes with a normal driving style and even longer with an active driving style.

In order to receive a result as quickly as possible:

- · Warm up the engine.
- Park the vehicle on a level surface.
- Leave the engine running at idle speed.

### On-board computer:

→ Service → Engine Oil Level

# You will see one of the following messages in the multifunction display:

Measuring Engine Oil Level...: measurement of the oil level is not yet possible. Repeat the request after a maximum of 30 minutes' driving.

- Engine Oil Level OK and the bar display for indicating the oil level in the multifunction display is green and is between "min" and "max": the oil level is correct
- Engine Oil Level Add 1.0 I and the bar display for indicating the oil level in the multifunction display is orange and is below "min": add 1.1 US at (1 liter) of engine oil.
- Reduce Engine Oil Level and the bar display for indicating the oil level in the multifunction display is orange and is above "max": drain off the excess engine oil. Consult a qualified specialist workshop.
- For Engine Oil Level Switch Ignition On: switch on the ignition to check the engine oil level.
- Engine Oil Level System Inoperative: sensor defective or not inserted. Consult a qualified specialist workshop.
- Engine Oil Level System Currently Unavail.: close the hood.



# Adding engine oil

WARNING Risk of burns from hot component parts in the engine compartment

Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.

WARNING Risk of fire and injury from engine oil

If engine oil comes into contact with hot component parts in the engine compartment, it may ignite.

- Make sure that no engine oil is spilled next to the filler opening.
- Allow the engine to cool off and thoroughly clean the engine oil from component parts before starting the vehicle.

- **NOTE** Engine damage caused by an incorrect oil filter, incorrect oil or additives
- ▶ Do not use engine oils or oil filters which do not correspond to the specifications explicitly prescribed for the service intervals.
- Do not alter the engine oil or oil filter in order to achieve longer change intervals than prescribed.
- Do not use additives.
- Follow the instructions in the service interval display regarding the oil change.
- **NOTE** Damage caused by adding too much engine oil

Too much engine oil can damage the engine or the catalytic converter.

Have excess engine oil removed at a qualified specialist workshop.



- Turn cap ① counter-clockwise and remove it.
- Add engine oil.
- Replace cap 1 and turn it clockwise as far as it will go.
- Check the oil level again.



### Checking coolant level

WARNING Risk of burns from hot component parts in the engine compartment


Certain components in the engine compartment can be very hot, e.g. the engine, the radiator and parts of the exhaust system.

Allow the engine to cool down and only touch component parts described in the following.

**WARNING** Risk of scalding from hot coolant

The engine cooling system is pressurized, particularly when the engine is warm. If you open the cap, you could be scalded by hot coolant spraying out.

- Let the engine cool down before opening the cap.
- When opening the cap, wear protective gloves and safety glasses.
- Open the cap slowly to release pressure.



- Park the vehicle on a level surface.
- Check the coolant temperature display in the instrument cluster.
  - The coolant temperature must be below 158 °F (70 °C).
- If necessary, remove the cover.
- ➤ Slowly turn cap ① counter-clockwise to relieve overpressure.

Continue turning cap (1) counter-clockwise and remove it.

The coolant level is correct:

- If the engine is cold, up to marker bar ②.
- If the engine is warm, up to 0.6 in (1.5 cm) over marker bar ②.
- If necessary, add coolant that has been approved by Mercedes-Benz.
- Further information on coolant: (→> page 412)

# Adding washer fluid to the windshield washer system

**WARNING** Risk of burns from hot component parts in the engine compartment

Certain component parts in the engine compartment can be very hot, e.g. the engine, the cooler and parts of the exhaust system.

 Let the engine cool down and only touch the component parts described as follows.

# **WARNING** Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.

# WARNING - Risk of fire and injury from windshield washer concentrate

Windshield washer concentrate is highly flammable. It could ignite if it comes into contact with hot engine component parts or the exhaust system.

Make sure that no windshield washer concentrate spills out next to the filler opening.





- Remove cap 1 by the tab, place on the edge of the filler opening and engage in place.
- Add washer fluid.

# Keeping the air-water duct free

Keep the area between the hood and the windshield free of deposits, e.g. ice, snow and leaves.

### Cleaning and care

Notes on washing the vehicle in a car wash

WARNING Risk of accident due to reduced braking effect after washing the vehicle

The braking effect is reduced after washing the vehicle.

- After the vehicle has been washed. brake carefully while paying attention to the traffic conditions until the braking effect has been fully restored.
- NOTE Damage due to unsuitable car wash
- Before driving into a car wash make sure that the car wash is suitable for the vehicle dimensions.
- Ensure there is sufficient ground clearance between the underbody and the guide rails of the car wash.

DEALER EPROCESS

Ensure that the clearance width of the car wash, in particular the width of the guide rails, is sufficient.

To avoid damage to your vehicle when using a car wash, ensure the following beforehand:

- Active Distance Assist DISTRONIC and the HOLD function are deactivated.
- the 360° Camera or the rear view camera is switched off.
- · the side windows and sliding sunroof are completely closed.
- the blower for the ventilation/heating is switched off.
- the windshield wiper switch is in position **0**.
- in car washes with a conveyor system: neutral **N** is engaged.
- the SmartKey is at a distance of at least 10 ft (3 m) away from the vehicle, otherwise the trunk lid could open unintentionally.

- i If you would like to leave the vehicle while it is being washed, make sure the SmartKey is located in the vehicle. The P gear is otherwise automatically engaged.
- i) If, after the car wash, you remove the wax from the windshield and wiper rubbers, this will prevent smearing and reduce wiper noise.

# Information on using a power washer

WARNING Risk of accident when using high-pressure cleaning equipment with round-spray nozzles

The water jet from a round-spray nozzle (dirt grinder) may cause damage to tires and suspension components that is not visible.

Components damaged in this way may fail unexpectedly.

Do not use high-pressure cleaning equipment with round-spray nozzles to clean your vehicle. Damaged tires or suspension components must be replaced immediately.

To avoid damage to your vehicle, observe the following when using a power washer:

- keep the SmartKey at least 10 ft (3 m) away from the vehicle. Otherwise the trunk lid could open unintentionally.
- maintain a distance of at least 11.8 in (30 cm) to the vehicle.
- vehicles with decorative foil: parts of your vehicle are covered with a decorative foil. Maintain a distance of at least 27.6 in (70 cm) between the foil-covered parts of the vehicle and the nozzle of the power washer. Move the power washer nozzle around whilst cleaning. The water temperature of the power washer must not exceed 140 °F (60 °C).
- observe the information on the correct distance in the equipment manufacturer's operating instructions.

DEALER ePROCESS

 do not point the nozzle of the power washer directly at sensitive parts such as tires, slits, electrical components, batteries, light bulbs and ventilation slots.

# Washing the vehicle by hand

Observe the legal requirements, e.g. in a number of countries, washing by hand is only permitted in specially designated wash bays.

- ▶ Use a mild cleaning agent, e.g. car shampoo.
- Wash the vehicle with lukewarm water using a soft car sponge. When doing so, do not expose the vehicle to direct sunlight.
- Carefully hose the vehicle off with water and dry using a chamois. Take care not to point the water jet directly towards the air inlet grille.

# Notes on paintwork/matte finish paintwork care

# Observe the following information:

	Cleaning and care	Avoiding paintwork damage
Paintwork	<ul> <li>Insect remains: soak with insect remover and rinse off the treated areas afterwards.</li> <li>Bird droppings: soak with water and rinse off afterwards.</li> <li>Tree resin, oils, fuels and greases: remove by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.</li> <li>Coolant and brake fluid: remove with a damp cloth and clean water.</li> <li>Tar stains: use tar remover.</li> <li>Wax: use silicone remover.</li> </ul>	<ul> <li>Do not attach stickers, films or similar.</li> <li>Remove dirt immediately, where possible.</li> </ul>



	Cleaning and care	Avoiding paintwork damage
Matte finish	Only use care products approved for Mercedes-Benz.	<ul> <li>Do not polish the vehicle and alloy wheels.</li> <li>Only use car washes that correspond to the latest engineering standards.</li> <li>Do not use car wash programs with a final hot wax treatment.</li> <li>Do not use paint cleaners, buffing or polishing products, gloss preservers, e.g. wax.</li> <li>Always have paintwork repairs carried out at a qualified specialist workshop.</li> </ul>

# Notes on cleaning decorative foils

Observe the notes on matte finish care in the chapter "Notes on paintwork/matte finish paint-

work care" ( page 345). They also apply to matte decorative foils.



### Observe the following information:

# Cleaning

- For cleaning, use plenty of water and a mild cleaning agent without additives or abrasive substances, e.g. a car shampoo approved for Mercedes-Benz
- Remove dirt immediately, where possible, whilst avoiding rubbing too hard. There is otherwise a risk of damaging the decorative foil irreparably.
- If there is dirt on the finish or if the decorative foil is dull: use the Paint Cleaner recommended and approved for Mercedes-Benz.
- Insect remains; soak with insect remover and rinse off the treated areas afterwards.
- Bird droppings: soak with water and rinse off afterwards.
- To prevent water stains, dry a foil-wrapped vehicle with a soft, absorbent cloth after every car wash.

# Avoiding damage to the decorative foil

- The service life and color of decorative foils are impaired by:
  - sunlight
  - temperature, e.g. hot air blower
  - weather conditions
  - stone chippings and dirt
  - chemical cleaning agents
  - oily products
- Do not use polish on matte decorative foil. Polishing will have the effect of shining the foil-wrapped surface.
- Do not treat matte or structured decorative foils with wax. Permanent stains may occur.

Scratches, corrosive deposits, areas affected by corrosion and damage caused by incorrect care cannot always be completely repaired. In such cases, visit a qualified specialist workshop.

You can obtain more information on care and cleaning products from the manufacturer.

In the case of foil-wrapped surfaces, optical differences may occur between the surfaces that were not protected by a decorative foil after removing a decorative foil.

DEALER EPROCESS



Have work or repairs to decorative foils carried out at a qualified specialist workshop, e.g. in an authorized Mercedes-Benz Center.


# **Cleaning Night View Assist**

#### Camera behind the windshield


**NOTE** Damage to the camera lens when cleaning


If you clean the camera lens yourself or spray glass cleaner on the camera lens, you could damage the camera lens.

- When cleaning the field of vision of the driving systems, do not spray glass cleaner on the camera lens.
- If the camera lens is dirty, please contact a qualified specialist workshop.



- Fold down the camera cover by handle recess 1.
- Use a cloth to clean the windshield in front of the camera.





Camera lens (2) is cleaned at regular intervals by operating the windshield washer system.

Use clear water and a soft cloth to clean camera lens 2 when it is very dirty.



# Notes on care of vehicle parts

WARNING Risk of entrapment if the windshield wipers are switched on while the windshield is being cleaned

If the windshield wipers are set in motion while you are cleaning the windshield or wiper blades, you can be trapped by the wiper arm.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

WARNING Risk of burning from the tailpipe or tailpipe trim

The tailpipe and tailpipe trim can become very hot. If you come into contact with these car parts, you could burn yourself.

- Always be particularly careful when in the vicinity of the tailpipe and tailpipe trims and supervise children very closely when in this area.
- Before any contact, allow the car parts to cool down.

# Observe the following information:

	Notes on cleaning and care	Avoiding vehicle damage
Wheels/rims	Use water and acid-free wheel cleaners.	<ul> <li>Do not use acidic wheel cleaners to remove brake dust. This could damage wheel bolts and brake components.</li> <li>To avoid corrosion of the brake discs and brakepads, drive the vehicle for a few minutes after cleaning before parking it. The brake discs and brakepads warm up and dry out.</li> </ul>
Windows	Clean the windows on the inside and outside using a damp cloth and cleaning agents recommended by Mercedes-Benz.	Do not use dry cloths or abrasive or solvent-based cleaning agents to clean the inside of windows.
Wiper blades	Fold out the wiper blades and clean them using a damp cloth.	Do not clean the wiper blades too often.

DEALER ePROCESS

	Notes on cleaning and care	Avoiding vehicle damage
Exterior lighting	Clean the lenses with a wet sponge and mild cleaning agent, e.g. car shampoo.	Only use cleaning agents or cleaning cloths that are suitable for plastic lenses.
Sensors	Clean the sensors in the front and rear bumper and in the radiator grill with a soft cloth and car shampoo.	When using a power washer, maintain a minimum distance of 11.8 in (30 cm).
Rear view camera and 360° Camera	<ul> <li>Open the camera cover with the multimedia system (→ page 190).</li> <li>Use clean water and a soft cloth to clean the camera lens.</li> </ul>	Do not use a power washer.
Tailpipes	Clean with cleaning agents recommended by Mercedes-Benz, particularly in the winter and after washing the vehicle.	Do not use acidic cleaning agents.

# Notes on care of the interior

WARNING Risk of injury from plastic parts breaking off after the use of solvent-based care products

Care and cleaning products containing solvents can cause surfaces in the cockpit to become porous.

When the airbags are deployed, plastic parts may break away.

Do not use any care or cleaning products containing solvents to clean the cockpit.



**WARNING** Risk of injury or death from bleached seat belts

Bleaching or dyeing seat belts can severely weaken them.

This can, for example, cause seat belts to tear or fail in an accident.

Never bleach or dye seat belts.

# Observe the following information:

	Cleaning and care	Avoiding vehicle damage
Seat belts	Clean with lukewarm and soapy water.	<ul> <li>Do not use chemical cleaning agents.</li> <li>Do not dry seat belts by heating them to over 176 °F (80 °C) or exposing them to direct sunlight.</li> </ul>
Display	Clean the surface carefully with a microfiber cloth and a suitable display care product (TFT/LCD).	<ul><li>Switch off the display and let it cool down.</li><li>Do not use any other cleaning products.</li></ul>
Plastic trim	<ul> <li>Clean with a damp microfiber cloth.</li> <li>For heavy soiling: use care product recommended for Mercedes-Benz.</li> </ul>	<ul> <li>Do not attach stickers, films or similar materials.</li> <li>Do not allow cosmetics, insect repellent or sun cream to come in contact with the plastic trim.</li> </ul>
Real wood/trim inserts	<ul> <li>Clean with a microfiber cloth.</li> <li>Black piano-lacquer look: clean with a damp cloth and soapy water.</li> <li>For heavy soiling: use care product recommended for Mercedes-Benz.</li> </ul>	Do not use solvent-based cleaning agents, polishes or waxes.
Headliner	Clean with a brush or dry shampoo.	
Carpet	Use carpet and textile cleaning agents recommended for Mercedes-Benz.	

DEALER ePROCESS

	Cleaning and care	Avoiding vehicle damage
Genuine leather seat covers	<ul> <li>Clean with a damp cloth and then wipe with a dry cloth.</li> <li>Leather care: use leather care agents that have been recommended for Mercedes-Benz.</li> </ul>	<ul><li>Do not allow the leather to become too damp.</li><li>Do not use a microfiber cloth.</li></ul>
DINAMICA seat covers	Clean with a damp cloth.	Do not use a microfiber cloth.
Imitation leather seat covers	Clean with a damp cloth and 1% soapy water.	Do not use a microfiber cloth.
Cloth seat covers	Clean with a damp microfiber cloth and 1% soapy water and allow to dry.	




#### **Emergency**

#### Removing the safety vest

The safety vests are located in stowage spaces in the front door.



- Take the safety vest bag out of stowage space 1.
- Open the safety vest bag and pull out the safety vest.
- Safety vests can also be stored in the rear door stowage spaces.



- Maximum number of washes
- Maximum wash temperature
- Do not bleach
- Do not iron
- Do not tumble dry
- Do not dry clean
- This is a class 2 yest

The requirements defined by the legal standard are only fulfilled in the following cases:

- · if the safety vest is the correct size
- the safety vest is fully closed whilst being worn

Replace the safety vest in the following cases:

- the reflective strips are damaged or dirt on the reflective strips can no longer be removed
- the maximum number of washes is exceeded.
- the fluorescence has faded

### Flat tire

#### Notes on flat tires

WARNING Risk of accident due to a flat tire

A flat tire severely affects the driving characteristics as well as the steering and braking of the vehicle.

#### Tires without run-flat characteristics:

- Do not drive on with a flat tire.
- Change the flat tire immediately with an emergency spare wheel or spare wheel. Alternatively, consult a qualified specialist workshop.



#### Tires with run-flat characteristics:

Observe the information and warning notes on MOExtended tires (run-flat tires).

In the event of a flat tire, the following options are available depending on your vehicle's equipment:

- Vehicles with MOExtended tires: it is possible to continue the journey for a short period of time. Make sure you observe the notes on MOExtended tires (run-flat tire)
   ( page 354).

- All vehicles: change the wheel
   page 398).

### Notes on MOExtended tires (run-flat tire)

**WARNING** Risk of accident when driving in emergency mode

When driving in emergency mode, the handling characteristics are impaired. e.g. when cornering, when accelerating strongly and when braking.

- Do not exceed the permissible maximum speed for MOExtended tires.
- Avoid any abrupt steering and driving maneuvers as well as driving over obstacles (curbs, pot holes, off-road). This applies, in particular, to a loaded vehicle.
- Stop driving in the emergency mode if you notice:
- · banging noise
- vehicle vibration
- smoke which smells like rubber
- continuous ESP<sup>®</sup> intervention
- · cracks in tire side walls

- After driving in emergency mode have the rims checked by a qualified specialist workshop with regard to their further use.
- The defective tire must be replaced in every case.

With MOExtended tires (run-flat tire), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires. However, the tire affected must not show any clearly visible damage.

You can recognize MOExtended tires by the MOExtended marking which appears on the side wall of the tire.

Vehicles with tire pressure monitoring system: MOExtended tires may only be used in conjunction with an activated tire pressure monitoring system.

If a pressure loss warning message appears in the multifunction display, proceed as follows:

- Check the tire for damage.
- If driving on, observe the following notes.



# Driving distance possible in emergency mode after the pressure loss warning:


Load condition	Driving distance pos- sible in emergency mode
Partially laden	50 miles (80 km)
Fully laden	19 miles (30 km)

The driving distance possible in emergency mode may vary depending on the driving style. Observe the maximum permissible speed of 50 mph (80 km/h).

If a tire has gone flat and cannot be replaced with an MOExtended tire, you can use a standard tire as a temporary measure.

# **TIREFIT** kit storage location

The TIREFIT kit is located under the trunk floor. Mercedes vehicles: observe the notes in the Supplement. Otherwise, you may not recognize dangers.



- Tire sealant bottle
- Tire inflation compressor

# Using the TIREFIT kit

#### Requirements:

- Tire sealant bottle
- Enclosed TIREFIT sticker
- Tire inflation compressor
- Disposable gloves

You can use TIREFIT tire sealant to seal perforation damage of up to 0.16 in (4 mm), particularly those in the tire contact surface. You can use

TIREFIT in outside temperatures down to -4 °F (-20 °C).

**WARNING** Risk of accident when using tire sealant.

In the following situations, the tire sealant is unable to provide sufficient breakdown assistance, as it is unable to seal the tire properly:

- There are cuts or punctures in the tire larger than those previously mentioned.
- The wheel rim is damaged.
- You have driven at a very low tire pressure or on a flat tire
- Do not continue driving.
- Consult a qualified specialist workshop.

WARNING Risk of injury and poisoning from tire sealant

The tire sealant is harmful and causes irritation. Do not allow it to come into contact with the skin, eyes or clothing, and do not



swallow it. Do not inhale tire sealant fumes. Keep the tire sealant away from children.

If you come into contact with the tire sealant, observe the following:

- Rinse off the tire sealant from your skin immediately using water.
- If tire sealant gets into your eyes, thoroughly rinse out the eyes using clean water.
- If tire sealant has been swallowed, immediately rinse out the mouth thoroughly and drink plenty of water. Do not induce vomiting and seek medical attention immediately.
- Change out of any clothes contaminated with tire sealant immediately.
- If allergic reactions occur, seek medical attention immediately.

- NOTE Overheating due to the tire inflation compressor running too long
- Do not run the tire inflation compressor for longer than eight minutes without interruption.


Comply with the manufacturer's safety notes on the sticker on the tire inflation compressor.

Have the tire sealant bottle replaced every four years at a qualified specialist workshop.

Do not remove any foreign objects which have entered the tire.



- Affix part ① of the TIREFIT sticker to the instrument cluster within the driver's field of vision.
- Affix part ② of the TIREFIT sticker near the valve on the wheel with the faulty tire.



Pull plug with the cable and hose out of the tire inflation compressor housing.

- Push the plug of hose (5) into flange (6) of tire sealant bottle 1 until the plug engages.
- Place tire sealant bottle 

  head downwards into recess 2 of the tire inflation compressor.



- Remove the cap from valve 
  on the faulty tire.
- Screw filling hose (8) onto valve (7).
- Insert connector (4) into a 12 V socket in vour vehicle.
- Switch on the ignition.

Press on and off switch (3) on the tire inflation compressor.

The tire inflation compressor is switched on. The tire is inflated. First, tire sealant is pumped into the tire. The pressure may briefly rise to approximately 500 kPa (5 bar/73 psi).

### Do not switch off the tire inflation compressor during this phase.

Let the tire inflation compressor run for a maximum of eight minutes. The tire should then have attained a tire pressure of at least 180 kPa (1.8 bar/26 psi).

If tire sealant leaks out, make sure you clean the affected area as quickly as possible. It is preferable to use clear water.

If you get tire sealant on your clothing, have it cleaned as soon as possible with perchloroethylene.

#### If a tire pressure of 180 kPa (1.8 bar/26 psi) has not been attained after eight minutes:

Switch off the tire inflation compressor.

Unscrew the filling hose from the valve of the faulty tire.

Please note that tire sealant may leak out when unscrewing the filling hose.

- Drive forwards or reverse very slowly for approximately 33 ft (10 m).
- Pump up the tire again. After a maximum of eight minutes the tire pressure must be at least 180 kPa (1.8 bar/ 26 psi).
- WARNING Risk of accident due to the specified tire pressure not being reached

If the specified tire pressure is not reached after the specified time, the tire is too badly damaged. The tire sealant cannot repair the tire in this instance.

Damaged tires and a tire pressure that is too low can significantly impair braking and handling characteristics.

- Do not continue driving.
- Consult a qualified specialist workshop.



# If a tire pressure of 180 kPa (1.8 bar/26 psi) has been attained after eight minutes:

WARNING Risk of accident from driving with sealed tires

A tire temporarily sealed with tire sealant impairs driving characteristics and is not suitable for higher speeds.

- Adapt your driving style accordingly and drive carefully.
- Do not exceed the maximum speed limit with a tire that has been repaired using tire sealant.

Observe the maximum permissible speed for a tire sealed with tire sealant 50 mph (80 km/h).

- Affix the upper section of the TIREFIT sticker to the instrument cluster in a location where it will be easily seen by the driver.
- ! NOTE Staining caused by leaking tire sealant

After use, excess tire sealant may leak out from the filling hose.

Therefore, place the filling hose in the plastic bag that contained the TIREFIT kit.



**ENVIRONMENTAL NOTE** Environmental pollution caused by environmentally irresponsible disposal

Tire sealant contains pollutants.

- Have the tire sealant bottle disposed of professionally, e.g. at an authorized Mercedes-Benz Center.
- Switch off the tire inflation compressor.
- Unscrew the filling hose from the valve of the faulty tire.
- Stow the tire sealant bottle, the tire inflation compressor and the warning triangle.
- Pull away immediately.
- Stop driving after approximately ten minutes and check the tire pressure using the tire inflation compressor.

The tire pressure must now be at least 130 kPa (1.3 bar/19 psi).

DEALER &PROCESS

**WARNING** Risk of accident due to the specified tire pressure not being reached

If the specified tire pressure is not reached after a brief drive, the tire is too badly damaged. The tire sealant cannot repair the tire in this instance.

Damaged tires and tire pressure that is too low can significantly impair the braking properties and the handling characteristics.

- Do not continue driving.
- ► Consult a qualified specialist workshop.

In cases such as the one mentioned above, contact an authorized Mercedes-Benz Center. Or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).

- Correct the tire pressure if it is still at least 130 kPa (1.3 bar/19 psi). You will find the values in the Tire and Loading Information placard on the B-pillar on the driver's side or in the tire pressure table in the fuel filler flap.
- ➤ To increase the tire pressure: switch on the tire inflation compressor.



- To reduce the tire pressure: press pressure release button next to pressure gauge
- When the tire pressure is correct, unscrew the filling hose from the valve of the sealed tire.
- Screw the valve cap onto the valve of the sealed tire.
- Pull the tire sealant bottle out of the tire inflation compressor. The filling hose stays on the tire sealant bot-

tle.

Drive to the nearest qualified specialist workshop and have the tire, tire sealant bottle and filling hose replaced there.

#### Battery (vehicle)

Notes on the 12 V battery

WARNING Risk of an accident due to work carried out incorrectly on the batterv

Work carried out incorrectly on the battery can, for example, lead to a short circuit. This can lead to function restrictions in safety-relevant systems, for example the lighting system, ABS (anti-lock braking system) or ESP® (Electronic Stability Program). The operating safety of your vehicle may be restricted.

You could lose control of the vehicle in the following situations:

- when braking
- in the event of abrupt steering maneuvers and/or when the vehicle's speed is not adapted to the road conditions

DEALER ePROCESS

- In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately.
- Do not continue driving.
- Always have work on the battery carried out at a qualified specialist workshop.
- Further information on ABS (——> page 151)
- Further information on FSP®  $(\longrightarrow)$  page 152)

For safety reasons, Mercedes-Benz recommends that you only use batteries which have been tested and approved for your vehicle by Mercedes-Benz. These batteries provide increased impact protection to prevent vehicle occupants from suffering acid burns should the battery be damaged in the event of an accident.

#### All vehicles except vehicles with a lithiumion battery

A

**WARNING** Risk of explosion due to electrostatic charge

Electrostatic charge can cause sparks which may ignite the highly flammable gas mixture in the battery.

To discharge any electrostatic charge that may have built up, touch the metal vehicle body before handling the battery.

The highly flammable gas mixture is created while the battery is charging and during starting assistance.

**WARNING** Danger of chemical burns from the battery acid

Battery acid is caustic.

- Avoid contact with the skin, eyes or clothing.
- Do not lean over the battery.

- Do not inhale battery gases.
- Keep children away from the battery.
- Immediately rinse battery acid off thoroughly with plenty of clean water and seek medical attention immediately.

#### All vehicles



**ENVIRONMENTAL NOTE** Environmental damage caused by improper disposal of batteries



Batteries contain pollutants. It is illegal to dispose of them with the household rubbish.



Dispose of batteries in an environmentally responsible manner. Take discharged batteries to a qualified

specialist workshop or to a collection point for used batteries.

If you have to disconnect the 12 V battery, contact a qualified specialist workshop.

Comply with safety notes and take protective measures when handling batteries.



Risk of explosion.



Fire, open flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Electrolyte or battery acid is corrosive. Avoid contact with the skin, eyes or clothing. Wear suitable protective clothing, in particular gloves, an apron and a face mask. Immediately rinse electrolyte or acid splashes off with clean water. Consult a doctor if necessary.





Wear safety glasses.



Keep children away.



Observe this Operator's Manual.

Observe the following if you do not intend to use the vehicle over an extended period of time:

- Activate standby mode.
- Alternatively: connect the battery to a battery charger approved by Mercedes-Benz or consult a qualified specialist workshop to disconnect the battery.

# Notes on starting assistance and on charging the 12 V battery

#### Vehicles with a lithium-ion battery

When charging the battery and during starting assistance, always use the jump-start connection point in the engine compartment.



NOTE Damage to the battery from overvoltage

When charging using a battery charger without a maximum charging voltage, the battery or the on-board electronics may be damaged.

Only use battery chargers with a maximum charging voltage of 14.4 V.

#### All other vehicles

When charging the battery and during starting assistance, always use the jump-start connection point in the engine compartment.



NOTE Damaging the battery through overvoltage

When charging using a battery charger without a maximum charging voltage, the battery or the vehicle electronics may be damaged.

Only use battery chargers with a maximum charging voltage of 14.8 V.

**WARNING** Risk of explosion from hydrogen gas igniting

A battery generates hydrogen gas during the charging process. If there is a short circuit or sparks start to form, there is a danger of the hydrogen gas igniting.

- Make sure that the positive terminal of the connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- When connecting and disconnecting the battery, you must observe the described order for the battery clamps.

- When giving starting assistance, always make sure that you only connect battery terminals with identical polarity.
- During starting assistance, you must observe the described order for connecting and disconnecting the jumper cables.
- Do not connect or disconnect the battery clamps while the engine is running.

# **WARNING** Risk of explosion during charging process and starting assistance

During the charging process and starting assistance, the battery may release an explosive gas mixture.

- Avoid fire, open flames, creating sparks and smoking.
- Make sure that there is sufficient ventilation during the charging process and during starting assistance.
- ▶ Do not lean over a battery.

# **WARNING** Risk of explosion from a frozen battery

A discharged battery may freeze at temperatures slightly above or below freezing point. During starting assistance or battery charg-

Always thaw a frozen battery out first before charging it or performing starting assistance.

ing, battery gas may be released.

If the indicator/warning lamps in the instrument cluster do not light up at low temperatures, it is very likely that the discharged battery has frozen. In this case you may neither jump-start the vehicle nor charge the battery.

The service life of a battery that has been thawed may be dramatically shortened. The starting characteristics may be impaired, especially at low temperatures.

It is recommended that you have a thawed battery checked at a qualified specialist workshop.



#### All vehicles

I NOTE Damage caused by numerous or extended attempts to start the engine

Numerous or extended attempts to start the engine may damage the catalytic converter due to non-combusted fuel.

Avoid numerous and extended attempts to start the engine.

Observe the following points during starting assistance and when charging the battery:

- Only use undamaged jumper cables/charging cables with a sufficient cross-section and insulated terminal clamps.
- Non-insulated parts of the terminal clamps must not come into contact with other metal parts while the jumper cable/charging cable is connected to the battery/jump-start connection point.
- The jumper cable/charging cable must not come into contact with any parts which may move when the engine is running.

- Always make sure that neither you nor the battery is electrostatically charged.
- Keep away from fire and open flames.
- Do not lean over the battery.

Observe the additional following points when charging the battery:

- · Only use battery chargers tested and approved for Mercedes-Benz.
- Read the battery charger's operating instructions before charging the battery.


Observe the additional following points during starting assistance:

- Starting assistance may only be provided using batteries with a nominal voltage of 12 V.
- The vehicles must not touch.
- Gasoline engine: Only accept starting assistance if the engine and exhaust system are cold.

#### Starting assistance and charging the 12 V battery

#### Requirements:

- The vehicle is secured with the electric parking brake.
- The transmission is in position **P**.
- The ignition and all electrical consumers are switched off.
- The hood is open.



- Slide cover 3 of positive clamp 4 on the jump-starting connection point in the direction of the arrow.
- Connect positive clamp 4 on your vehicle to the positive pole of the donor battery using the jumper cable/charging cable. Always begin with positive clamp 4 on your own vehicle first.



- During starting assistance: start the engine of the donor vehicle and run at idle speed.
- Connect the negative pole of the donor battery and ground point ⑤ of your own vehicle by using the jumper cable/charging cable. Begin with the donor battery first.
- **During starting assistance:** start the engine of your own vehicle.
- **During the charging process:** start the charging process.
- **During starting assistance:** let the engines run for several minutes.
- During starting assistance: before disconnecting the jumper cable, switch on an electrical consumer in your own vehicle, e.g. the rear window defroster or lighting.

When the starting assistance/charging process is complete:

First, remove the jumper cable/charging cable from ground point (a) and negative pole of the donor battery, then from positive clamp (a) and positive pole of the donor bat-

tery. Begin each time with the contacts on your own vehicle first.

After removing the jumper cable/charging cable, close cover (3) of positive clamp (4).

Further information can be obtained at a qualified specialist workshop.

### Replacing the 12 V battery

Mercedes-Benz recommends that you have the 12 V battery replaced at a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.

Observe the following notes if you want to replace the battery yourself:

 Always replace a faulty battery with a battery which meets the specific vehicle requirements.

The vehicle is equipped with an AGM technology battery (Absorbent Glass Mat) or a lithium-ion battery. Full vehicle functionality is only guaranteed with an AGM battery or lithium-ion battery. For safety reasons, Mercedes-Benz recommends that you only use batteries which have been tested and approved for your vehicle by Mercedes-Benz.

- Carry over detachable parts, such as vent hoses, elbow fitting or terminal covers from the battery being replaced.
- Make sure that the vent hose is always connected to the original opening on the side of the battery.

Install any existing or supplied cell caps. Otherwise, gases or battery acid could escape.

Make sure that detachable parts are reconnected in the same way.

### Tow starting or towing away Permitted towing methods

Mercedes-Benz recommends transporting your vehicle in the case of a breakdown, rather than towing it away.



NOTE Damage to the vehicle due to towing away incorrectly
 Observe the instructions and notes on towing away.

**Towing with a raised axle:** towing should be performed by a towing company.

#### Permitted towing methods

Vehicle equipment/towing method			
	Both axles on the ground	Front axle raised	Rear axle raised
Vehicles with automatic transmission	Yes, maximum 31 miles (50 km) at 31 mph (50 km/h)	No	Yes, if the steering wheel is fixed in the center position with a steering wheel lock
4MATIC vehicles	Yes, maximum 31 miles (50 km) at 31 mph (50 km/h)	No	No



# Towing the vehicle with both axles on the ground

- Observe the notes on the permitted towing methods ( page 364).
- Make sure that the battery is connected and charged.

When the battery is discharged, the following actions cannot be performed:

- · the engine cannot be started
- the electric parking brake cannot be released or applied
- the automatic transmission cannot be shifted to position N or P
- If the automatic transmission cannot be shifted to position N, or the multifunction display in the instrument cluster does not show anything, have the vehicle transported away (→ page 367). A towing vehicle with lifting equipment is required for vehicle transportation.

NOTE Damage due to towing away at excessively high speeds or over long distances

The drivetrain could be damaged when towing at excessively high speeds or over long distances.

- A towing speed of 30 mph (50 km/h) must not be exceeded.
- A towing distance of 30 miles (50 km) must not be exceeded.

**WARNING** Risk of accident when towing a vehicle which is too heavy

If the vehicle being tow-started or towed away is heavier than the permissible gross mass of your vehicle, the following situations can occur:

- The towing eye may become detached.
- The vehicle/trailer combination may swerve or even overturn.
- If another vehicle is tow-started or towed away, its weight must not exceed

the permissible gross mass of your own vehicle.

If a vehicle must be tow-started or towed away, its weight must not exceed the permissible gross mass of the towing vehicle.

- Information on the permissible gross mass of the vehicle can be found on the vehicle identification plate ( page 406).
- Do not open the driver's door or front passenger door, otherwise the automatic transmission automatically shifts to position
   P.
- ► Install the towing eye ( → page 369).
- Fasten the tow bar.
  - NOTE Damage due to incorrect connection
  - Only connect the tow rope or tow bar to the towing eyes.
- Deactivate the automatic locking mechanism (→ page 61).



- Do not activate the HOLD function
- Deactivate Active Brake Assist  $(\longrightarrow)$  page 159).
- Shift the automatic transmission to position N.
- Release the electric parking brake.
- WARNING Risk of accident due to limited safety-related functions during the towing process

Safety-related functions are limited or no longer available in the following situations:

- the ignition is switched off.
- the brake system or power steering system is malfunctioning.
- · the energy supply or the on-board electrical system is malfunctioning.

When your vehicle is then towed away, significantly more effort may be required to steer and brake than is normally required.

Use a tow bar.

- Make sure that the steering wheel can move freely, before towing the vehicle away.
- **NOTE** Damage due to excessive tractive power

If you pull away sharply, the tractive power may be too high and the vehicles could be damaged.

Pull away slowly and smoothly.

### Loading the vehicle for transport

- Observe the notes on towing away  $(\longrightarrow)$  page 366).
- Connect the tow bar to the towing eye to load the vehicle.
- Shift the automatic transmission to position N.
- The automatic transmission may be locked in position P in the event of damage to the electrics. To shift to N, provide the on-

DEALER ePROCESS

- board electrical system with power  $(\longrightarrow)$  page 363).
- Load the vehicle onto the transporter.
- Shift the automatic transmission to position Ρ.
- Use the electric parking brake to secure the vehicle against rolling away.
- Only secure the vehicle by the wheels.

### Vehicles with ADS PLUS (Adaptive Damping System PLUS)

WARNING Risk of an accident when transporting vehicles with Adaptive Damping System PLUS

The reduced damping forces on the vehicle being transported can cause the vehicle/ trailer combination to start to swing.


As a result, when transporting vehicles with the Adaptive Damping System PLUS, the vehicle/trailer combination may start to skid. Consequently, you could lose control of your vehicle.

When transporting, ensure that:

- The vehicle has been loaded onto the transporter correctly
- The vehicle is secured at all four wheels with suitable tensioning straps
- The maximum permissible speed of 35 mph (60 km/h) is not exceeded when transporting
- NOTE Damage to the vehicle from securing it incorrectly
- After loading, the vehicle must be secured on all four wheels. Otherwise, the vehicle could be damaged.
- A minimum distance of 4 in (10 cm) upwards and 8 in (20 cm) downwards must be kept to the transport platform.

Transport level is not available for the following vehicles:

- · Mercedes-AMG vehicles
- Vehicles with MAGIC BODY CONTROL



- i Depending on the model, button i is located in the control panel between the steering wheel and the driver's door.
- To activate transport level: press button

  1.

Indicator lamp 2 lights up.

The vehicle is raised by 1.2 in (30 mm) compared to the normal level.

DEALER ePROCESS

Press button again and hold it for at least five seconds.

The vehicle is raised from the raised level to the transport level.

The transport level is reached when indicator lamp ② flashes and the Max. Speed 22mph display message appears in the multifunction display.

The vehicle is lowered again in the following situations:

- When driving faster than 22 mph (35 km/h).
- After selecting a drive program using the DYNAMIC SELECT switch.


The vehicle is then adjusted to the height of the last active drive program.

- Secure the vehicle on all four wheels after loading.
- ➤ To deactivate transport level: start the engine when the vehicle is at a standstill. If transport level is activated, indicator lamp



- Press and hold button (1) for at least five seconds.
  - The vehicle is adjusted to the height of the last active drive program. Indicator lamp 2 goes out.
- Drive the vehicle off the transporter.


#### 4MATIC vehicles



Make sure that the front and rear axles come to rest on the same transportation vehicle.

- NOTE Damage to the drivetrain due to incorrect positioning
- Do not position the vehicle above the connection point of the transport vehicle.


### Towing eye storage location



Towing eye (1) is located with the vehicle tool kit under the trunk floor.



#### Installing the towing eye



- Press the mark on cover **(1)** inwards and remove.
- Screw in the towing eye clockwise as far as it will go and tighten.
- (i) Make sure that cover (1) engages in the bumper when you remove the towing eye.

NOTE Damage due to incorrect use of the towing eye

When a towing eye is used to recover a vehicle, the vehicle may be damaged in the process.

Only use the towing eye to tow away or tow start the vehicle.

# Tow-starting the vehicle (emergency engine start)

! NOTE Damage to the automatic transmission due to tow starting

The automatic transmission may be damaged in the process of tow starting vehicles with automatic transmission.

- Vehicles with automatic transmission must not be tow started.
- Vehicles with automatic transmission must not be tow-started.

#### Electrical fuses

#### Notes on electrical fuses

A

WARNING Risk of accident and injury due to overloaded lines

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric line could be overloaded.

This could result in a fire.

- Always replace faulty fuses with specified new fuses containing the correct amperage.
- NOTE Damage caused by incorrect fuses

Incorrect fuses may cause damage to electrical components or systems.

 Only use Mercedes-Benz approved fuses with the correct fuse rating.

Blown fuses must be replaced with fuses of the same rating, which you can recognize by the color and fuse rating. The fuse ratings and fur-

DEALER ePROCESS

ther information to be observed are listed in the fuse assignment diagram.

NOTE Damage or malfunctions caused by moisture

Moisture may cause damage to the electrical system or cause it to malfunction.

- When the fuse box is open, make sure that no moisture can enter the fuse box.
- When closing the fuse box, make sure that the seal of the lid is positioned correctly on the fuse box.

If the newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

Ensure the following before replacing a fuse:

- · The vehicle is secured against rolling away
- · All electrical consumers are switched off
- · The ignition is switched off

The electrical fuses are located in the following fuse boxes:

- Fuse box in the engine compartment on the driver's side ( $\longrightarrow$  page 371)
- Fuse box on the driver's side of the cockpit  $(\longrightarrow)$  page 372)
- Fuse box in the front passenger footwell  $(\longrightarrow)$  page 372)
- Fuse box in the trunk on the right-hand side of the vehicle when viewed in the direction of travel ( $\longrightarrow$  page 373)

#### Opening and closing the fuse box in the engine compartment

#### Requirements:


- Observe the notes on electrical fuses  $(\longrightarrow)$  page 370).
- Have the following tools readily available:
  - a dry cloth
  - a screwdriver

#### Opening

WARNING Risk of injury from using the windshield wipers while the engine hood is open


When the engine hood is open and the windshield wipers are set in motion, you can be trapped by the wiper linkage.

Always switch off the windshield wipers and ignition before opening the engine hood.



Release retaining clips ①. Pull cover 2 up.





- Remove any existing moisture from the fuse box using a dry cloth.
- Loosen screws 4, and remove fuse box lid from the top.

#### Closing

Check whether the seal is positioned correctly in lid 3.

- Insert lid (3) into the bracket at the rear of the fuse box.
- Fold down lid (3) of the fuse box and tighten screws (6).
- Insert cover ② on both sides and engage retaining clips ①.
- Close the hood.

# Opening and closing the fuse box in the cockpit

#### Requirements:

Observe the notes on electrical fuses
 ( page 370).




Open cover 
in the direction of the arrow and remove it.

# Opening and closing the fuse box in the front passenger footwell

#### Requirements:

 Observe the notes on electrical fuses ( page 370).



Open cover 1 in the direction of the arrow and remove it.

#### Opening and closing the fuse box in the trunk

#### Requirements:

• Observe the notes on electrical fuses  $(\longrightarrow)$  page 370).



Fold cover 1 down in the direction of the arrow.



#### Notes on noise or unusual handling characteristics

While driving, pay attention to vibrations, noises and unusual handling characteristics, e.g. pulling to one side. This may indicate that the wheels or tires are damaged. If you suspect that a tire is defective, reduce your speed immediately. Stop the vehicle as soon as possible to check the wheels and tires for damage. Hidden tire damage could also be causing the unusual handling characteristics. If you find no signs of damage, have the tires and wheels checked at a qualified specialist workshop.

#### Notes on regularly inspecting wheels and tires

WARNING Risk of accident from damaged tires

Damaged tires can cause tire pressure loss. As a result, you could lose control of your vehicle.

Check the tires regularly for signs of damage and replace any damaged tires immediately.

WARNING Risk of aquaplaning due to insufficient tire tread

Insufficient tire tread will result in reduced tire grip. The tire tread is no longer able to dissipate water.

This means that in heavy rain or slush the risk of hydroplaning is increased, in particular if vehicle speed is not adapted to suit the conditions.

If the tire pressure is too high or too low, tires may exhibit different levels of wear at different locations on the tire contact surface.

Thus, you should regularly check the tread depth and the condition of the tire contact surface across the entire width of all tires.

DEALER EPROCESS

Minimum tread depth for:

- Summer tires: ½ in (3 mm)
- M+S tires: 1/6 in (4 mm)
- For safety reasons, replace the tires before the legally prescribed limit for the minimum tread depth is reached.

Carry out the following checks on all wheels regularly, at least once a month or as required, e.g. prior to a long journey or driving off-road:

- Check the tire pressure (\rightarrow\rightarrow page 375).
- Visually inspect tires and wheels for damage.
- Check the valve caps.

The valves must be protected against moisture and dirt by the valve caps approved especially for your vehicle by Mercedes-Benz.

· Visual check of the tire tread depth and the tire contact surface across the entire width.

The minimum tread depth for summer tires is  $\frac{1}{8}$  in (3 mm) and for winter tires  $\frac{1}{6}$  in (4 mm).



Six marks 1 show where the bar indicators (arrow) are integrated into the tire tread. They are visible once a tread depth of approximately  $\frac{1}{16}$  in (1.6 mm) has been reached.

#### Notes on snow chains

WARNING Risk of accident due to incorrect mounting of snow chains

If you have mounted snow chains to the front wheels, the snow chains may drag against the vehicle body or chassis components.

This could cause damage to the vehicle or the tires.

- Never mount snow chains on the front wheels.
- Only mount snow chains on the rear wheels in pairs.
- **NOTE** Damage to the wheel trim from mounted snow chains

If snow chains are mounted to steel wheels. the wheel trims can be damaged.

- Remove the wheel trims of steel wheels before mounting snow chains.
- Snow chains are only permissible for certain wheel/tire combinations. You can obtain information about this from an authorized Mercedes-Benz Center.
- For safety reasons, only use snow chains that have been specifically approved for your vehicle by Mercedes-Benz, or snow chains with the same quality standard.

- If snow chains are installed, the maximum permissible speed is 30 mph (50 km/h).
- Vehicles with Active Parking Assist: Do not use Parking Assist PARKTRONIC when snow chains have been installed
- Vehicles with AIR BODY CONTROL or MAGIC BODY CONTROL: If snow chains are installed, only drive at raised vehicle level.
- You can deactivate ESP® to pull away ( page 154). This allows the wheels to spin, achieving an increased driving force.

#### Tire pressure

### Notes on tire pressure

WARNING Risk of accident due to insufficient or excessive tire pressure

Underinflated or overinflated tires pose the following risks:

• The tires may burst, especially as the load and vehicle speed increase.



- The tires may wear excessively and/or unevenly, which may greatly impair tire traction
- The driving characteristics, as well as steering and braking, may be greatly impaired.
- Comply with the recommended tire pressure and check the tire pressure of all tires including the spare wheel regularly:
- at least once a month
- when the load changes
- before embarking on a longer journey
- if operating conditions change, e.g. offroad driving
- Adjust the tire pressure as necessary.

Driving with tire pressure that is too high or too low can:

- Shorten the service life of the tires.
- Cause increased tire damage.

 Adversely affect driving characteristics and thus driving safety, e.g. due to hydroplaning.

# WARNING Risk of an accident due to

insufficient tire pressure

Tires with pressure that is too low can overheat and burst as a result.

In addition, they also suffer from excessive and/or irregular wear, which can significantly impair the braking properties and the handling characteristics.

Avoid excessively low tire pressures in all the tires, including the spare wheel.

Tire pressure which is too low can cause:

- Tire defects as a result of overheating
- Impaired handling characteristics
- Irregular wear
- Increased fuel consumption



### WARNING Risk of accident from excessive tire pressure

Tires with excessively high pressure can burst because they are damaged more easily by highway fill, pot holes etc.

In addition, they also suffer from irregular wear, which can significantly impair the braking properties and the handling characteristics.

Avoid excessively high tire pressures in all the tires, including the spare wheel.

Excessively high tire pressure can result in:

- · Increased braking distance
- Impaired handling characteristics
- Irregular wear
- Impaired driving comfort
- Susceptibility to damage

**WARNING** Risk of accident caused by repeated drop in tire pressure

If the tire pressure drops repeatedly, the wheel, valve or tire may be damaged.

Insufficient tire pressure can cause the tires to burst.

- Inspect the tire for signs of foreign objects.
- Check whether the wheel or valve has a leak.
- If you are unable to rectify the damage, contact a qualified specialist workshop.

You can find information on tire pressure for the vehicle's factory-installed tires on the following labels:

- Tire and Loading Information placard on the B-pillar of your vehicle ( page 382).
- Tire pressure table on the inside of the fuel filler flap ( $\longrightarrow$  page 377).

Observe the maximum tire pressure  $(\longrightarrow)$  page 389).

Use a suitable tire pressure gauge to check the tire pressure. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure.

Vehicles with a tire pressure monitoring system: You can also check the tire pressure using the on-board computer.

Only correct tire pressure when the tires are cold. Conditions for cold tires:

- The vehicle has been parked with the tires out of direct sunlight for at least three hours.
- The vehicle has traveled less than 1 mile (1.6 km).

A rise in the tire temperature of 18 °F (10 °C) increases the tire pressure by approx. 10 kPa (0.1 bar/1.5 psi). Take this into account when checking the tire pressure of warm tires.

The tire pressure recommended for increased load/speed in the tire pressure table can affect the ride comfort.



WARNING Risk of accident from unsuitable accessories on the tire valves


If you mount unsuitable accessories onto tire valves, the tire valves may be overloaded and malfunction, which can cause tire pressure loss. Tire pressure monitoring systems for retrofitting will cause the tire valve to remain open. This can also result in tire pressure loss.

Only screw standard valve caps or valve caps specifically approved by Mercedes-Benz for your vehicle onto the tire valve.

#### Tire pressure table

The tire pressure table is on the inside of the fuel filler flap.


(i) The data shown in the images is example data.



The tire pressure table shows the recommended tire pressure for all tires approved for this vehicle. The recommended tire pressures apply for cold tires under various operating conditions, i.e. loading and/or speed of the vehicle.

If one or more tire sizes precede a tire pressure, the tire pressure information following is only valid for those tire sizes.

The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of passengers and amounts of luggage. The actual number of seats may differ from this.



Be sure to also observe the following further related subjects:

Notes on tire pressure ( > page 375)

DEALER EPROCESS

- Tire and Loading Information placard ( page 382)
- Maximum tire pressure ( page 389)

#### Checking tire pressures manually

- Read the tire pressure for the current operating conditions from the Tire and Loading Information placard or the tire pressure table. Observe the notes on tire pressure.
- Remove the valve cap of the tire to be checked.
- Press the tire pressure gauge securely onto the valve.
- Read the tire pressure.
- If the tire pressure is lower than the recommended value, increase the tire pressure to the recommended value.
- If the tire pressure is higher than the recommended value, release air. To do so, press down the metal pin in the valve, e.g. using the tip of a pen for example. Then check the tire pressure again using the tire pressure gauge.

Screw the valve cap onto the valve.

Further related subjects:

- Notes on tire pressure (—— page 375)
- Tire pressure table ( page 377)
- Tire and Loading Information placard  $(\longrightarrow)$  page 382)

### Tire pressure monitoring system

Function of the tire pressure monitoring system

**DANGER** Risk of accident due to incorrect tire pressure

Every tire, including the spare (if provided), should be checked when cold at least once a month and inflated to the pressure recommended by the vehicle manufacturer (see Tire and Loading Information placard on the B-pillar on the driver's side or the tire pressure label on the inside of the fuel filler flap of your vehicle). If your vehicle has tires of a different size than the size indicated on the

Tire and Loading Information placard or the tire pressure table, you need to determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure indicator lamp when one or more of your tires are significantly underinflated. Accordingly, if the low tire pressure indicator lamp lights up, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also increases fuel consumption and reduces tire tread life, and may affect the vehicle's handling and braking ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure indicator lamp.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure indicator lamp. When the system detects a malfunction, the indicator lamp will flash for approximately a minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction warning lamp after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels



allow the TPMS to continue to function properly.

The system checks the tire pressure and the tire temperature of the tires installed on the vehicle by means of a tire pressure sensor.

New tire pressure sensors, e.g. in winter tires, are automatically taught-in during the first journey they are used.

If there is a substantial pressure loss or if the tire temperature is excessive, you will be warned in the following ways:

- via display messages (——> page 450)
- via the <a href="tel:">(!)</a> warning lamp in the instrument cluster (
   page 473)

The tire pressure monitoring system is only an aid. It is the driver's responsibility to set the tire pressure to the recommended cold tire pressure suitable for the operating situation. Set the tire pressure for cold tires using a tire pressure gauge. Note that the correct tire pressure for the current operating situation must first be taughtin to the tire pressure monitoring system.

#### System limitations

The system may be impaired or may not function in the following situations:

- If the tire pressure is set incorrectly
- If there is a sudden pressure loss caused, for example, by a foreign object penetrating the tire
- If there is a malfunction caused by another radio signal source

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 375)

Checking the tire pressure with the tire pressure monitoring system

#### Requirements:

The ignition is switched on.

DEALER ePROCESS

On-board computer:

→ Service → Tires

One of the following displays appears:

- Current tire pressure of each wheel:
- Tire pressure will be displayed after driving a few minutes
- Tire Pressure Monitor Active: the teach-in process of the system is not yet complete.
   The tire pressure are already being monitored.
- Compare the tire pressure with the recommended tire pressure for the current operating condition (→ page 377). Observe the notes on tire temperature (→ page 375).
- i The values displayed in the multifunction display may deviate from those of the tire pressure gauge as they refer to sea level. At high altitudes, the tire pressure value indicated by a pressure gauge are higher than those shown by the on-board computer. In this case, do not reduce the tire pressure.

Make sure to observe the following further related subject:

Notes on tire pressure ( page 375)

Restarting the tire pressure monitoring system

#### Requirements:

 The recommended tire pressure is correctly set for the respective operating condition on each of the four wheels (
 page 375).

Restart the tire pressure monitoring system in the following situations:

- The tire pressure has changed.
- The wheels or tires have been changed or newly installed.

On-board computer:

¬→ Service → Tires

Swipe downwards on Touch Control on the left-hand side of the steering wheel. The Use Current Pressures as New Reference Values? message is shown in the multifunction display. Press OK to confirm the restart.
 The Run Flat Indicator Restarted message is shown in the multifunction display.

Current warning messages are deleted and the yellow warning lamp goes out.

After you have driven for a few minutes, the system checks whether the current tire pressures are within the specified range. The current tire pressures are then accepted as reference values and monitored.

Make sure to observe the following further related subject:

Notes on tire pressure ( page 375)

# Radio equipment approval of the tire pressure monitoring system

Radio equipment approval numbers

Country	Radio type approval number
Canada	IC: 2546A-GG4T IC: 2546A-DG6W2D4 IC: 2546A-MC34MA4
	Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploita- tion est autorisée aux deux con- ditions suivantes:
	(1) l'appareil ne doit pas produire de brouillage, et
	(2) l'utilisateur de l'appareil doit accepter tout brouillage radioé- lectrique subi, même si le
	brouillage est susceptible d'en compromettre le fonctionnement.



Country	Radio type approval number
USA	FCC ID: MRXGG4T
	FCC ID: MRXDG6W2D4
	FCC ID: MRXMC34MA4
	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
	(1) This device may not cause harmful interference, and
	(2) This device must accept any interference received, including interference that may cause undesired operation.

#### Loading the vehicle

Notes on Tire and Loading Information placard




**WARNING** Risk of accident from overloaded tires

Overloaded tires may overheat and burst as a consequence. Overloaded tires can also impair the steering and handling characteristics and lead to brake failure.


- Observe the load-bearing capacity of the tires.
- The load-bearing capacity must be at least half the gross axle weight rating of the vehicle.
- Never overload the tires by exceeding the maximum load.

The Tire and Loading Information placard is on the B-pillar on the driver's side of the vehicle.





Tire and Loading Information placard



The data shown in the illustration is example data.

The Tire and Loading Information placard shows:

- Maximum number of seats 2 according to the maximum number of people permitted to travel in the vehicle.
- Maximum permissible load (3) comprises the gross weight of all vehicle occupants, load and luggage.

• Recommended tire pressures (1) for cold tires. The recommended tire pressures are valid for the maximum permissible load and up to the maximum permissible vehicle speed.

#### Please also note:

- Information on permissible weights and loads on the vehicle identification plate  $(\longrightarrow)$  page 406).
- Information on tire pressure in the tire pressure table ( $\longrightarrow$  page 377).

#### Further related subjects:

- Determining the maximum permissible load  $(\longrightarrow)$  page 383)
- Notes on tire pressure ( page 375).

### Determining the maximum permissible load

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575, pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

- Step 1: locate the statement "The combined weight of occupants and load should never exceed XXX kg or XXX lbs." ("The combined weight of occupants and load should never exceed XXX kg or XXX lbs.") on your vehicle's Tire and Loading Information placard.
- **Step 2:** determine the combined weight of the driver and passengers that will be traveling in your vehicle.
- Step 3: subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- Step 4: the resulting figure equals the permissible cargo and luggage load capacity. For example: If "XXX" equals 1400 lbs and there are five occupants in your vehicle with a weight of 150 lbs each, the maximum cargo and luggage load capacity is 650 lbs (1400 - $750 (5 \times 150) = 650 lbs$ ).
- Step 5: determine the combined weight of luggage and load that the vehicle will be carrying. For safety reasons, this weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.

#### **384** Wheels and tires

Even if you have calculated the total load carefully, you should still make sure that the maximum permissible gross mass and the maximum permissible axle load of your vehicle are not exceeded. Details can be found on the vehicle identification plate.

 Have your loaded vehicle – including driver, occupants and load – weighed on a vehicle weighbridge.

The measured values may not exceed the maximum permissible values stated on the vehicle identification plate.

Further related subjects:

- Tire pressure table (→ page 377)
- · Vehicle identification plate

# Calculation example for determining the maximum load

The following table shows examples of how to calculate total and load capacities with varying

The higher the weight of all the occupants, the smaller the maximum load for luggage.

### Step 1

	Example 1	Example 2
Combined maximum weight of occupants and load (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)




	Example 1	Example 2
Number of people in the vehicle (driver and occupants)	5	1
Distribution of the occupants	Front: 2 Rear: 3	Front: 1
Weight of occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)	Occupant 1: 200 lbs (91 kg)
Total weight of all occupants	750 lbs (340 kg)	200 lbs (91 kg)

# Step 3

	Example 1	Example 2
Permissible load (maximum gross vehicle weight rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 200 lbs (91 kg) = 1300 lbs (589 kg)

### Tire labeling

#### Overview of tire labeling




- Uniform Tire Quality Grading Standard
   page 386)
- DOT, Tire Identification Number ( page 387)
- Maximum tire load ( page 388)
- Maximum tire pressure ( page 389)


- Manufacturer
- ⑥ Characteristics of the tire (→ page 389)
- Tire size designation, load-bearing capacity, speed rating and load index ( page 389)
- Tire name
- (i) The data shown in the image is example data.

### **Tire Quality Grading**

In accordance with the US Department of Transportation's "Uniform Tire Quality Grading Standards", tire manufacturers are required to grade their tires on the basis of the following three performance factors:

DEALER ePROCESS





- Tread wear grade
- 2 Traction grade
- Temperature grade
- i) The data shown in the image is example data.
- i) The classification is not legally stipulated for Canada, but it is generally stated.

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified test track of the US Department of Transportation. For example, a tire graded 150 would wear one

and one-half times as well on the government test track as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

#### Traction grade

A

**DANGER** Risk of accident due to inadequate traction

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include either acceleration, cornering, hydroplaning or peak traction characteristics.

Always adapt your driving style and drive at a speed to suit the prevailing traffic and weather conditions.

- NOTE Damage to the drivetrain from wheelspin
- Avoid wheelspin.

The traction grades – from highest to lowest – are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces made of asphalt and concrete.

#### Temperature grade

A

**WARNING** Risk of accident from tire overheating and tire failure

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

 Observe the recommended tire pressures and regularly check the tire pres-

- sure of all tires including the spare wheel.
- Adjust the tire pressure as necessary.

The temperature grades are A (the highest), B and C. They represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. Grade C corresponds to a level of performance which all passenger car tires must meet under the requirements of the US Department of Transportation.

#### **DOT, Tire Identification Number (TIN)**

US tire regulations stipulate that every tire manufacturer or retreader must imprint a TIN in or on the side wall of each tire produced.





The data shown in the image is example data.

The TIN is a unique identification number to identify tires and comprises the following:

- DOT (Department of Transportation): tire symbol marks (1) indicating that the tire complies with the requirements of the US Department of Transportation.
- Manufacturer identification code: manufacturer identification code (2) contains details of the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols. Further

information on retreaded tires → page 394).

- Tire size: identifier (3) describes the tire size.
- **Tire type code:** tire type code **(4)** can be used by the manufacturer as a code to describe specific characteristics of the tire.
- Manufacturing date: manufacturing date provides information about the age of a tire. The 1st and 2nd positions represent the calendar week and the 3rd and 4th positions state the year of manufacture (e.g. "3208" represents the 32nd week of 2008).

#### Information on the maximum tire load



The data shown in the image is example data.

Maximum tire load (1) is the maximum permissible weight for which the tire is approved.

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side ( $\longrightarrow$  page 382).



i The data shown in the image is example data.

Never exceed maximum tire pressure (1) specified for the tire.

#### Information on tire characteristics



i The data shown in the image is example data.

This information describes the type of tire cord and the number of layers in side wall ① and under tire tread ②.


# Tire size designation, load-bearing capacity, speed rating and load index

▲ WARNING Risk of injury through exceeding the specified tire load rating or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- ► Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.





- Preceding letter
- Nominal tire width in millimeters
- 3 Aspect ratio in %
- Tire code
- 6 Rim diameter
- Load-bearing index
- Speed rating
- Load index
- i The data shown in the image is example data.

Information about reading tire data can be obtained from any qualified specialist workshop.

# Preceding letter 10:

- Without: passenger vehicle tires according to European manufacturing standards.
- "P": passenger vehicle tires according to US manufacturing standards.
- "LT": light truck tires according to US manufacturing standards.
- "T": compact emergency spare wheels with high tire pressure that are only designed for temporary use in an emergency.

## Aspect ratio 3:

Ratio between tire height and tire width in percent (tire height divided by tire width).

### Tire code (1) (tire type):

- "R" radial tire
- "D": bias ply tire
- "B": bias belted tires
- "ZR": radial tire with a maximum speed above 149 mph (240 km/h) (optional)



### Rim diameter 6:

The diameter of the bead seat (not the diameter of the rim flange). The rim diameter is specified in inches (in).

## Load-bearing index 60:

Numerical code that specifies the maximum load-bearing capacity of a tire (e.g. "91" corresponds to 1356 lbs (615 kg)).

The load-bearing capacity of the tire must be at least half the permissible axle load of your vehicle. Do not overload the tires by exceeding the specified load limit.

#### See also:

- Maximum permissible load on the Tire and Loading Information placard ( page 382)
- Maximum tire load (→ page 388)
- Load index

# Speed rating 2:

Specifies the approved maximum speed of the tire.

Make sure that your tires have the required speed rating. You can obtain information on the required speed rating from an authorized Mercedes-Benz Center.

#### Summer tires

Index	Speed rating
Q	up to 100 mph (160 km/h)
R	up to 106 mph (170 km/h)
S	up to 112 mph (180 km/h)
Т	up to 118 mph (190 km/h)
Н	up to 130 mph (210 km/h)
V	up to 149 mph (240 km/h)
W	up to 168 mph (270 km/h)

Index	Speed rating
Υ	up to 186 mph (300 km/h)
ZRY <sup>1</sup>	up to 186 mph (300 km/h)
ZR(Y) <sup>1</sup>	over 186 mph (300 km/h)
ZR <sup>1</sup>	over 149 mph (240 km/h)

- Specifying the speed rating as the "ZR" index in tire code is optional for tires up to 186 mph (300 km/h).
- If your tire code (a) includes "ZR" and there
  is no speed rating (a), find out what the maximum speed is from the tire manufacturer.
- If load-bearing index and speed rating are in brackets, the maximum speed rating of your tire is above 186 mph (300 km/h). To find out the maximum speed, ask the tire manufacturer.



#### All-weather tires and winter tires

Index	Speed rating
Q M+S <sup>2</sup>	up to 100 mph (160 km/h)
T M+S <sup>2</sup>	up to 118 mph (190 km/h)
H M+S <sup>2</sup>	up to 130 mph (210 km/h)
V M+S <sup>2</sup>	up to 149 mph (240 km/h)

Winter tires bear the A snowflake symbol and fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow.

#### Load index (1):

- No specification given: standard load (SL) tire
- "XL" or "Extra Load": extra load tire or reinforced tire
- "Light Load": light load tire

<sup>1 &</sup>quot;ZR" stated in the tire code.

<sup>2</sup> Or "M+S & " for winter tires

 "C", "D", "E": a load range that depends on the maximum load that the tire can carry at a certain pressure

#### Definition of terms for tires and loading

Tire structure and characteristics: describes the number of layers or the number of rubbercoated belts in the tire contact surface and the tire wall. These are made of steel, nylon, polyester and other materials.

**Bar:** metric unit for tire pressure. 14.5038 pounds per square inch (psi) and 100 kilopascal (kPa) is the equivalent of one bar.

**DOT** (Department of Transportation): DOT-marked tires fulfill the requirements of the US Department of Transportation.

Average weight of the vehicle occupants: the number of vehicle occupants for which the vehicle is designed, multiplied by 150 lb (68 kg).

**Uniform Tire Quality Grading Standards:** a uniform standard to grade the quality of tires with regard to tread quality, tire traction and temperature characteristics. The quality grading

assessment is made by the manufacturer following specifications from the U.S. government. The quality grade of a tire is imprinted on the side wall of the tire.

**Recommended tire pressure:** the recommended tire pressure is the tire pressure specified for the tires mounted to the vehicle at the factory.

The tire and information table contains the recommended tire pressures for cold tires, the maximum permissible load and the maximum permissible vehicle speed.

The tire pressure table contains the recommended tire pressures for cold tires under various operating conditions, i.e. loading and/or speed of the vehicle.

Increased vehicle weight due to optional equipment: the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

Rim: the part of the wheel on which the tire is installed.

DEALER ePROCESS

**GAWR (Gross Axle Weight Rating):** the GAWR is the maximum permissible axle load. The actual load on an axle must never exceed the gross axle weight rating. The gross axle weight rating can be found on the vehicle identification plate on the B-pillar on the driver's side.

**Speed rating:** the speed rating is part of the tire identification. It specifies the speed range for which a tire is approved.

**GVW (Gross Vehicle Weight):** the gross vehicle weight comprises the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the trailer drawbar noseweight, if applicable. The gross vehicle weight must not exceed the gross vehicle weight rating GVWR as specified on the vehicle identification plate on the B-pillar on the driver's side.

GVWR (Gross Vehicle Weight Rating): the GVWR is the maximum permitted gross weight of the fully laden vehicle (weight of the vehicle including all accessories, occupants, fuel, luggage and the trailer drawbar noseweight if applicable). The gross vehicle weight rating is speci-

fied on the vehicle identification plate on the B-pillar on the driver's side.

Maximum weight of the laden vehicle: the maximum weight is the sum of the curb weight of the vehicle, the weight of the accessories, the maximum load and the weight of optional equipment installed at the factory.

Kilopascal (kPa): metric unit for tire pressure. 6.9 kPa corresponds to 1 psi. Another unit for tire pressure is bar. 100 kilopascal (kPa) equals 1 bar.

Load index: in addition to the load-bearing index, the load index may also be imprinted on the side wall of the tire. This specifies the loadbearing capacity of the tire more precisely.

Curb weight: the weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the air conditioning system and optional equipment if these are installed on the vehicle, but does not include passengers or luggage.

Maximum tire load: the maximum tire load is the maximum permissible weight in kilograms or lbs for which a tire is approved.

Maximum permissible tire pressure: maximum permissible tire pressure for one tire.

Maximum load on one tire: maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

PSI (pounds per square inch): standard unit of measurement for tire pressure.

Aspect ratio: ratio between tire height and tire width in percent.

**Tire pressure:** pressure inside the tire applying an outward force to every square inch of the tire. The tire pressure is specified in pounds per square inch (psi), in kilopascals (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

**Cold tire pressure:** the tires are cold when the vehicle has been parked for at least 3 hours without direct sunlight on the tires or the vehicle has been driven for less than 1 mile (1.6 km).

**Tire contact surface:** the part of the tire that comes into contact with the road.

Tire bead: the purpose of the tire bead is to ensure that the tire sits securely on the wheel

rim. There are several wire cores in the tire head. to prevent the tire from changing length on the wheel rim

Side wall: the part of the tire between the tread and the tire bead.

Weight of optional equipment: the combined weight of the optional equipment weighing more than the replaced standard parts and more than 5 lbs (2.3 kg). This optional equipment, such as high-performance brakes, level control system, a roof luggage rack or high-performance batteries, is not included in the curb weight and the weight of the accessories

TIN (Tire Identification Number): a unique identification number which can be used by a tire manufacturer to identify tires, for example, in a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer's identity code, tire size, tire type code and the manufacturing date.

Load-bearing index: the load-bearing index is a code that contains the maximum load-bearing capacity of a tire.



**Traction:** traction is the grip resulting from friction between the tires and the road surface.

**Wear indicator:** narrow bars (tread wear bars) that are distributed over the tire contact surface. If the tire tread is level with the bars, the wear limit of 1/16 in (1.6 mm) has been reached.

**Distribution of vehicle occupants:** distribution of vehicle occupants over designated seat positions in a vehicle.

Maximum permissible payload weight: nominal load and luggage load plus 150 lb (68 kg) multiplied by the number of seats in the vehicle.

#### Changing a wheel

Notes on selecting, installing and replacing tires

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may not recognize dangers.

You can ask for information regarding permitted wheel/tire combinations at an authorized Mercedes-Benz Center.

# WARNING Risk of accident due to incorrect dimensions of wheels and tires

If wheels and tires of the wrong size are installed, the wheel brakes or wheel suspension components may be damaged.

Always replace wheels and tires with those that fulfill the specifications of the original part.

When replacing wheels, make sure to fit the correct:

- Designation
- Model

When replacing tires, make sure to install the correct:

- Designation
- Manufacturer
- Model



WARNING Risk of injury through exceeding the specified tire load rating or the permissible speed rating

Exceeding the specified tire load rating or the permissible speed rating may lead to tire damage and to the tires bursting.

- Therefore, only use tire types and sizes approved for your vehicle model.
- Observe the tire load rating and speed rating required for your vehicle.
- NOTE Vehicle and tire damage through tire types and sizes that have not been approved

For safety reasons, only use tires, wheels and accessories which have been specially approved by Mercedes-Benz for your vehicle.

These tires are specially adapted to the control systems, such as ABS, ESP® and 4MATIC, and marked as follows:

• MO = Mercedes-Benz Original

• MO1 = Mercedes-Benz Original (only certain AMG tires)

Certain characteristics, such as handling, vehicle noise emissions, fuel consumption, etc. may otherwise be adversely affected. Furthermore, other tire sizes could result in the tires rubbing against the body and axle components when loaded. This could result in damage to the tire or the vehicle.

Only use tires, wheels and accessories that have been checked and recommended by Mercedes-Benz.

I NOTE Risk to driving safety from retreaded tires

Retreaded tires are neither tested nor recommended by Mercedes-Benz, since previous damage cannot always be detected on retreaded tires.

For this reason driving safety cannot be guaranteed.

- Do not use used tires if you have no information about their previous usage.
- I NOTE Possible damage to wheels or tires when driving over obstacles

Large wheels have a lower tire section width. The lower the tire section width, the greater is the risk of damage to wheels or tires when driving over obstacles.

- Avoid obstacles or drive particularly carefully.
- NOTE Damage to electronic component parts from the use of tire-mounting tools

Vehicles with a tire pressure monitoring system: Electronic component parts are located in the wheel. Tire-mounting tools should not be used in the area of the valve. This could otherwise damage the electronic component parts.

Have the tires changed at a qualified specialist workshop only. NOTE Damage to summer tires at low ambient temperatures

At low ambient temperatures, tears could form when driving with summer tires, causing permanent damage to the tires.

At temperatures below 45 °F (7 °C), use M+S tires .

Accessory parts that are not approved for your vehicle by Mercedes-Benz or are not being used correctly can impair the operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and inquire about:

- Suitability
- · Legal stipulations
- Factory recommendations

**WARNING** Risk of accident with high performance tires

The special tire tread in combination with the optimized tire compound means that the risk



of skidding or hydroplaning on wet roads is increased.

In addition, the tire grip is greatly reduced at a low outside temperature and tire running temperature.

- Switch on the ESP® and adapt your driving style accordingly.
- Use M+S tire at outside temperatures of less than 10 °C (50 °F).

Observe the following when selecting, installing and replacing tires:

- Only use tires and wheels of the same type (summer tires, winter tires, MOExtended tires) and the same make.
- Only install wheels of the same size on one axle (left and right).
  - It is only permissible to install a different wheel size in the event of a flat tire in order to drive to the specialist workshop.
- Only install tires of the correct size onto the wheels.

- Vehicles with a tire pressure monitoring system: All installed wheels must be equipped with functioning sensors for the tire pressure monitoring system.
- At temperatures below 45 °F (7 °C), use winter tires or all-season tires marked M+S for all wheels.

Winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

- For M+S tires, only use tires with the same tread.
- Observe the maximum permissible speed for the M+S tires installed.

If this is below the vehicle's maximum speed, this must be indicated by an appropriate label in the driver's field of vision.

- Break in new tires at moderate speeds for the first 60 miles (100 km).
- Replace the tires after six years at the latest, regardless of wear.

DEALER ePROCESS

When replacing with tires that do not feature run-flat characteristics: vehicles with MOExtended tires are not equipped with a TIREFIT kit at the factory. Equip the vehicle with a TIREFIT kit after replacing with tires that do not feature run-flat characteristics, e.g. winter tires.

For more information on wheels and tires, contact a qualified specialist workshop.

Be sure to also observe the following further related subjects:

- Notes on tire pressure ( page 375)
- Tire size designation, load-bearing capacity, speed rating and load index ( page 389)
- Tire pressure table ( page 377)

# Notes on rotating wheels

WARNING Risk of injury through different wheel sizes

Interchanging the front and rear wheels if the wheels or tires have different dimensions may severely impair the driving characteristics.

The wheel brakes or wheel suspension components may also be damaged.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

The wear patterns on the front and rear wheels differ:

- Front wheels wear more on the shoulder of the tire
- Rear wheels wear more in the center of the tire

On vehicles that have the same size front and rear wheels, rotate the wheels according to the intervals in the tire manufacturer's warranty

book in your vehicle documents. If this is not available, rotate the tires every

3,000 to 6,000 miles (5,000 to 10,000 km), depending on the wear. Ensure that the direction of rotation is maintained.

It is imperative to observe the instructions and safety notes on "Changing a wheel" when doing so Preparing the vehicle for a wheel change( $\longrightarrow$  page 398).

# Notes on storing wheels

When storing wheels, observe the following notes:

- After removing wheels, store them in a cool, dry and preferably dark place.
- Protect the tires from contact with oil, grease or fuel.

# Overview of the tire-change tool kit

Apart from some country-specific variants, vehicles are not equipped with a tire-change tool kit. For more information on which tire-change tools are required and approved for performing a


DEALER ePROCESS

wheel change on your vehicle, consult a qualified specialist workshop.

Required tire-change tools may include, for example:

- lack
- Chock
- · Lug wrench
- Alignment bolt

The tire-change tool kit is located under the trunk floor.



- Ratchet
- Alignment bolt

- 3 Jacking support
- Jack
- 6 Lug wrench
- 6 Folding chock

# Setting up the folding chock



#### Preparing the vehicle for a wheel change

#### Requirements:

- The required tire-change tool is available. If your vehicle is not equipped with the tirechange tool kit, consult a qualified specialist workshop to find out about suitable tools.
- The vehicle is not on a slope.
- The vehicle is on solid, non-slippery and level ground.
- Apply the electric parking brake manually.
- Move the front wheels to the straight-ahead position.
- Vehicles with automatic transmission: Shift into position P.
- Vehicles with level control system: Set the normal vehicle level (→ page 175).
- Switch off the engine.
- Make sure that the engine cannot be started.
- Place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.

- ► Raise the vehicle ( → page 399).

# Removing and installing hub caps

#### Requirements:


 The vehicle is prepared for a wheel change — page 398).

#### Plastic hub cap

- To remove: turn the center cover of the hub cap counter-clockwise and remove the hub cap.
- To install: make sure that the center cover of the hub cap is turned counter-clockwise.
- Position the hub cap and turn the center cover clockwise until the hub cap engages physically and audibly.



# Aluminum hub cap



- To remove: position socket ② on hub cap

  ①.
- (i) The socket can be found in the tire-change tool kit.
- Position wheel wrench 3 on socket 2.
- Using wheel wrench ③, turn hub cap ① counter-clockwise and remove it.
- ➤ To install: position hub cap and turn until it is completely flush with the wheel.
- Position socket ② on hub cap ①.

Attach wheel wrench (a) to socket (2) and tighten the hub cap clockwise.
 Specified tightening torque: 18 lb-ft (25 Nm).

# Raising the vehicle when changing a wheel

#### Requirements:


- There are no persons in the vehicle.
- The vehicle has been prepared for a wheel change ( page 398).
- The hub caps have been removed (→ page 398).

Important notes on using the jack:

- Use only the vehicle-specific jack that has been tested and approved by Mercedes-Benz to raise the vehicle.
- The jack is only designed for raising and holding the vehicle for a short time while a wheel is being changed and not for maintenance work under the vehicle.




- The jack must be placed on a firm, flat and non-slip surface. If necessary, use a large, flat, load-bearing, non-slip underlay.
- The foot of the jack must be positioned vertically under the jack support point.




Rules of conduct when the vehicle is raised:

- Never place your hands or feet under the vehicle.
- · Never lie under the vehicle.
- Do not start the engine and do not release the electric parking brake.
- Do not open or close any doors or the trunk lid.



Using the lug wrench, loosen the wheel bolts on the wheel you wish to change by about one full turn. Do not unscrew the bolts completely.



Position of jack support points

**WARNING** Risk of injury from incorrect positioning of the jack

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip with the vehicle raised.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically under the jacking point of the vehicle.

DEALER ePROCESS

NOTE Vehicle damage from the jack

If you do not position the jack correctly at the appropriate jack support point of the vehicle, the jack could tip over with the vehicle raised.

- The jack is designed exclusively for jacking up the vehicle at the jack support points.
- ➤ Take the ratchet out of the tire-change tool kit and place it on the hexagon nut of the jack so that the letters "AUF" are visible.

- Position jack 2 at jack support point 1.
- Turn ratchet (a) clockwise until jack (a) sits completely on jack support point (b) and the base of the jack lies evenly on the ground.
- Turn ratchet (a) until the tire is raised a maximum of 1.2 in (3 cm) from the ground.
- Loosen and remove the wheel (→ page 401).

# Removing a wheel

# Requirements:


• The vehicle is raised (——— page 399).

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may not recognize dangers.

When changing a wheel, avoid applying any force to the brake discs, since this could impair the level of comfort when braking.

- I NOTE Damage to threading from dirt on wheel bolts
- Do not place wheel bolts in sand or on a dirty surface.
- Unscrew the uppermost wheel bolt completely.





- Screw alignment bolt 1 instead of the wheel bolt into the threading.
- Unscrew the remaining wheel bolts fully.
- Remove the wheel.
- ► Install the new wheel (→ page 401).

# Mounting a new wheel

# Requirements:

The wheel is removed (→ page 401).

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may not recognize dangers.

# **WARNING** Risk of accident from losing a wheel

Oiled, greased or damaged wheel bolt/wheel nut threads or wheel hub/wheel mounting bolt threads can cause the wheel bolts/ wheel nuts to come loose.

As a result, you could lose a wheel while driving.

- Never oil or grease the threads.
- In the event of damage to the threads, contact a qualified specialist workshop immediately.
- Have the damaged wheel bolts or damaged hub threads replaced.
- ▶ Do not continue driving.

For tires with a specified direction of rotation, an arrow on the side wall of the tire indicates the correct direction of rotation. Observe the direction of rotation when installing.

Slide the wheel to be mounted onto the alignment bolt and push it on.

# A

**WARNING** Risk of injury from tightening wheel bolts and nuts

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip.

- Only tighten wheel bolts or wheel nuts when the vehicle is on the ground.
- Be sure to observe the instructions and safety notes on "Changing a wheel" (
  page 394).
- For safety reasons, only use wheel bolts which have been approved by Mercedes-Benz and for the wheel in question.
- NOTE Damage to paintwork of the wheel rim when screwing on the first wheel bolt

If the wheel has too much play when screwing in the first wheel bolt, the wheel rim paint can be damaged.


DEALER ePROCESS

- Press the wheel firmly against the wheel hub when screwing on the first wheel bolt.
- Tighten the wheel bolts evenly in a diagonal pattern in the order indicated until they are finger-tight.
- Unscrew the alignment bolt.
- Tighten the last wheel bolt until it is fingertight.
- Lower the vehicle ( page 402).

# Lowering the vehicle after a wheel change

#### Requirements:

- The new wheel has been installed ( page 401).
- Place the ratchet onto the hexagon nut of the jack so that the letters "AB" are visible.
- ➤ **To lower the vehicle:** turn the ratchet of the jack counter-clockwise.



➤ Tighten the wheel bolts evenly in a diagonal pattern in the order indicated ( to s).
Specified tightening torque: 111 lb-ft (150 Nm).

**WARNING** Risk of injury through incorrect tightening torque

The wheels could come loose if the wheel bolts or wheel nuts are not tightened to the prescribed tightening torque.

Make sure the wheel bolts or wheel nuts are tightened to the prescribed tightening torque.

- If you are not sure, do not move the vehicle. Consult a qualified specialist workshop and have the tightening torque checked immediately.
- Check the tire pressure of the newly mounted wheel and adjust accordingly.
- Vehicles with a tire pressure monitoring system: Restart the tire pressure monitoring system ( page 381).

Make sure to observe the following further related subject:

Notes on tire pressure (→ page 375)



#### Notes on technical data

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may not recognize dangers.

The data stated only applies to vehicles with standard equipment. You can obtain further information from an authorized Mercedes-Benz Center.

#### **Vehicle electronics**

Two-way radios

# Notes on installing two-way radios

**WARNING** Risk of accident due to improper work on two-way radios

The electromagnetic radiation from two-way radios can interfere with the on-board electronics if RF transmitters are manipulated or retrofitted incorrectly.

This could jeopardize the operating safety of the vehicle.

You should have all work on electrical and electronic components carried out at a qualified specialist workshop.

**WARNING** Risk of accident from incorrect operation of two-way radios

If you operate two-way radios incorrectly in the vehicle, the electromagnetic radiation could interfere with the on-board electronics, e.g.:

- if the two-way radio is not connected to an exterior antenna
- if the exterior antenna is not correctly mounted or is not of low reflection

This could jeopardies the operating safety of the vehicle.


- Have the low-reflection exterior antenna installed at a qualified specialist workshop.
- When operating two-way radios in the vehicle, always connect them to the low-reflection exterior antenna.

NOTE Invalidation of the operating permit due to failure to comply with the instructions for installation and use

The operating permit may be invalidated if the instructions for installation and use of two-way radios are not observed.

- Only use approved frequency bands.
- Observe the maximum permissible output power in these frequency bands.
- Only use approved antenna positions.





Front roof area

Rear roof area

Rear fenders

Trunk lid

On the rear fenders, it is recommended that you install the antenna on the side of the vehicle closest to the center of the road.

Use Technical Specification ISO/TS 21609 (Road Vehicles - "FMCs for installation of aftermarket radio frequency transmitting equipment") when retrofitting two-way radios. Comply with the legal requirements for detachable parts.

If your vehicle has installing for two-way radio equipment, use the power supply and antenna connectors provided in the pre-installation. Observe the manufacturer's supplements when installing.

# Two-way radio transmission output

The maximum transmission output (PEAK) at the base of the antenna must not exceed the values in the following table:

#### Frequency band and maximum transmission output

Frequency band	Maximum transmis- sion output
Short wave 3 - 54 MHz	100 W
4 m waveband 74 - 78 MHz	30 W
2 m waveband 144 - 174 MHz	50 W
Trunked radio system/Tetra 380 - 460 MHz	10 W
70 cm waveband 400 - 460 MHz	35 W
Two-way radio (2G/3G/4G)	10 W



The following can be used in the vehicle without restrictions:

- RF transmitters with a maximum transmission output of up to 100 mW
- RF transmitters with transmitter frequencies in the 380 - 410 MHz waveband and a maximum transmission output of up to 2 W (trunked radio system/Tetra)
- Mobile phones (2G/3G/4G)


There are no restrictions when positioning the antenna on the outside of the vehicle for some wavebands.


This applies to the following wavebands:

- Trunked radio system/Tetra
- 70 cm waveband
- 2G/3G/4G

# Vehicle identification plate, VIN and engine number overview

# Vehicle identification plate





Vehicle identification plate (USA only)

- Permissible gross weight
  - Permissible front axle load
  - Permissible rear axle load
  - Paint code
  - VIN (vehicle identification number)






Vehicle identification plate (Canada only)

- Permissible gross weight
- Permissible front axle load
- Permissible rear axle load
- Paint code
- VIN (vehicle identification number)

The permissible gross vehicle weight is made up of the vehicle weight, all vehicle occupants, the fuel and the load. The maximum gross axle weight rating is the maximum weight that can be carried on one axle (front or rear axle).

Never exceed the permissible gross vehicle weight or the maximum gross axle weight rating for the front or rear axle.


#### VIN in front of the front seat



VIN (vehicle identification number)



#### Additional plates




- Plate with information about emissions testing, including confirmation of emissions guidelines at the U.S. federal level as well as for California
- VIN (vehicle identification number)
- Engine number (stamped into the crankcase)

# **Operating fluids**

# Notes on operating fluids

**Mercedes-AMG vehicles:** observe the notes in the Supplement. Otherwise, you may fail to recognize dangers.



Operating fluids may be poisonous and harmful to your health.

- Observe the text on the original containers when using, storing or disposing of operating fluids.
- Always store operating fluids sealed in their original containers.
- Always keep children away from operating fluids.

# **WARNING** Risk of fire or explosion from fuel

Fuels are highly flammable.

- Fire, open flames, smoking and creation of sparks must be avoided.
- Switch off the ignition and, if available, the stationary heater, before and while refueling the vehicle.

# **WARNING** Risk of injury from fuels

Fuels are poisonous and hazardous to your health.

- Do not swallow fuel or let it come into contact with skin, eyes or clothing.
- Do not inhale fuel vapor.
- Keep children away from fuel.
- Keep doors and windows closed during the refueling process.

If you or other people come into contact with fuel, observe the following:

- Immediately rinse fuel off your skin with soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thor-

- oughly with clean water. Seek medical attention immediately.
- If you swallow fuel, seek medical attention immediately. Do not induce vomiting.
- ► Change immediately out of clothing that has come into contact with fuel.
- ENVIRONMENTAL NOTE Environmental pollution caused by environmentally irresponsible disposal
- Dispose of operating fluids in an environmentally responsible manner.

Operating fluids include the following:

- Fuels
- Lubricants
- Coolant
- Brake fluid
- · Windshield washer fluid
- Climate control system refrigerant



Only use products approved by Mercedes-Benz.

You can identify operating fluids approved by Mercedes-Benz by the following inscriptions on the container:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB-Approval (e.g. MB-Approval 229.51)

Further information on approved operating fluids:

- in the Mercedes-Benz Specifications for Operating Fluids at http://bevo.mercedesbenz.com (by entering the designation)
- in the Mercedes-Benz Specifications for Operating Fluids in the Mercedes-Benz BeVo app (by entering the designation)
- · at a qualified specialist workshop

#### **Fuel**

Notes on fuel grades for vehicles with a gasoline engine

Observe the notes on operating fluids (——) page 408).

NOTE Damage caused by the wrong fuel

Even small amounts of the wrong fuel could result in damage to the fuel system, the engine and the emission control system.

Only refuel with low-sulfur unleaded fuel.

This fuel may contain up to 10% ethanol by volume. Your vehicle is suitable for use with E10 fuel.

Never refuel with one of the following fuels:

- Diesel
- Gasoline with more than 10% ethanol by volume, e.g. E15, E85, E100
- Gasoline with more than 3% methanol by volume, e.g. M15, M30, M85, M100
- Gasoline with additives containing metal

If you have accidentally refueled with the wrong fuel:

- Do not switch on the ignition.
- Consult a qualified specialist workshop.

If the available fuel is not sufficiently low in sulfur, this can produce unpleasant odors.

If you want maximum engine output: only refuel with unleaded premium grade gasoline with at least 91 AKI/95 RON.

As a temporary measure, if the recommended fuel is not available, you may also use unleaded regular gasoline with an octane number of at least 87 AKI/91 RON.

NOTE Premature wear through unleaded regular gasoline

Unleaded regular gasoline can cause the engine to wear more quickly and impair longevity and performance.

If unleaded premium grade gasoline is unavailable and you have to refuel using unleaded regular gasoline with 87 AKI/91 RON:



- Only fill the fuel tank to half full with unleaded regular gasoline and top up as soon as possible with unleaded premium grade gasoline.
- Do not drive at the maximum speed.
- Avoid sudden acceleration and engine speeds over 3000 rpm.

This may reduce engine performance and increase fuel consumption. Never refuel using gasoline with a lower octane number.

Further information on fuel can be found:

- at a gas station
- at a qualified specialist workshop
- USA only: at http://www.mbusa.com

NOTE Damage from use of unsuitable additives

Even small amounts of the wrong additive may lead to malfunctions occurring.

Only add cleaning additives recommended by Mercedes-Benz to the fuel.

Mercedes-Benz recommends that you use fuel brands that have additives.

In some countries, the fuel available may not have sufficient additives. Residue could build up in the fuel injection system as a result. In this case, in consultation with an authorized Mercedes-Benz Center, the fuel may be mixed with the cleaning additive recommended by Mercedes-Benz. Be sure to observe the notes and mixing ratios specified on the container.

#### Tank content and fuel reserve

The total capacity of the fuel tank may vary, depending on the vehicle equipment.



Model	Total capacity
S 560 4MATIC	21.1 gal (80.0 liters)
Model	Of which reserve
S 560 4MATIC	2.1 gal (8.0 liters)

# **Engine oil**

#### Notes on engine oil



- **NOTE** Engine damage caused by an incorrect oil filter, incorrect oil or additives
- ▶ Do not use engine oils or oil filters other than those which meet the specifications necessary for the prescribed service intervals.
- Do not alter the engine oil or oil filter in order to achieve longer change intervals than prescribed.
- Do not use additives
- Have the engine oil changed after the prescribed intervals.

Mercedes-Benz recommends that you have the oil change carried out at a qualified specialist workshop.

Further information on engine oil and oil filters is available at the following locations:

- In the Mercedes-Benz Specifications for Operating Fluids by entering the designation:
  - At http://bevo.mercedes-benz.com
  - In the Mercedes-Benz BeVo app

at a qualified specialist workshop

# Quality and capacity of engine oil

# MB-Freigabe or MB-Approval

Model	MB-Freigabe or MB- Approval
S 560 4MATIC	229.52, 229.61

The following values refer to an oil change, including the oil filter.

# Capacity

Model	Capacity	
S 560 4MATIC	9.5 US qt (9.0 liters)	

#### Notes on brake fluid

Observe the notes on operating fluids → page 408).



WARNING Risk of an accident due to vapor pockets forming in the brake system

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point is too low, vapor pockets may form in the brake system when the brakes are applied hard.

This causes the braking effect to be impaired.

Have the brake fluid renewed at the specified intervals.

Have the brake fluid regularly replaced at a qualified specialist workshop.

Only use brake fluid approved by Mercedes-Benz according to MB-Freigabe or MB-Approval 331.0.

You can obtain further information on brake fluid in the following places:

- in the Mercedes-Benz Specifications for **Operating Fluids** 
  - at http://bevo.mercedes-benz.com
  - in the Mercedes-Benz BeVo App

· at a qualified specialist workshop

#### Coolant

#### Notes on coolant

**WARNING** - Risk of fire and injury from antifreeze

If antifreeze comes into contact with hot component parts in the engine compartment, it may ignite.

- Allow the engine to cool down before adding antifreeze.
- Make sure that no antifreeze spills out next to the filler opening.
- Thoroughly clean off any antifreeze from component parts before starting the vehicle.

- NOTE Damage caused by incorrect coolant
- Only add coolant that has been premixed with the required antifreeze protection.

Information on coolant is available at the following locations:

- In the Mercedes-Benz Specification for Operating Fluids 310.1
  - At http://bevo.mercedes-benz.com
  - In the Mercedes-Benz BeVo app
- At a qualified specialist workshop
- NOTE Overheating at high outside temperatures

If an inappropriate coolant is used, the engine cooling system is not sufficiently protected against overheating and corrosion at high outside temperatures.

DEALER ePROCESS

Always use coolant approved by Mercedes-Benz.

Observe the instructions in the Mercedes-Benz Specifications for Operating Fluids 310.1.

Have the coolant regularly replaced at a qualified specialist workshop.

The proportion of corrosion inhibitor/antifreeze concentrate in the engine cooling system should be:

- a minimum of 50% (antifreeze protection down to approximately -35 °F (-37 °C))
- a maximum of 55% (antifreeze protection down to -49 °F (-45 °C))

# Coolant capacity

Model Capacity	
S 560 4MATIC	15.0 US qt (14.2 I)

#### Notes on windshield washer fluid

Observe the notes on operating fluids (

page 408).

**WARNING** - Risk of fire and injury from windshield washer concentrate

Windshield washer concentrate is highly flammable. It could ignite if it comes into contact with hot engine component parts or the exhaust system.

- Make sure that no windshield washer concentrate spills out next to the filler opening.
- I NOTE Blocked spray nozzles caused by mixing windshield washer fluids
- Do not mix MB SummerFit and MB WinterFit with other windshield washer fluids.

Do not use distilled or de-ionized water as the fill level sensor may be triggered erroneously.

- Recommended windshield washer fluid:

   Above freezing point: e.g. MB SummerFit
- Below freezing point: e.g. MB WinterFit

For the correct mixing ratio, refer to the information on the antifreeze container.

Mix the washer fluid with the windshield washer fluid all year round.

# Refrigerant

#### Notes on refrigerants

Observe the notes on operating fluids (→ page 408).

NOTE Damage due to incorrect refrigerant

If a non-approved refrigerant is used, the climate control system may be damaged.

- Only use the refrigerant R-134a
- NOTE Damage to the climate control system due to incorrect refrigerant compressor oil
- Only use refrigerant compressor oil that has been approved by Mercedes-Benz.

 Do not mix the approved refrigerant compressor oil with a different refrigerant compressor oil.

Work on the climate control system may be carried out only by a qualified specialist workshop. All applicable regulations, as well as SAE standard J639, must be adhered to.



- Warning symbols
- Refrigerant filling capacity
- 3 Applicable standards
- PAG oil part number
- Sefrigerant type



Warning symbols (1) advise you about:

- Possible dangers
- Having service work carried out at a qualified specialist workshop

# Refrigerant filling capacity and PAG oil

Model	Refrigerant
S 560 4MATIC	$23.3 \pm 0.4$ oz $(660 \pm 10 \text{ g})$

Model	PAG oil
S 560 4MATIC	$3.9 \pm 0.4 \text{ oz}$ (110 ± 10 g)


#### Vehicle data

#### Vehicle dimensions

The heights specified may vary as a result of the:

- Tires
- Load
- Condition of the suspension

• Optional equipment



#### Height when opened



#### Vehicle dimensions

S 560 4MATIC	
Vehicle length	198.1 in (5032 mm)
Vehicle width including exterior mirrors	83.0 in (2108 mm)
Vehicle width without exterior mirrors	74.8 in (1899 mm)
Vehicle height	55.6 in (1411 mm)
Wheelbase	115.9 in (2945 mm)
Turning radius	38.1 ft (11.60 m)

# Weights and loads

Please note that for the specified vehicle data:

• items of optional equipment increase the curb weight and reduce the payload.

# **Roof load**

Maximum roof load	
S 560 4MATIC	0 lb (0 kg)



# Introduction

#### Notes on display messages

Display messages appear on the multifunction display.

Display messages with graphic symbols are simplified in the Operator's Manual and may differ from the symbols on the multifunction display. The multifunction display shows high-priority display messages in red. Certain display messages are accompanied by a warning tone.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

For some display messages, a symbol is also shown:

Further information

Hide display message

You can select the desired symbol by swiping left or right on the left-hand Touch Control. Press the i symbol to show further information on the multifunction display. Press the symbol to hide the display message.

You can hide low-priority display messages by pressing the figure button or the left-hand Touch Control. The display messages are then stored in the message memory.

Rectify the cause of a display message as quickly as possible.

High-priority display messages cannot be hidden. The multifunction display shows these display messages continuously until the cause of the message has been rectified.

# Calling up stored display messages

On-board computer:

¬→ Service → 1 Message

If there are no display messages. No Messages appears on the multifunction display.

- Scroll through the display messages by swiping upwards or downwards on the left-hand Touch Control.
- To exit the message memory: press the r button.



#### Safety systems

# Display messages Possible causes / consequences and ▶ Solutions \* ESP® is temporarily unavailable. Other driving systems and driving safety systems may also malfunction. **WARNING** Risk of skidding if ESP® is malfunctioning Currently Unavailable See Operator's Manual If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off. Drive on carefully. Have ESP® checked at a qualified specialist workshop. Carefully drive on a suitable stretch of road, making slight steering movements at a speed above 19 mph (30 km/h).If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully. \* The red PARK (USA only) or (P) indicator lamp (Canada only) is lit. **PARK** You have attempted to release the electric parking brake with the ignition switched off. Switch the ignition on. (USA only)



DEALER ePROCESS

# Display messages or To apply: To release: continues to flash:

Possible causes/consequences and > Solutions

► Release the electric parking brake automatically (→→ page 148).

If it is still not possible to release the electric parking brake:

Do not continue driving under any circumstances. Consult a qualified specialist workshop.

The yellow (P) indicator lamp is lit and the red PARK (USA only) or (P) (Canada only) indicator lamp is flashing. The electric parking brake is malfunctioning.

The electric parking brake could not be applied or released.

Switch off the ignition and switch it back on.

 $\triangleright$  Release and then apply the electric parking brake manually ( $\longrightarrow$  page 149).

Apply and then release the electric parking brake manually.

If the electric parking brake cannot be applied or the red PARK (USA only) or (Canada only) indicator lamp

- Do not continue driving under any circumstances. Consult a qualified specialist workshop.
- Where necessary, also safeguard the parked vehicle against rolling away.

The yellow ( indicator lamp is on and the red PARK indicator lamp (USA only) or the ( indicator lamp (Canada only) flashes for approximately ten seconds after the electric parking brake has been applied or released. It then remains lit or goes out. The electric parking brake is malfunctioning.

#### Possible causes/consequences and ▶ Solutions

#### If the battery charge level is too low:

► Charge the battery.

#### To apply:

Switch off the ignition.

The electric parking brake is applied automatically.

If the electric parking brake should not be applied, e.g. when washing the vehicle in an automatic car wash or when having the vehicle towed, leave the ignition switched on. This does not include having the vehicle towed with the rear axle raised.

If the electric parking brake is not applied automatically:

- Switch off the ignition and switch it back on.
- ▶ Release and then apply the electric parking brake manually (→→ page 149).


If it is still not possible to apply the electric parking brake:

- Visit a qualified specialist workshop.
- Where necessary, also safeguard the parked vehicle against rolling away.

#### To release:

Display messages	Possible causes/consequences and ▶ Solutions
	If it is still not possible to release the electric parking brake:  Do not continue driving under any circumstances. Consult a qualified specialist workshop.
PARK (USA only)	<ul> <li>* The red PARK (USA only) or ((a) (Canada only) indicator lamp flashes.</li> <li>The electric parking brake is applied while you are driving:</li> <li>• A condition for automatic release of the electric parking brake is not fulfilled ( page 148).</li> <li>• You are performing emergency braking using the electric parking brake ( page 149).</li> </ul>
(Canada only) Please Release Parking Brake	<ul> <li>Check that the conditions for automatic release of the electric parking brake are fulfilled.</li> <li>Release the electric parking brake manually.</li> </ul>





Inoperative See Operator's Manual

BRAKE

(USA only)



# Possible causes/consequences and ▶ Solutions

 $^{\star}$  EBD, ABS and ESP  $\!^{\rm \tiny (\!R\!)}$  are malfunctioning.

Other driving systems and driving safety systems may also malfunction.

**A** WARNING Risk of skidding if EBD, ABS and ESP® are malfunctioning

If EBD, ABS and ESP® are malfunctioning, the wheels can lock when braking and ESP® cannot carry out vehicle stabilization.

The steering capability and braking characteristics are thus severely impaired. The braking distance in an emergency braking situation can increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- ► Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Visit a qualified specialist workshop immediately.
- \* There is insufficient brake fluid in the brake fluid reservoir.

**A** WARNING Risk of an accident due to low brake fluid level

If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.

Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.

DEALER EPROCESS



Currently Unavailable See Operator's Manual

# Possible causes / consequences and ▶ Solutions

ABS and ESP® are temporarily unavailable.

Other driving systems and driving safety systems may also be temporarily unavailable.

The brake system continues to operate normally. The braking distance in an emergency braking situation can increase.

# **A** WARNING Risk of skidding if ABS and ESP® are malfunctioning

If ABS and ESP® are malfunctioning, the wheels could lock when braking and ESP® cannot carry out vehicle stabilization.

The steering capability and braking characteristics are thus severely impaired. The braking distance in an emergency braking situation can increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have ABS and ESP® checked immediately at a qualified specialist workshop.
- Carefully drive on a suitable stretch of road, making slight steering movements at a speed above 19 mph (30 km/h).
- If the display message does not disappear, consult a qualified specialist workshop immediately. Drive carefully.





Inoperative See Operator's Manual

# Possible causes / consequences and ▶ Solutions

\* ABS and ESP® are malfunctioning.

Other driving systems and driving safety systems may also malfunction.

The brake system continues to operate normally. The braking distance in an emergency braking situation can increase.

**A WARNING** Risk of skidding if ABS and ESP® are malfunctioning

If ABS and ESP® are malfunctioning, the wheels could lock when braking and ESP® cannot carry out vehicle stabilization.

The steering capability and braking characteristics are thus severely impaired. The braking distance in an emergency braking situation can increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- ► Have ABS and ESP® checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Visit a qualified specialist workshop immediately.



Other driving systems and driving safety systems may also malfunction.

DEALER EPROCESS

The brake system continues to operate normally. The braking distance in an emergency braking situation can increase.



Display messages	Possible causes/consequences and ▶ Solutions
	<b>▲ WARNING</b> Risk of skidding if ESP <sup>®</sup> is malfunctioning
	If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.
	▶ Drive on carefully.
	► Have ESP <sup>®</sup> checked at a qualified specialist workshop.
	▶ Drive on carefully.
	Visit a qualified specialist workshop immediately.
* The restraint system is defective (	
	▲ WARNING Risk of injury or fatal injury due to a malfunction in the restraint system
SRS Malfunction Service Required	If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or might not be triggered at all in the event of an accident. This may affect the Emergency Tensioning Device or airbag, for example.
	► Have the restraint system checked and repaired immediately at a qualified specialist workshop.
	Detection of a restraint system malfunction:
	• The prestraint system warning lamp does not light up when the ignition is switched on.
	<ul> <li>The restraint system warning lamp lights up continuously or repeatedly during a journey.</li> <li>Visit a qualified specialist workshop immediately.</li> </ul>



Front Left Malfunction Service Required (Example)

#### Possible causes/consequences and > Solutions

\* The corresponding restraint system is malfunctioning (——— page 29).

**A WARNING** Risk of injury or fatal injury due to a malfunction in the restraint system

If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or might not be triggered at all in the event of an accident. This may affect the Emergency Tensioning Device or airbag, for example.

▶ Have the restraint system checked and repaired immediately at a qualified specialist workshop.

Detection of a restraint system malfunction:

- The prestraint system warning lamp does not light up when the ignition is switched on.
- The prestraint system warning lamp lights up continuously or repeatedly during a journey.
- Visit a qualified specialist workshop immediately.
- \* The corresponding window curtain airbag is malfunctioning (\(\bigsim\) page 29).

**A WARNING** Risk of injury or fatal injury due to malfunctions in the window airbag

If the window airbag is malfunctioning, it might be triggered unintentionally or might not be triggered at all in the event of an accident with high deceleration.

- Have the window airbag checked and repaired immediately at a qualified specialist workshop.
- Visit a qualified specialist workshop immediately.



Left Side Curtain Airbag Malfunction Service Required (Example)



# Display messages Front Passenger Airbag **Enabled See Operator's** Manual

# Possible causes/consequences and ▶ Solutions

- \* The front passenger airbag and knee airbags are enabled during the journey:
  - even when a child, a small adult or an object weighing less than the system weight threshold is located on the front passenger seat
  - · even when the front passenger seat is not occupied

The system may detect objects or forces that are adding to the weight applied to the seat.

**WARNING** Risk of injury or fatal injury when using a child restraint system while the front passenger air bag is enabled

If you secure a child in a child restraint system on the front passenger seat and the front passenger air bag is enabled, the front passenger air bag can deploy in the event of an accident.

The child could be struck by the air bag.

▶ Ensure, both before and during the journey, that the status of the front passenger air bag is correct.

NEVER use a rearward facing child restraint on a seat protected by an ACTIVE FRONT AIR BAG; DEATH or SERI-OUS INJURY to the CHILD can occur.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- Check the status of the automatic front passenger airbag shutoff ( page 40).
- If necessary, consult a qualified specialist workshop immediately.



Display messages	Possible causes/consequences and ▶ Solutions	
Front Passenger Airbag Dis- abled See Operator's Man- ual	* The front passenger airbag and the knee airbag are deactivated, although an adult or a person with an adult stature is on the front passenger seat. If additional forces are applied to the seat, the weight the system detects may be too low.	
	▲ WARNING Risk of injury or fatal injury due to a disabled front passenger airbag	
	If the front passenger airbag is disabled, the front passenger airbag will not be deployed in the event of an accident and cannot perform its intended protective function.	
	A person in the front passenger seat could then, for example, come into contact with the vehicle's interior, especially if the person is sitting too close to the cockpit.	
	Make sure, both before and during the journey, that the status of the front passenger airbag is correct.	
	<ul> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Check the status of the automatic front passenger airbag shutoff ( page 40).</li> <li>If necessary, consult a qualified specialist workshop immediately.</li> </ul>	
Active Brake Assist Functions Limited See Opera-	* <b>Vehicles with Driving Assistance Package:</b> Active Brake Assist with cross-traffic function, Evasive Steering Assist or PRE-SAFE® PLUS is malfunctioning.	
tor's Manual	<ul><li>Vehicles without Driving Assistance Package: Active Brake Assist is malfunctioning.</li><li>Visit a qualified specialist workshop.</li></ul>	
	* Vehicles with the Driving Assistance Package: Active Brake Assist with cross-traffic function, Evasive Steering Assist or PRE-SAFE® PLUS are temporarily unavailable or only partially available.	

DEALER ePROCESS

Display messages	Possible causes/consequences and ▶ Solutions
Active Brake Assist Functions Currently Limited See Operator's Manual	<ul> <li>Vehicles without the Driving Assistance package: Active Brake Assist is temporarily unavailable.</li> <li>The ambient conditions are outside the system limits.</li> <li>Drive on. As soon as the ambient conditions are within the system limits, the system will become available again.</li> <li>If the display message does not disappear, stop the vehicle while paying attention to road and traffic conditions and restart the engine.</li> </ul>
PRE-SAFE Inoperative See Operator's Manual	* PRE-SAFE® functions are malfunctioning.  Visit a qualified specialist workshop.
Mercedes me connect Services Limited See Oper- ator's Manual	<ul> <li>* Service limited.</li> <li>At least one of the main functions of the Mercedes me connect system is malfunctioning.</li> <li>Observe the notes on the diagnostics connection (————————————————————————————————————</li></ul>
Inoperative	<ul> <li>* At least one main function of the Mercedes me connect system or of the SOS emergency call system is malfunctioning.</li> <li>Visit a qualified specialist workshop.</li> </ul>
Check Brake Pads See Operator's Manual	* The brake pads have reached the wear limit.

DEALER ePROCESS

Display messages	Possible causes/consequences and ▶ Solutions
	▲ WARNING Risk of accident due to restricted braking power
	When the brake pads have reached their wear limit, the braking power may be restricted.  Drive on carefully.
	Have the brake system checked immediately at a qualified specialist workshop.
	Visit a qualified specialist workshop.

# **Driving systems**

Display messages	Possible causes/consequences and ▶ Solutions
Active Blind Spot Asst. Not Available When Towing a Trailer See Operator's Man- ual	* When you establish the electrical connection to the trailer, Active Blind Spot Assist is unavailable.  Press the left-hand Touch Control and acknowledge the display message.
Drive More Slowly	<ul> <li>* You are driving too fast for the selected vehicle level.</li> <li>In order to adjust the vehicle level, you must not drive at speeds greater than 50 mph (80 km/h).</li> <li>In order to adjust the vehicle level during trailer operation, you must not drive at speeds greater than 19 mph (30 km/h).</li> </ul>
	* Blind Spot Assist is temporarily unavailable.

Display messages	Possible causes/consequences and ▶ Solutions
Blind Spot Assist Currently Unavailable See Operator's Manual	<ul> <li>The system limits have been reached ( page 203).</li> <li>Drive on.</li> <li>Once the cause of the problem is no longer present, the system will be available again.</li> <li>If the display message does not disappear, stop the vehicle while paying attention to road and traffic conditions and restart the engine.</li> <li>If necessary, clean the rear bumper. If the bumper is extremely dirty, the sensors in the bumper may be malfunctioning.</li> </ul>
Active Steering Assist Inoperative	* Active Steering Assist is malfunctioning. Active Distance Assist DISTRONIC remains available.  Visit a qualified specialist workshop.
Vehicle Rising Please Wait	* The vehicle level is too low. The vehicle is raised to the selected vehicle level.  Note: Wait until the display message disappears before pulling away.
Blind Spot Assist Inoperative	<ul> <li>* Blind Spot Assist is malfunctioning.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>

Display messages	Possible causes/consequences and ▶ Solutions
Active Parking Assist and PARKTRONIC Inoperative See Operator's Manual	<ul> <li>* Active Parking Assist and Parking Assist PARKTRONIC are malfunctioning.</li> <li>Stop the vehicle, paying attention to road and traffic conditions, and restart the engine.</li> <li>If the display message continues to be displayed, consult a qualified specialist workshop.</li> </ul>
Active Blind Spot Assist Currently Unavailable See Operator's Manual	<ul> <li>* Active Blind Spot Assist is temporarily unavailable.</li> <li>The system limits have been reached ( &gt;&gt; page 203).</li> <li>Drive on. Once the cause of the problem is no longer present, the system will be available again.</li> <li>If the display message does not disappear, stop the vehicle while paying attention to road and traffic conditions and restart the engine.</li> </ul>
Active Steering Assist Currently Unavailable See Operator's Manual	<ul> <li>* Active Steering Assist is temporarily unavailable.</li> <li>The ambient conditions are outside the system limits ( page 167).</li> <li>Drive on. As soon as the ambient conditions are within the system limits, the system will become available again. </li> <li>If necessary, clean the windshield in the camera's field of vision.</li> <li>Check the tire pressure if necessary.</li> </ul>
<u>\$\$\$</u>	* ATTENTION ASSIST has detected fatigue or an increasing lack of concentration on the part of the driver ( >> page 197).  If necessary, take a break.

Display messages	Possible causes/consequences and ▶ Solutions
ATTENTION ASSIST: Take a Break!	
Traffic Sign Assist Inopera- tive	<ul><li>* Traffic Sign Assist is malfunctioning.</li><li>Visit a qualified specialist workshop.</li></ul>
Active Lane Keeping Assist Currently Unavailable See Operator's Manual	* Active Lane Keeping Assist is temporarily unavailable. The ambient conditions are outside the system limits (————————————————————————————————————
	<ul> <li>* Active Steering Assist has reached its system limits.</li> <li>Take over the steering and drive on in accordance with the traffic conditions.</li> </ul>
	* Traffic Sign Assist is temporarily unavailable.

Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.

Display messages	Possible causes/consequences and ▶ Solutions
	Clean the windshield.
Active Lane Keeping Assist Inoperative	<ul> <li>* Active Lane Keeping Assist is malfunctioning.</li> <li>Consult a qualified specialist workshop.</li> </ul>
<b>))))</b>	* AIRMATIC is functioning only to a limited extent. The vehicle's handling characteristics may be affected.
	NOTE The tires of the front axle or the front fenders could be damaged by large steering movements
Malfunction Drive at Max. 50 mph	Avoid large steering movements while driving and listen for scraping sounds.
30 mpn	If you hear scraping sounds, pull over and stop the vehicle safely, paying attention to road and traffic conditions, and set a higher vehicle level if possible.
	<ul> <li>Drive in a manner appropriate for the current level, but do not exceed 50 mph (80 km/h).</li> <li>Visit a qualified specialist workshop.</li> </ul>
	Active Body Control is malfunctioning. The vehicle's handling characteristics may be affected.
	NOTE The tires of the front axle or the front fenders could be damaged by large steering movements
	Avoid large steering movements while driving and listen for scraping sounds.
	If you hear scraping sounds, pull over and stop the vehicle safely, paying attention to road and traffic conditions, and set a higher vehicle level if possible.
	Do not drive at speeds greater than 50 mph (80 km/h).
	DEALER @PROCESS

Display messages	Possible causes/consequences and ▶ Solutions
	Visit a qualified specialist workshop.
Blind Spot Assist Not Avail- able When Towing a Trailer See Operator's Manual	* When you establish the electrical connection to the trailer, Blind Spot Assist is unavailable.  Press the left-hand Touch Control and acknowledge the display message.
	* You have pulled away despite the vehicle level being too low.
Ø <b>◆</b> 0	Pull over and stop the vehicle, paying attention to road and traffic conditions. The vehicle is raised to the selected vehicle level.
Stop Vehicle Vehicle Too Low	➤ Wait until the display message disappears before pulling away.  If the display message does not disappear and a warning tone also sounds, AIRMATIC is malfunctioning:
	Do not drive faster than 50 mph (80 km/h) and consult a qualified specialist workshop immediately.
	I NOTE The tires of the front axle or the front fenders could be damaged by large steering movements
	<ul> <li>Avoid large steering movements while driving and listen for scraping sounds.</li> <li>If you hear scraping sounds, pull over and stop the vehicle safely, paying attention to road and traffic conditions, and set a higher vehicle level if possible.</li> </ul>
	➤ Set a higher vehicle level (→ page 175).  Depending on the malfunction, the vehicle is raised.

Display messages	Possible causes/consequences and ▶ Solutions
Max. Speed 22 mph	* The vehicle has been set to transport level. Transport level is not a permissible driving level. Only suitable for transporting the vehicle.  Do not drive faster than 22 mph (35 km/h).
Lowering	<ul> <li>* The vehicle level may be lowered for the following reasons:</li> <li>you have selected a different drive program.</li> <li>you have exceeded a critical speed.</li> <li>you have changed the vehicle level by pressing a button.</li> </ul>
ATTENTION ASSIST Inoperative	* ATTENTION ASSIST is malfunctioning.  Consult a qualified specialist workshop.
Active Blind Spot Assist Inoperative	<ul> <li>* Active Blind Spot Assist is malfunctioning.</li> <li>Visit a qualified specialist workshop.</li> </ul>
Off	* Active Distance Assist DISTRONIC was deactivated. If a warning tone also sounds, the Active Distance Assist DISTRONIC has deactivated automatically ( page 163).

Display messages	Possible causes/consequences and ▶ Solutions
<b>⊘10</b>	* The vehicle level is too low. The vehicle is raised to the selected vehicle level.  Wait until the display message disappears before pulling away.
ABC Vehicle Rising Please Wait Briefly	
Road Surface Scan Inoperative	<ul> <li>* The ROAD SURFACE SCAN is malfunctioning.</li> <li>Drive on carefully.</li> <li>Visit a qualified specialist workshop.</li> </ul>
ABC Malfunction Stop Vehicle	<ul> <li>* Active Body Control is malfunctioning.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Consult a qualified specialist workshop.</li> </ul>
mph	* Active Distance Assist DISTRONIC cannot be activated as not all activation conditions have been fulfilled.  Comply with the activation conditions of Active Distance Assist DISTRONIC (————) page 163).
	* If you activate the accelerator pedal beyond the Active Distance Assist DISTRONIC setting, the system will be put into passive mode ( page 171).

Display messages	Possible causes/consequences and ▶ Solutions
Suspended	
Active Distance Assist Cur- rently Unavailable See Operator's Manual	<ul> <li>* Active Distance Assist DISTRONIC is temporarily unavailable.</li> <li>The ambient conditions are outside the system limits (————————————————————————————————————</li></ul>
Active Distance Assist Inoperative	<ul> <li>* Active Distance Assist DISTRONIC is malfunctioning.</li> <li>Other driving systems and driving safety systems may also malfunction.</li> <li>Visit a qualified specialist workshop.</li> </ul>
Active Distance Assist Now Available	* Active Distance Assist DISTRONIC is operational again and can be activated (———> page 163).
mph	<ul> <li>* Cruise control cannot be activated as not all activation conditions are fulfilled.</li> <li>Dobserve the activation conditions for cruise control (————————————————————————————————————</li></ul>
Cruise Control Off	* Cruise control has been deactivated.  If there is an additional warning tone, cruise control has been deactivated automatically (———> page 159).
Cruise Control Inoperative	<ul> <li>* Cruise control is malfunctioning.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>

#### Display messages

Active Lane Keeping Assist Camera View Restricted See Operator's Manual

#### Possible causes / consequences and ▶ Solutions

- \* Vehicles without Active Steering Assist: the camera view is restricted.
- Possible causes are:
- dirt on the windshield in the camera's field of vision
- · heavy rain, snow or fog

Driving systems and driving safety systems may be malfunctioning or temporarily unavailable.

Once the cause of the problem is no longer present, driving systems and driving safety systems will be available again.

If the display message does not disappear:

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- Clean the windshield.

#### Engine

### Display messages



See Operator's Manual

# Possible causes/consequences and ▶ Solutions

- \* The battery is not being charged.
  - **NOTE** Possible engine damage if you continue driving
  - Do not continue driving under any circumstances.

Display messages	Possible causes/consequences and ▶ Solutions
	Consult a qualified specialist workshop.
	<ul> <li>Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.</li> <li>Consult a qualified specialist workshop.</li> </ul>
	* The battery charge level is too low.
- +	Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
Stop Vehicle Leave Engine	➤ Leave the engine running.
Running	➤ Wait until the display message disappears before pulling away.
Check Coolant Level See	* The coolant level is too low.
Operator's Manual	NOTE Engine damage due to insufficient coolant
	Avoid long journeys with insufficient coolant.
	➤ Add coolant (—→ page 341).
	* There has been pressure loss in the fuel system. The fuel filler cap is not closed correctly or the fuel system is leaking.
V	Close the fuel filler cap.
Gas Cap Loose	If the fuel filler cap was already properly closed: consult a qualified specialist workshop.

#### Display messages





Coolant Too Hot Stop Vehicle Turn Engine Off

# Possible causes/consequences and ▶ Solutions

- \* The fan motor is defective.
  - Avoiding high loads on the engine, drive to the nearest qualified specialist workshop. In doing so, ensure that the coolant temperature display remains below the red marking.
- \* The coolant is too hot.
- Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.

# ▲ WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- ▶ Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.
- Wait until the engine has cooled down.
- Make sure that the air supply to the radiator is not obstructed.
- Avoiding high loads on the engine, drive to the nearest qualified specialist workshop. In doing so, ensure that the coolant temperature display remains below the red marking.



# Engine oil

Display messages	Possible causes/consequences and ▶ Solutions
متح	<ul> <li>* The electrical connection to the oil level sensor has been interrupted or the oil level sensor is faulty.</li> <li>Consult a qualified specialist workshop.</li> </ul>
Engine Oil Level Cannot Be Measured	
AT a	* Display message only for certain engines:
	The engine oil level is too high.
Engine Oil Reduce Oil Level	NOTE Engine damage caused by driving with excess engine oil
	Avoid long journeys with excess engine oil.
	Consult a qualified specialist workshop immediately and have the engine oil siphoned off.
AT a	* Display message only for certain engines:
Engine Oil Level Low Stop Vehicle Turn Engine Off	The engine oil level is too low.
	NOTE Engine damage caused by driving with insufficient engine oil
	Avoid long journeys with insufficient engine oil.

Display messages	Possible causes/consequences and ▶ Solutions
	<ul> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Switch off the engine.</li> <li>Add 1.1 US qt (1 I) engine oil.</li> <li>Check the engine oil level.</li> </ul>
	Top up engine oil (──→ page 340).  Notes on engine oil (──→ page 410).
Engine Oil Pressure Stop Switch Off Engine	* Display message only for certain engines:  The engine oil pressure is too low.  NOTE Engine damage caused by driving with insufficient engine oil pressure
	Avoid driving with insufficient engine oil pressure.
	<ul> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Consult a qualified specialist workshop.</li> </ul>
	* Display message only for certain engines: The engine oil level has dropped to the minimum level.

# Display messages Possible causes / consequences and ▶ Solutions Check Engine Oil Level **NOTE** Engine damage caused by driving with insufficient engine oil (Add 1 quart) Avoid long journeys with insufficient engine oil. When next refueling, add 1 quart of engine oil. Top up engine oil ( $\longrightarrow$ page 340). Notes on engine oil ( $\longrightarrow$ page 410). \* The engine oil level has dropped to the minimum level. **NOTE** Engine damage caused by driving with insufficient engine oil Check Engine Oil At Next Avoid long journeys with insufficient engine oil. Refueling Check the engine oil level when next refueling. Add engine oil ( page 340). Notes on engine oil ( page 410).

#### **Transmission**

# Display messages Possible causes/consequences and > Solutions \* The transmission is malfunctioning. The transmission shifts to position [N] automatically.

Display messages	Possible causes/consequences and ▶ Solutions
Transmission Malfunction Stop	<ul> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Switch the transmission to position P.</li> <li>Consult a qualified specialist workshop.</li> </ul>
Stop Vehicle Leave Engine Running Wait Transmission Cooling	<ul> <li>* The transmission is overheating. Pulling away may be temporarily impaired or not possible.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.</li> <li>Leave the engine running.</li> <li>Wait until the display message disappears before pulling away.</li> </ul>
To Deselect P or N, Depress Brake and Start Engine	* You have attempted to shift the transmission out of position P or N into another transmission position.  Depress the brake pedal.  Start the engine.
Apply Brake to Shift from 'P'	* You have attempted to shift the transmission out of position P and into another transmission position.  Depress the brake pedal.
Service Required Do Not Shift Gears Visit Dealer	<ul> <li>* The transmission is malfunctioning. The transmission position can no longer be shifted.</li> <li>When the transmission is in position D, consult a qualified specialist workshop and do not change the transmission position.</li> <li>For all other transmission positions, park the vehicle safely.</li> <li>Consult a qualified specialist workshop or breakdown service.</li> </ul>

Display messages	Possible causes/consequences and ▶ Solutions
Reversing Not Possible Service Required	<ul> <li>* The transmission is malfunctioning. Reverse gear can no longer be engaged.</li> <li>Visit a qualified specialist workshop.</li> </ul>
Auxiliary Battery Malfunction	<ul> <li>* The auxiliary battery for the transmission is no longer being charged.</li> <li>Visit a qualified specialist workshop.</li> <li>Until then, manually set the transmission to position P before you switch off the engine.</li> <li>Before leaving the vehicle, apply the electric parking brake.</li> </ul>
N Permanently Active Risk of Rolling Away	* While the vehicle is rolling or while you are driving, the transmission has been shifted to position N.  Depress the brake pedal to stop and, when the vehicle is stationary, shift the transmission to position P.  To continue your journey, shift the transmission to position D or R.
Only Shift to 'P' when Vehicle is Stationary	* The transmission can only be shifted to position [P] when the vehicle is stationary.
Driver's Door Open & Transmission Not in P Risk of Vehicle Rolling Away	* The driver's door is not fully closed and the transmission is in position R, N or D.  Shift the transmission to position P when you park the vehicle.
To Engage Transmiss. Position R First Depress the Brake	<ul> <li>You have tried to switch to transmission position R.</li> <li>Depress the brake pedal.</li> <li>Shift the transmission to position R.</li> </ul>

Display messages	Possible causes/consequences and ▶ Solutions
Shift to 'P'	<ul> <li>* Shift the selector lever to position P.</li> <li>Pull over and stop the vehicle.</li> <li>Shift the transmission to position P.</li> </ul>
Shift to 'P' or 'N' to Start Engine	<ul> <li>You have tried to start the engine in transmission position P or N.</li> <li>Shift the transmission to position P or N.</li> </ul>

#### Tires

# Possible causes/consequences and ▶ Solutions \* The tire pressure in one or more tires has dropped suddenly. The wheel position is displayed. ▶ WARNING Risk of an accident from driving with a flat tire Flat tires are dangerous in the following ways: • The tires can overheat and cause a fire. • The driving characteristics, as well as steering and braking, may be greatly impaired. You could then lose control of the vehicle. ▶ Do not drive with a flat tire. ▶ Observe the notes on flat tires.

Display messages	Possible causes/consequences and ▶ Solutions
	Notes on flat tires ( >> page 353).  Stop the vehicle, paying attention to road and traffic conditions.  Check the tires.
	* The tire pressure in one or more tires has dropped significantly. The wheel position is displayed.  • WARNING Risk of an accident due to insufficient tire pressure
Check Tires	<ul> <li>Tire pressures that are too low pose the following hazards:</li> <li>The tires may burst, especially as the load and vehicle speed increase.</li> <li>The tires may wear excessively and/or unevenly, which may greatly impair tire traction.</li> <li>The driving characteristics, as well as steering and braking, may be greatly impaired.</li> <li>You could then lose control of the vehicle.</li> </ul>
	<ul><li>Observe the recommended tire pressure.</li><li>Adjust the tire pressure if necessary.</li></ul>
	<ul> <li>Stop the vehicle, paying attention to road and traffic conditions.</li> <li>Check the tire pressure ( page 375) and the tires.</li> </ul>
	<ul> <li>* The tire pressure is too low in at least one of the tires, or the tire pressure difference between the wheels is too great.</li> <li>Check the tire pressure and add air, if necessary.</li> </ul>

Display messages	Possible causes/consequences and ▶ Solutions
Please Correct Tire Pressure	➤ When the tire pressure is correct, restart the tire pressure monitoring system (→→ page 381).
Tire Press. Monitor Currently Unavailable	* There is interference from a powerful radio signal source. As a result, no signals from the tire pressure sensor are received. The tire pressure monitoring system is temporarily unavailable.  Drive on.  The tire pressure monitoring system restarts automatically as soon as the cause has been rectified.
Wheel Sensor(s) Missing	<ul> <li>* The tire pressure sensor signal is missing from one or more tire(s). The pressure of the affected tire is not displayed.</li> <li>Have the defective tire pressure sensor replaced at a qualified specialist workshop.</li> </ul>
Tire Pressure Monitor Inoperative No Wheel Sensors	* The wheels installed do not have suitable tire pressure sensors. The tire pressure monitoring system is deactivated.  Install wheels with suitable tire pressure sensors.
<u>(!)</u>	* The tire pressure monitoring system is defective.

# **SmartKey**

Display messages	Possible causes/consequences and ▶ Solutions
Key Not Detected (red display message)	<ul> <li>* The SmartKey cannot be detected and may no longer be in the vehicle. The SmartKey is no longer in the vehicle and you switch off the engine: <ul> <li>You can no longer start the engine.</li> <li>You cannot centrally lock the vehicle.</li> </ul> </li> <li>Ensure that the SmartKey is in the vehicle.</li> <li>If the SmartKey detection function has a malfunction due to a strong radio signal source: <ul> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Place the SmartKey in the marked space for starting the engine with the SmartKey (———) page 128).</li> </ul> </li> </ul>
Obtain a New Key	* The SmartKey needs to be replaced.  Visit a qualified specialist workshop.
Key Not Detected (white display message)	<ul> <li>* The SmartKey is currently undetected.</li> <li>Change the location of the SmartKey in the vehicle.</li> <li>If the SmartKey is still not recognized, start the engine with the SmartKey in the marked space (———) page 128).</li> </ul>

Display messages	Possible causes/consequences and ▶ Solutions
Replace Key Battery	* The SmartKey battery is discharged.  Replace the battery ( > page 57).
Place the Key in the Marked Space See Opera- tor's Manual	* The SmartKey detection function is malfunctioning.  Change the location of the SmartKey in the vehicle.  Start the vehicle with the SmartKey in the slot (————————————————————————————————————
Don't Forget Your Key	* A warning tone also sounds. This message reminds you to take your SmartKey with you when you leave the vehicle.



### Vehicle

Display messages	Possible causes/consequences and ▶ Solutions
Rear Left Backrest Not Latched (Example)	* The corresponding rear seat backrest is not engaged.  Fold the corresponding seat backrest back until it engages.
Front Left Seat Backrest Not Locked (Example)	* The seat backrest of the corresponding front seat is not engaged.  Fold the seat backrest back until it engages.
Steering Malfunction Stop Immediately See Opera- tor's Manual	* The steering is malfunctioning Steering capability is considerably impaired.
	▲ WARNING Risk of accident if steering capability is impaired
	If the steering does not function as intended, the vehicle's operating safety is jeopardized.
	Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
	Consult a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
	▶ Before every trip, ensure that the engine hood is latched.
	<ul><li>Stop the vehicle immediately, paying attention to road and traffic conditions.</li><li>Close the hood.</li></ul>
	* At least one door is open.  Close all doors.
	* The trunk lid is open.  A DANGER Risk of exhaust gas poisoning  Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid is open when the engine is running, especially if the vehicle is in motion.  Always switch off the engine before opening the trunk lid.  Never drive with the trunk lid open.
	Close the trunk lid.
Check Washer Fluid	* The washer fluid level in the washer fluid reservoir has dropped below the minimum.  ▶ Add washer fluid (→ page 342).

### **Climate control**

Display messages	Possible causes/consequences and ▶ Solutions
Air Conditioning Malfunction See Operator's Manual	* Operation of the climate control system is temporarily restricted. Airflow and fresh air supply are set to automatic mode.
р	Have the climate control system checked at a qualified specialist workshop.
Let fresh air into the vehi-	* The climate control system is malfunctioning.
cle interior. Air Condition- ing Malf. Visit Workshop	▲ WARNING Risk of injury and accident due to an insufficient supply of fresh air
	If the climate control system is malfunctioning, carbon dioxide levels may increase in the vehicle interior. Breathing in carbon dioxide may cause dizziness.
	Open the window to ensure that there is a sufficient supply of fresh air.
	Open the window to ensure that there is an adequate supply of fresh air.
	Visit a qualified specialist workshop immediately.



# Lights

Display messages	Possible causes/consequences and ▶ Solutions
Intell. Light System Inoperative	<ul> <li>* The Intelligent Light System is defective. The lighting system continues to function properly without the functions of the Intelligent Light System.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>
Check Left Low Beam (Example)	<ul> <li>* The corresponding light source is defective.</li> <li>Drive on carefully.</li> <li>Visit a qualified specialist workshop immediately.</li> <li>i LED light bulbs: the display message for the corresponding lamp appears only when all the light-emitting diodes in the lamp have failed.</li> </ul>
Active Headlamps Inoperative	<ul> <li>* The active headlamps are defective.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>
- <del>\</del> \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	* You are leaving the vehicle and the lights are still switched on.  Turn the light switch to the AUTO position.

Display messages	Possible causes/consequences and ▶ Solutions
Switch Off Lights	
Malfunction See Operator's Manual	<ul> <li>* The exterior lighting is defective.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>
Switch On Headlamps	* You are driving without low-beam headlamps.  ▶ Turn the light switch to the ☑ or Аυто position.
Automatic Headlamp Mode Inoperative	<ul> <li>* The light sensor is faulty.</li> <li>▶ Consult a qualified specialist workshop.</li> </ul>
Adaptive Highbeam Assist Inoperative	<ul> <li>* Adaptive Highbeam Assist is malfunctioning.</li> <li>Visit a qualified specialist workshop.</li> </ul>
	* Adaptive Highbeam Assist is temporarily unavailable.  The system limits have been reached ( >> page 109).

Display messages	Possible causes/consequences and ▶ Solutions
Adaptive Highbeam Assist Currently Unavailable See Operator's Manual	Drive on. Once the cause of the problem is no longer present, the system will be available again. The Adaptive Highbeam Assist Now Available display message appears.
Adaptive Highbeam Assist Camera View Restricted See Operator's Manual	<ul> <li>* The camera view is restricted. Possible causes are:</li> <li>Dirt on the windshield in the camera's field of vision</li> <li>Heavy rain, snow or fog</li> </ul>
	Driving systems and driving safety systems may be malfunctioning or temporarily unavailable.  Once the cause of the problem is no longer present, driving systems and driving safety systems will be available again.  If the display message does not disappear:  Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
	<ul> <li>Clean the windshield.</li> </ul>

# Warning and indicator lamps Overview of warning and indicator lamps

Some systems will perform a self-test when the ignition is switched on. Some warning and indicator lamps may briefly light up or flash. This behavior is non-critical. These warning and indi-

cator lamps indicate a malfunction only if they light up or flash after the engine has been started or during a journey.



#### **Instrument Display**



# Progressive setting



If you select the progressive display setting, the positions of the indicator lamps on the instrument display will change.

#### Warning and indicator lamps:

**■**D Low beam( $\longrightarrow$  page 106) Parking lights (—— page 106) -000-≣D High beam( $\longrightarrow$  page 107)  $\Diamond$ Turn signal lights( $\longrightarrow$  page 107)

0≑ Rear fog light( $\longrightarrow$  page 106) **P**i Restraint system( page 464)

\* Seat belt not fastened( $\longrightarrow$  page 469)

BRAKE

(I)

(P)

PARK

USA: brakes (red) (→ page 464) Canada: brakes (red)

 $(\longrightarrow)$  page 464) Electric parking brake (yellow)

 $(\longrightarrow)$  page 464)

USA: electric parking brake applied (red) ( $\longrightarrow$  page 464)

DEALER ePROCESS

(P)

(ABS)

ÖFF  $\triangle$ 

⊕!

Ů

Ē Ŧ

\*F

(i)

Canada: electric parking brake applied (red) ( $\longrightarrow$  page 464)

ABS malfunction $ing(\longrightarrow)$  page 464)

 $ESP^{\mathbb{R}}(\longrightarrow)$  page 464)  $ESP^{\otimes} OFF(\longrightarrow)$  page 464)

Distance warning( $\longrightarrow$  page 470)

Power-assisted steering malfunction $ing(\longrightarrow)$  page 475)

AIRMATIC/Active Body Control malfunctioning ( $\longrightarrow$  page 470)

Check Engine( page 470)

Electrical malfunction  $(\longrightarrow)$  page 470)

Fuel reserve with fuel filler flap location indicator ( $\longrightarrow$  page 470)  $(\longrightarrow)$  page 470)

Coolant too hot/cold  $(\longrightarrow)$  page 470)

Tire pressure monitoring system page 473)

# Safety systems

# Warning/indicator lamp



Brake warning lamp (USA)



Brakes warning lamp (Canada)

# Possible causes / consequences and ▶ Solutions

The red brake system warning lamp is lit while the engine is running.

Possible causes are:

- The brake force boosting is malfunctioning and the braking characteristics may be affected.
- There is insufficient brake fluid in the brake fluid reservoir.

# **WARNING** Risk of accident and injury if brake force boosting is malfunctioning

If brake force boosting is malfunctioning, increased brake pedal force may be necessary for braking. The braking characteristics may be impaired. The braking distance can increase in emergency braking situations.

- Stop in a safe location immediately. Do not continue driving.
- Consult a qualified specialist workshop.

#### WARNING Risk of an accident due to low brake fluid level

If the brake fluid level is too low, the braking effect and the braking characteristics may be impaired.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Consult a qualified specialist workshop.
- Do not add brake fluid.



# Warning/indicator lamp

#### Possible causes/consequences and > Solutions

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Observe the messages on the multifunction display.
- Consult a qualified specialist workshop.



ABS warning lamp

The yellow ABS warning lamp is lit while the engine is running.

ABS is malfunctioning.

If there is an additional warning tone, EBD is malfunctioning.

Other driving systems and driving safety systems may also malfunction.

# **WARNING** There is risk of skidding if EBD or ABS is malfunctioning

If EBD or ABS is malfunctioning, the wheels could lock when braking

The steering capability and braking characteristics are thus severely impaired. The braking distance in an emergency braking situation can increase. In addition, other driving safety systems are switched off.

- Drive on carefully.
- Have the brake system checked immediately at a qualified specialist workshop.
- Drive on carefully.
- Observe the messages on the multifunction display.
- Visit a qualified specialist workshop.



#### Warning/indicator lamp



Red indicator lamp, electric parking brake applied (USA only)



Red indicator lamp, electric parking brake applied (Canada only)



Yellow electric parking brake indicator lamp is malfunctioning

# Possible causes / consequences and ▶ Solutions

The red electric parking brake indicator lamp flashes or is lit. The yellow indicator lamp is also lit if the electric parking brake malfunctions.

Observe the messages on the multifunction display.



The yellow ESP® warning lamp flashes while the vehicle is in motion.

At least one wheel and tire assembly has reached its traction limit (\(\rightarrow\) page 152).

Adapt your driving style to suit the road and weather conditions.

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
ESP® warning lamp flashes	
ESP® warning lamp lights	The yellow ESP® warning lamp is lit while the engine is running. ESP® is malfunctioning Other driving systems and driving safety systems may also malfunction.
up	▲ WARNING Risk of skidding if ESP <sup>®</sup> is malfunctioning
	If ESP® is malfunctioning, ESP® cannot carry out vehicle stabilization. In addition, other driving safety systems are switched off.  Drive on carefully.  Have ESP® checked at a qualified specialist workshop.
	<ul> <li>Drive on carefully.</li> <li>Observe the messages on the multifunction display.</li> <li>Visit a qualified specialist workshop.</li> </ul>
OFF ESP® OFF warning lamp	The yellow ESP® OFF warning lamp is lit while the engine is running. ESP® is deactivated.

## Warning/indicator lamp

## Possible causes / consequences and ▶ Solutions

# **MARNING** Risk of skidding when driving with ESP® deactivated

If ESP® is deactivated, ESP® cannot carry out vehicle stabilization. The availability of further driving safety systems is also limited.

- Drive on carefully.
- Only deactivate ESP® for as long as the situation requires.

If ESP® cannot be activated, ESP® is malfunctioning.

- ► Have ESP® checked immediately at a qualified specialist workshop.
- $\triangleright$  Observe the notes on deactivating ESP<sup>®</sup> ( $\longrightarrow$  page 152).

The red restraint system warning lamp is lit while the engine is running.

The restraint system is defective ( $\longrightarrow$  page 28).



Restraint system warning lamp

# WARNING Risk of injury or fatal injury due to a malfunction in the restraint system

If the restraint system is malfunctioning, restraint system components may be triggered unintentionally or might not be triggered at all in the event of an accident. This may affect the Emergency Tensioning Device or airbag, for example.

- Have the restraint system checked and repaired immediately at a qualified specialist workshop.
- Drive on carefully.



Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	<ul> <li>Observe the messages on the multifunction display.</li> <li>Visit a qualified specialist workshop immediately.</li> </ul>

#### Seat belts

Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
Seat belt warning lamp lights up	The red seat belt warning lamp will light up for six seconds once the engine has started.  In addition, a warning tone may sound.  The seat belt warning lamp reminds the driver and front passenger to fasten their seat belts.  ▶ Fasten your seat belt (→→ page 34).  If you have placed objects on the front passenger seat, the seat belt warning lamp may remain lit.
Seat belt warning lamp flashes	The red seat belt warning lamp flashes and an intermittent warning tone sounds.  The driver or front passenger has not fastened their seat belt while the vehicle is in motion.  Fasten your seat belt(————————————————————————————————————



## **Driving systems**

## Warning/indicator lamp Possible causes / consequences and ▶ Solutions The yellow AIRMATIC/Active Body Control warning lamp is on. There is a malfunction in AIRMATIC/the Active Body Control system. Observe the messages on the multifunction display. Suspension warning lamp The red distance warning lamp lights up while the vehicle is in motion. The distance to the vehicle in front is too small for the speed selected. If there is an additional warning tone, you are approaching an obstacle at too high a speed. Warning lamp for distance Be prepared to brake immediately. warning function Increase the distance. Active Brake Assist.

## **Engine**

# Warning/indicator lamp



# Possible causes/consequences and ▶ Solutions

The yellow Check Engine warning lamp is lit while the engine is running.

A malfunction has occurred in the engine, the exhaust system or the fuel system.

The emission limit values may be exceeded and the engine may be in emergency mode.



Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
Engine diagnosis warning lamp	In some states, legal requirements stipulate that you must immediately consult a qualified specialist workshop as soon as the yellow Check Engine warning lamp lights up.
	Have the vehicle checked as soon as possible at a qualified specialist workshop.
	The red electrical malfunction warning lamp is lit.
- +	There is a malfunction in the electrics.
Electrical malfunction warn- ng lamp	Observe the messages on the multifunction display.
Fuel reserve warning lamp	The yellow fuel reserve warning lamp lights up while driving.
	There has been pressure loss in the fuel system. The fuel filler cap is not closed correctly or the fuel system is leaking.  Close the fuel filler cap.
	If the fuel filler cap has already been closed correctly:
	➤ Visit a qualified specialist workshop.
	The yellow fuel reserve warning lamp is lit while the engine is running.
	The fuel supply has dropped into the reserve range.
uel reserve warning lamp	Refuel.

## Warning/indicator lamp



Coolant warning lamp

# Possible causes / consequences and ▶ Solutions

The red coolant warning lamp is lit while the engine is running.

Possible causes are:

- The temperature sensor is malfunctioning
- The coolant level is too low
- The air supply to the radiator is obstructed
- The radiator fan is faulty

If there is an additional warning tone, the coolant temperature has exceeded the maximum permissible temperature.

# WARNING Danger of burns when opening the hood

If you open the hood when the engine has overheated or during a fire in the engine compartment, you could come into contact with hot gases or other escaping operating fluids.

- ▶ Before opening the hood, allow the engine to cool down.
- In the event of a fire in the engine compartment, keep the hood closed and call the fire service.
- Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Observe the messages on the multifunction display.

If the coolant temperature display is at the lower end of the temperature scale:

Consult a qualified specialist workshop.



### Warning/indicator lamp

#### Possible causes / consequences and ▶ Solutions

or

- Exit the vehicle and keep a safe distance from it until the engine has cooled down.
- Check the coolant level ( $\longrightarrow$  page 341).
- Make sure that the air supply to the radiator is not obstructed.
- Avoiding high loads on the engine, drive to the nearest qualified specialist workshop. In doing so, ensure that the coolant temperature display remains below the red area.

#### Tires

# Warning/indicator lamp



Tire pressure monitoring system warning lamp lights up

## Possible causes/consequences and > Solutions

The yellow tire pressure monitoring system warning lamp (pressure loss/malfunction) is lit.

The tire pressure monitoring system has detected tire pressure loss in at least one of the tires.

**WARNING** Risk of an accident due to insufficient tire pressure

Tire pressures that are too low pose the following hazards:

- The tires may burst, especially as the load and vehicle speed increase.
- The tires may wear excessively and/or unevenly, which may greatly impair tire traction.
- The driving characteristics, as well as steering and braking, may be greatly impaired.



Warning/indicator lamp	Possible causes/consequences and ▶ Solutions
	You could then lose control of the vehicle.  Observe the recommended tire pressure.  Adjust the tire pressure if necessary.
	<ul><li>Stop the vehicle, paying attention to road and traffic conditions.</li><li>Check the tire pressure and the tires.</li></ul>
<u>(i)</u>	The yellow tire pressure monitoring system warning lamp (pressure loss/malfunction) flashes for approximately one minute and then remains lit.  The tire pressure monitoring system is defective.
Tire pressure monitoring system warning lamp flashes	<b>WARNING</b> There is a risk of an accident if the tire pressure monitoring system is malfunctioning
	If the tire pressure monitoring system is malfunctioning, it is not able to issue a warning if there is pressure loss in one or more of the tires.
	Underinflated tires may, for example, impair the driving, steering and braking characteristics.  Have the tire pressure monitoring system checked at a qualified specialist workshop.
	Visit a qualified specialist workshop.



#### Vehicle

#### Warning/indicator lamp



Power steering system warning lamp

## Possible causes/consequences and > Solutions

The red power steering system warning lamp is lit while the engine is running.

The power-assisted steering or the steering itself is malfunctioning.

WARNING Risk of accident if steering capability is impaired

If the steering does not function as intended, the vehicle's operating safety is jeopardized.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- Consult a qualified specialist workshop.
- Observe the messages on the multifunction display.



		A self-out and bounded-out on an area			
1, 2, 3  4MATIC	139 139	Accident and breakdown management  Mercedes me connect		Route-based speed adaptation Steering wheel buttons Storing a speed Switching off/deactivating Switching on/activating System limitations  Active Emergency Stop Assist	16 16 16 16
see Socket (12 V)		Burmester® surround sound system	334	Active hood (pedestrian protection)	33
360° Camera	188 188	Active Blind Spot Assist	203 204	Method of operationResetting	33
Opening the camera cover (rear view camera)		Function	203 206	Active Lane Change Assist  Activating/deactivating  Function	17
Setting favorites	190	Active Brake Assist		Active Lane Keeping Assist	20
A (C function		Function/notes Setting	155 159	Activating/deactivating	
A/C function  Activating/deactivating (multimedia system)	120 120	Active Distance Assist DISTRONIC  Active Emergency Stop Assist  Active Lane Change Assist		Function	20
Switching on/off (control panel)		Calling up a speed	163	Active Parking Assist	19
ABS (Anti-lock Braking System)	151	Displays in the Instrument Display	171	Cross Traffic Alert	19
Acceleration		Function	162	Drive Away Assist	
see Kickdown		Increasing/decreasing speed	163	Exiting a parking space	
		Requirements	163	Function	19

Air suspension see AIRMATIC	Alarm see Panic alarm	Anti-theft alarm system see ATA (anti-theft alarm system)
Air vents       123         Adjusting (front)       123	Alarm system see ATA (anti-theft alarm system)	Anti-theft protection Immobilizer
Adjusting (rear)	All-wheel drive see 4MATIC	Anti-theft protection see ATA (anti-theft alarm system)
Air vents see Air vents	Alternative route see Route	Anticipatory occupant protection see PRE-SAFE® (anticipatory occu-
Air-recirculation mode 121	Ambient lighting	pant protection)
<b>Air-water duct</b>	Setting (multimedia system) 111	see PRE-SAFE® PLUS (anticipatory
Keeping free 343	<b>Android Auto</b>	occupant protection plus)
<b>Airbag</b>	Connecting a mobile phone 300	Apple CarPlay™ 298
Activation	Ending	Connecting an iPhone®
Front airbag (driver, front passenger) 35	Information	Ending
Installation locations	Overview	Notes
Knee airbag	Sound settings	Overview
Overview		Transferred vehicle data
Protection	Animals Pets in the vehicle	
Side airbag		Ashtray Front center console
Window curtain airbag	Anti-lock braking system	
<b>AIRMATIC</b> 174	see ABS (Anti-lock Braking System)	Assistance systems
Setting	Anti-skid chains	see Driving safety system
Suspension	see Snow chains	

В		Information	248	EBD (electronic brake force distribu-	455
BAS (Brake Assist System) Battery Charging (Remote Online) SmartKey		Bluetooth® audio Activating	324 324 322	tion)	155 173 130
Battery see Battery (vehicle)		Overview	322 324	Notes on breaking-in a new vehicle	129 129
3 8 8 ( 3 3 3 3 3 )	363 129 359 361 364	Searching for and authorizing the device		Braking assistance see BAS (Brake Assist System)  Breakdown Changing a wheel	. 14 . 19 370 366
Belt see Seat belt		Brake force distribution EBD (electronic brake force distribu-		Transporting the vehicle  Breakdown	367
Switching on/off	203	tion)	151 155	see Flat tire  Burmester® high-end 3D surround sound system Adjusting the balance/fader	
Bluetooth®	248 248	BAS (Brake Assist System)  Driving tips	151 130	Adjusting the sound optimization	335

Adjusting treble, mid-range and bass settings	335 334 335 333 334 334 334 334 333 333	Calling up the sound menu  Burmester® high-end 3D surround sound system  Burmester® surround sound system  Calls  Accepting  Activating functions during a call  Calls with several participants  Declining  Ending a call  Incoming call during an existing call  Making  Via the overhead control panel (Mercedes me connect)  Camera  see 360° Camera see Rear view camera  Car key see SmartKey  Car wash	291 291 291 291 291 291 292 291	Automatic car wash Carpet Decorative foil Display Exterior lighting Headliner Matte finish Night View Assist Paintwork Plastic trim Power washer Real wood/trim elements Rear view camera Seat belts Seat cover Sensors Tailpipes Washing by hand Wheels/rims Windows Wiper blades	35 34 35 34 34 35 34 35 34 35 34 35 34 35 34 35 34 35 34 35 35 36 36 36 36 36 36 36 36 36 36 36 36 36
Making a call	295	see Care		Carpet (Care)	
Overview	295	Car wash (care)	343	Change of address	1
		Care Air-water duct	350 343	Change of ownership	1

# Index

		Notes on risks and dangers Securing on the front passenger seat Securing on the rear seat	53	Activating/deactivating the synchro- nization function (multimedia sys- tem)	121
Changing gears	137 137	Top Tether Children		Air-recirculation mode	120 121
Character entry On the touchpad Using the controller Charging	246 245 363 103	Avoiding dangers in the vehicle Basic instructions Special seat belt retractor  Chock Storage location  Chock see Chock Cigarette lighter Front center console  Cleaning	44 49 397	Climate style function Control panel for 3-zone automatic climate control Filling capacity for PAG oil Front air vents Glove box air vent Inserting/removing the flacon (fragrance system) Ionization Note	414 123 124 122 122 119
Child safety lock Activating/deactivating (multimedia system) Child seat Attaching (notes) Basic instructions front-passenger seat (notes) LATCH-type (ISOFIX) (installing)	252 48 44 53	see Care  Climate control  Activating/deactivating		Rear air vents Refrigerant Refrigerant filling capacity Removing condensation from the windows Residual heat Setting rear climate control (multi- media system) Setting the climate style Setting the fragrance system	413 414 121 121 121 120

Ventilating the vehicle (convenience		Connectivity		Trademarks	2
opening)	71 123	Switching transmission of the vehicle	248	Cornering light function	10
	123	position on/off		Cross Traffic Alert	19
Function	120	Calling up	293	Crosswind Assist Function/notes	15
Setting  Cockpit  Overview	6	Deleting  Downloading (from mobile phone)  Importing	294 293 294	Crosswind Assist see MAGIC BODY CONTROL	
Coffee cup symbol see ATTENTION ASSIST		Importing (overview) Information Making a call	293 292 294	Cruise control	16
COMAND see Multimedia system		Name format Options	293 294	Calling up a speed Function Requirements:	15
COMAND Touch  Managing devices	251	Storing Controller	294		16
Combination switch	107	Operating	239	Storing a speed	16
Compass	284	Convenience closing feature  Convenience opening		Switching off	16
see On-board computer  Connection status  Displaying	308 308	Coolant (engine) Check level Filling capacity Notes	412	Cup holder	9
		Copyright Licenses	27	Customer Assistance Center (CAC)  Customer Relations Department	

D	Dealership		Selecting previous destinations	263
Dashboard	see Qualified specialist workshop  Declaration of conformity		Detecting inattentiveness see ATTENTION ASSIST	
see Cockpit  Dashboard lighting see Instrument cluster lighting	Wireless vehicle components  Decorative foil (cleaning instructions)	21	Diagnostics connection	
Data acquisition Vehicle	Definitions (tires and loading)	346 392	Digital speedometer  Dinghy towing	
Data import/export252Function/notes252	Designs  Menu (on-board computer)		see Tow-bar system  DIRECT SELECT lever	135
Importing/exporting 253  Data storage Electronic control units 24 Online services 25 Vehicle 24  Date	Editing intermediate destinations Editing the previous destinations External	264 275 276 275 275	Engaging park position automatically Engaging reverse gear	
Setting the time and date automatically	8	266 260	Care  Display (multimedia system)  Settings	
Daytime running lights	Entering an intermediate destination Entering geo-coordinates	264 265 265	<b>Display (on-board computer)</b> Displays on the multifunction display	
Deactivating the alarm (ATA) 78	Selecting a POI			

<b>Display content</b> Setting the additional value range	213	Active Brake Assist Functions Cur- rently Limited See Operator's Man-		Active Parking Assist and PARKTRONIC Inoperative See Opera-	
Display message  Calling up (on-board computer)  Notes	416	ual	429	tor's Manual	43
Display messages		ted See Operator's Manual	429	Unavailable See Operator's Manual	
(S) mph	440	Active Distance Assist Currently		Active Steering Assist Inoperative	43
<b>=ি</b> হের mph	439	Unavailable See Operator's Manual		Adaptive Highbeam Assist Camera	
12 V Battery See Operator's		Active Distance Assist Inoperative	440	View Restricted See Operator's Man-	
Manual	443	Active Distance Assist Now Available		ual	46
ABC Malfunction Stop Vehicle	439		440	Adaptive Highbeam Assist Currently	
ABC Vehicle Rising Please Wait		Active Headlamps Inoperative	460	Unavailable See Operator's Manual	46
Briefly	439	Active Hood Malfunction See Opera-		Adaptive Highbeam Assist Inopera-	
Active Blind Spot Assist Currently	,	tor's Manual	457	tive	46
Unavailable See Operator's Manual	433	Active Lane Keeping Assist Camera		Air Conditioning Malfunction See	
Active Blind Spot Assist Inoperative		View Restricted See Operator's Man-		Operator's Manual	45
Active Blind Spot Asst. Not Available	100	ual	441	Apply Brake to Shift from 'P'	44
When Towing a Trailer See Opera-		Active Lane Keeping Assist Currently		ATTENTION ASSIST Inoperative	43
tor's Manual	431	Unavailable See Operator's Manual	434	ATTENTION ASSIST: Take a	
tor o Mariaar	701	Active Lane Keeping Assist Inopera-		Break!	43
		tive	436		

Automatic Headlamp Mode		() Check Tires	451	Engine Oil Pressure Stop Switch	
Inoperative	461	Check Washer Fluid	458	Off Engine	446
Auxiliary Battery Malfunction		Coolant Too Hot Stop Vehicle		Engine Oil Reduce Oil Level	445
Blind Spot Assist Currently Unavaila-		Turn Engine Off	444	Front Left Malfunction Service	
ble See Operator's Manual	431	Cruise Control Inoperative		Required (Example)	427
Blind Spot Assist Inoperative	432	Cruise Control Off		Front Left Seat Backrest Not	
Blind Spot Assist Not Available When		© Currently Unavailable See Oper-		Locked (Example)	456
Towing a Trailer See Operator's Man-		ator's Manual	424	Front Passenger Airbag Disabled See	
ual	437	Surrently Unavailable See Oper-		Operator's Manual	429
BRAKE Check Brake Fluid Level	422	ator's Manual	417	Front Passenger Airbag Enabled See	
Check Brake Pads See Operator's		Decrease Speed	453	Operator's Manual	428
Manual	430	Don't Forget Your Key	455	Fuel Level Low	
Check Coolant Level See Operator's		Drive More Slowly		Gas Cap Loose	442
Manual	442	Driver's Door Open & Transmission		Inoperative See Operator's	
Check Engine Oil At Next Refu-		Not in P Risk of Vehicle Rolling Away	449	Manual	425
eling	447	Engine Oil Level Cannot Be		[ Inoperative See Operator's	
Check Engine Oil Level (Add 1		Measured	445	Manual	425
quart)	446	Engine Oil Level Low Stop Vehi-		EBD Inoperative See Operator's	
		cle Turn Engine Off	445	Manual	422
ple)	460			sos Inoperative	430

↑ Intell. Light System Inoperative	460	P(S) Off	438	See Operator's Manual	441
Key Not Detected (white dis-		HOLD Off	435	Service Required Do Not Shift Gears	
play message)	454	Only Shift to 'P' when Vehicle is Sta-		Visit Dealer	448
Key Not Detected (red display		tionary	449	Shift to 'P'	450
message)	454	PARK Parking Brake See Operator's		Shift to 'P' or 'N' to Start Engine	450
Left Side Curtain Airbag Mal-		Manual	418	SRS Malfunction Service	
function Service Required (Example)	427	Place the Key in the Marked		Required	426
Let fresh air into the vehicle interior.		Space See Operator's Manual	455	<b>⊚!</b> Steering Malfunction Increased	
Air Conditioning Malf. Visit Work-		(!) Please Correct Tire Pressure	451	Physical Effort See Operator's Man-	
shop	459	PARK Please Release Parking Brake	421	ual	457
<b>๔ Lowering</b>	438	PRE-SAFE Inoperative See Opera-		<b>⊗!</b> Steering Malfunction Stop	
Malfunction Drive at Max. 50 mph	436	tor's Manual	430	Immediately See Operator's Manual	456
Malfunction See Operator's		Radar Sensors Dirty See Operator's		Stop Vehicle Leave Engine Running	
Manual	461	Manual	423	Wait Transmission Cooling	448
Max. Speed 22 mph	438	Rear Left Backrest Not		Stop Vehicle Leave Engine Run-	
Mercedes me connect Services Limi-		Latched (Example)	456	ning	442
ted See Operator's Manual	430	Replace Key Battery	455	Stop Vehicle See Operator's	
N Permanently Active Risk of Rolling		Reversing Not Possible Service		Manual	443
Away	449	Required	449	Stop Vehicle Vehicle Too Low	437
Obtain a New Key	454	Road Surface Scan Inoperative	439	Suspended	439

Switch Off Lights	460	Vehicle Rising Please Wait	432	Drawbar	
数 Switch On Headlamps	461	Vehicle Rising	435	see Tow-bar system	400
Tire Press. Monitor Currently		(!) Warning Tire Malfunction	450	Drinking and driving	130
Unavailable		Wheel Sensor(s) Missing	452	<b>Drinks holder</b> see Cup holder	
(!) Tire Press. Monitor Inoperative (!) Tire Pressure Monitor Inopera-	452	Display on the windshield see Head-up Display		Drive Away Assist	195
tive No Wheel Sensors	452	Distance control		Drive position Inserting	137
	453	see Active Distance Assist DISTRONIC  Distance recorder		Drive program display	
To Deselect P or N, Depress Brake and Start Engine	448	see Trip distance  DISTRONIC		Drive programs see DYNAMIC SELECT	
To Engage Transmiss. Position R First Depress the Brake	449	see Active Distance Assist DISTRONIC  Door		Driver's seat see Seat	
Traffic Sign Assist Camera View Restricted See Operator's Manual	435	Locking (emergency key)	62 59	Driving lights see Automatic driving lights	
Traffic Sign Assist Currently Unavail-		Opening (from the inside)	59	Driving safety system	
able See Operator's Manual	434	Unlocking (emergency key) Unlocking (from the inside)		Active Brake AssistBAS (Brake Assist System)	155
Transmission Malfunction Stop  PARK Turn On the Ignition to Release	447	Door control panel (rear passenger compartment)	12	EBD (electronic brake force distribution)	155
the Parking Brake	417	DOT, Tire Identification Number (TIN)		ESP® Crosswind Assist Overview	154

Radar sensors	150	Drinking and driving	130	Setting  Easy exit feature Function/notes Setting	8
see 360° Camera see Active Blind Spot As		Drowsiness detection see ATTENTION ASSIST		EBD (electronic brake force distribution)	
see Active Distance Ass		Dynamic handling control system		Function/notes	15
see Active Emergency S see Active Lane Change	•	see ESP® (Electronic Stability Program)		ECO display	
see Active Lane Keeping see Active Parking Assis	g Assist	DYNAMIC SELECT		FunctionResetting	13 21
see Active Speed Limit see Active Steering Ass see AIRMATIC see ATTENTION ASSIST see Blind Spot Assist	Assist	Displaying engine data Displaying vehicle data Drive program display Drive programs Function	135 135 134	ECO start/stop function Automatic engine start Automatic engine stop Method of operation Switching off/on	13 13 13
see Cruise control see Driving safety syste see HOLD function see MAGIC BODY CONT see Night View Assist		Operating (DYNAMIC SELECT switch) Selecting the drive program Showing operation feedback		Electric parking brake  Applying automatically  Applying or releasing manually  Emergency braking  Releasing automatically	14 14 14
see Parking Assist PARI see Rear view camera see Traffic Sign Assist	TRONIC	E E10Easy entry feature	409	Electronic Stability Program see ESP® (Electronic Stability Program)	14

Overview of the help functions	Starting (emergency operation mode)	128	Activating/deactivating Function/notes	154
Emergency braking	Starting (Remote Online) Starting (start/stop button) Starting assistance Switching off (start/stop button)  Engine data Displaying	129 127 363 141	Exterior lighting Care	349
Emergency length   S70	Engine number  Engine oil  Additives  Capacity  Checking the oil level using the onboard computer  MB-Freigabe or MB-Approval  Quality  Topping up	340 410 411 340 411 411	Automatic mirror folding function Folding in/out Operating the memory function Parking position Setting External device Locking (child safety lock) Eyeglasses compartment	116 114 91 116 114
Activation 29  ENERGIZING comfort Overview of programs 258 Starting the program 259  Engine ECO start/stop function 132	Entering characters Function/notes	<ul><li>244</li><li>154</li></ul>	Fatigue detection see ATTENTION ASSIST Favorites Adding	242

Calling up Deleting Moving Overview Renaming Flacon Inserting/removing Flat tire	<ul><li>243</li><li>242</li><li>241</li><li>242</li><li>122</li><li>353</li></ul>	Frequency band Dialing (on-board computer)  Front airbag (driver, front passenger)  Front passenger seat Adjusting from the driver's seat  Fuel Additives E10	35 82 410 410	Dashboard fuse box	37 37 37 37
Changing a wheel	354 353	Quality (gasoline) Refueling	409 409 139 409	G Garage door opener Clearing the memory Opening or closing the door Programming buttons	14
Floor mats  Foil covering Radar sensors  Fragrance see Perfume atomizer  Free software  Frequencies Two-way radio	150	Fuel consumption On-board computer  Function seat (rear passenger compartment) see Seat (rear passenger compartment) Fuse insert see Fuses Fuses	216 370	Radio equipment approval numbers Resolving problems Synchronizing the rolling code  Gas station search Starting automatic search Switching automatic search on/off Using automatic search  Gasoline	14 14 14 26 27 27
,	.50	Before replacing a fuse	370	Gearshift recommendation	13

Genuine parts	17	Adjusting the brightness (on-board computer)	221	Hotspot Setting up (Wi-Fi) Hydropneumatic suspension	25
Glide mode 13	38	Menu (on-board computer) Operating the memory function		see MAGIC BODY CONTROL	
Glove box	0.4	Setting the position (on-board com-		I	
Air vent		puter) Switching on/off	220 221	Identification plate Engine	40
н		Headliner (care)	350	Refrigerant	41
Handbrake		High beam Switching on/off	107	Vehicle Ignition	40
see Electric parking brake  Handling characteristics (unusual) 37	74	High-beam flasher	107	Switching on (Start/Stop button)	12
HANDS-FREE ACCESS		High-beam headlamps Adaptive Highbeam Assist	109	Ignition key see SmartKey	
Hazard warning lights 10	80	Hill start assist		Immobilizer	. 7
Head restraint Front (adjusting mechanically)	84 83	HOLD function  Function/notes  Switching on/off  Hood  Function (active hood)  Opening/closing  Resetting (active hood)	173 173 337 338	Indicator lamps see Warning/indicator lamps Individual drive program Configuring	
Adjusting display elements (on-board computer)		Noocelling (notive flood)	507	see Exterior mirrors	

Inspection see ASSYST PLUS	Starting an automatic gas station search	264	Selecting and connecting to a station	
Instrument cluster see Instrument Display	Starting the automatic service station search	270	Selecting stream  Setting options  Terms of use	31
Instrument cluster lighting 214	Internet	200		31
Instrument Display         210           Adjusting the lighting         214           Function/notes         210           Instrument cluster         8           Setting the additional value range         213           Warning/indicator lamps         462	Calling up a web page Closing the browser Deleting a bookmark Deleting browser data Managing bookmarks Internet connection	310 310 310 310	Ionization Activating/deactivating (multimedia system)  iPhone® see Apple CarPlay™ see Mercedes-Benz Link	12
Intelligent Light System	Communication module function Connection status	307		
Adaptive Highbeam Assist       109         Cornering light function       109         Interior lighting       111         Ambient lighting       111         Reading light       111         Setting       111	Displaying the connection status Establishing	308 307 307 307	Jack Storage location  Jump-start connection General notes	36
Switch-off delay time	Deleting stations		KEYLESS-GO	
Calculating a route with intermediate destinations	Logging out Overview Registering Saving stations DEALER EPROCESS	311 312	Locking the vehicle Problem Unlocking setting Unlocking the vehicle	. 6 . 5

#### Index

Kickdown 138	see MAGIC BODY CONTROL		Limited Warranty	
Using 138	Light switch		Vehicle	23
Knee airbag	Overview	106	Live Traffic Information	
L	Lighting see Interior lighting		Displaying subscription information Displaying the traffic map Displaying traffic incidents	277
Labeling (tires) see Tire labeling	see Lights Lights	106	Extending a subscription	277
Lamp see Interior lighting	Adaptive Highbeam Assist		Load index (tires)	389
Lamps (Instrument Display) see Warning/indicator lamps	Automatic driving lights	107 107	Load-bearing capacity (tires)  Loading  Definitions	
Lane detection (automatic) see Active Lane Keeping Assist	Hazard warning lights High beam	108	Notes	92
Lane Keeping Assist see Active Lane Keeping Assist	High-beam flasher Light switch	107	Loading guidelines	
Language         252           Notes         252           Setting         252           LATCH-type (ISOFIX) child seat securing system         49           Installing         49           Level control system see AIRMATIC	Low-beam headlamps Parking lights Rear fog lamp Responsibility for lighting systems Setting the exterior lighting switch- off delay time Setting the surround lighting Standing lights Turn signals	106 106 106 106 110 110	Loading information table  Loads Securing Securing See Surround lighting Locking/unlocking Activating/deactivating the automatic locking feature	92
	DEALER ePROCESS			

Emergency key	Maintenance  Menu (on-board computer)  Vehicle		Selecting POI symbols	28
Unlocking and opening doors from the inside	Maintenance see ASSYST PLUS		Setting the map scale  Setting the map scale automatically  Updating	28
Low-beam headlamps Switching on/off	Malfunction Restraint system	29	Map and compass	
Lubricant additives see Additives	Malfunction message see Display message		Massage program Overview	
Luggage Net hooks	Map 277, 279, Avoiding an area	282	Resetting the settings	
M	Avoiding an area (overview)		Selecting the front seats	8
MAGIC BODY CONTROL	Displaying the compass	284	Resetting	
Setting	Displaying the map version  Displaying the next intersecting	201	Matte finish (cleaning instructions)	34
Suspension		281	Maximum load rating	38
MAGIC SKY CONTROL         76           Function         76           Operating         76           MAGIC VISION CONTROL         112	Displaying the satellite map Displaying the traffic map Displaying weather information Map data Moving	284 277 284 283	Determining	38 38 38

#### Index

Unlocking the trunk lid	68	Outside mirrors — Calling up stored		Information	301
Media		settings		Making a call via the overhead con-	
Menu (on-board computer)	219	Outside mirrors — Storing settings	. 91	trol panel	302
Searching		Seat – Calling up stored settings	. 91		
Media display		Seat — Storing settings	. 91	Transferred data	304
. ,	0.07	Steering wheel — Calling up saved		Mercedes-AMG vehicles	
Notes	23/	settings	. 91	Notes	126
Media Interface		Steering wheel — Saving settings	. 91		
Activating	320	Menu (on-board computer)		Mercedes-Benz Apps	000
Information	319	Assistant display	215	Calling up	308
Overview	321	Designs		Using voice control	308
Media mode				Mercedes-Benz emergency call sys-	
Activating	31/	Head-up Display Maintenance			304
ŭ	514			Automatic emergency call	305
Media playback		Media		Information	
Operating (on-board computer)	219	Navigation		Information on data processing	306
Media search		Overview			
Starting	319	Radio	218	Overview	304
Media source		Telephone			
	210	Trip	216	Mercedes-Benz Link	
Selecting (on-board computer)	219	Mercedes me connect	302	Connecting	
Memory function		Accident and breakdown manage-		Ending	
Head-up Display – Calling up stored		ment	303		
settings	91	Arranging a service appointment	303	Using	297
Head-up Display – Storing settings	. 91	Calling the Mercedes-Benz Customer		Message (multifunction display)	
Operating		Center	302	see Display message	
				, , 3	
		DEALER ePROCESS			

Connecting the mobile phone to the	217 290	Standby mode function  Notes on breaking-in a new vehicle	150 149 129	On-board computer  Assistance graphic menu  Displaying the service due date  Head-up Display menu  Media menu  Menu designs	215 336 220 219 213
Information Switching Bluetooth® audio equip- ment	<ul><li>290</li><li>324</li></ul>	Occupant safety Pets in the vehicle	54	Menu overview  Multifunction display  Navigation system menu  Operating	214 217
Switching mobile phones Using a mobile phone  Neutral Inserting	290	Occupant safety see Airbag see Automatic front passenger front airbag shutoff		Radio menu	218 218 219
NFC see Near Field Communication (NFC) Night view see Night View Assist		see PRE-SAFE® (anticipatory occupant protection) see PRE-SAFE® PLUS (anticipatory occupant protection plus)		On-board diagnostics interface see Diagnostics connection  Open-source software  Opening the trunk lid using your foot	27
Care	202 348 200 201 202	see Restraint system see Seat belt  Odometer see Total distance  Oil see Engine oil		HANDS-FREE ACCESS  Operating fluids Additives (fuel) Brake fluid Coolant (engine) Engine oil	410 411 412

Fuel (gasoline)	408	Panic alarm		Parking brake see Electric parking brake	
Refrigerant (air conditioning system) Windshield washer fluid		Panoramic roof		Parking for an extended period	149
Operating safety	712	Adjusting the roller sunblind  Operating the roller sunblind		Parking lights	100
Declaration of conformity (wireless vehicle components)	21	Parcel net hooks	96	Parking position Exterior mirrors	110
Information		Park position Inserting	137	Storing the position of the front- passenger outside mirror using	
Operating system see On-board computer			137	reverse gear	110
Operator's Manual Vehicle equipment	18	Parking see Electric parking brake Parking aid		PASSENGER AIR BAG status display see Automatic front passenger front airbag shutoff	
Operator's Manual (digital)	16	see Parking Assist PARKTRONIC		Payload	
Overhead control panel Making calls (Mercedes me connect)		•	182 184	Calculation example  Determining the maximum	
Overview	302 10	Adjusting warning tonesFunction	185 182	Pedestrian protection see Active hood (pedestrian protection)	
P		Side impact protection Switching off	183 184	Perfume see Perfume atomizer	
Paint code	406		182	Perfume atomizer	121
Paintwork (cleaning instructions)	345	Parking assistance systems		Inserting/removing the flacon	
Panel heating Setting	87	see Active Parking Assist		Setting	

#### 500 Index

Perfume vial see Perfume atomizer  Permitted towing methods	364	Power closing function  Door  Trunk lid  Power supply  Switching on (Start/Stop button)	64	Programs see DYNAMIC SELECT Protecting the environment Notes	17
see User profile  Pets in the vehicle  Phone book	54	Power windows		Q QR code	
see Contacts  Picture formats see Video mode		see Side windows  PRE-SAFE® (anticipatory occupant protection)	43	Rescue card  Qualified specialist workshop	
Picture settings see Video mode		Function	43 43	R Radar sensors Foil covering	150
PIN protection         Activating/deactivating         2           Plastic trim (Care)         3           Playback options         Selecting         3	350 316	PRE-SAFE® PLUS (anticipatory occupant protection plus)  Function  Reversing measures  Preventative occupant protection system	43 43	Radio  Activating/deactivating radio text Calling up the station list Deleting channels Direct frequency entry Displaying information Displaying radio text	327 327 327 328
Selecting		see PRE-SAFE® (anticipatory occupant protection)  Previous destinations Selecting	263	Editing station presets  Menu (on-board computer)  Moving stations  Overview	327 218 327

Searching for stations Setting a channel Setting the waveband Storing radio stations Switching on Switching the HD radio function on/off Tagging music tracks Voice commands (Voice Control System)  Radio stations Dialing (on-board computer)  Range Displaying  Reading light	327 327 327 325 327 328 230 218	Function Opening the camera cover (360° Camera) Setting favorites (360° Camera) Rear window Roller sunblind Reflective safety vest Refrigerant (air conditioning system) Notes Refrigerator box Removing/installing Using Refueling Refueling Refueling the vehicle	190 69 353 413 103 101	Reserve Fuel	25 12 2 4 2 2 2 2 2 2
see Interior lighting  Real wood (Care)  Rear climate control  Setting  Rear fog lamp  Switching on/off  Rear view camera  Care	121 107 186	Remote Online Charging the battery Cooling or heating the vehicle interior Starting the vehicle Reporting malfunctions relevant to safety Rescue card		Reverse gear Inserting Rims (Care)  ROAD SURFACE SCAN Multifunction camera  Roadside Assistance Roadside Assistance call see Mercedes me connect	13 34 17

Roll away protection see HOLD function		Changing direction  Destination reached	273	Displaying service informationInformation	
Roller sunblind		From an off-road location		Information about Smart Favorites	
Panoramic roof	74	Lane recommendations		and TuneStart	
Rear window		Notes		Logging in	
Roof load	414	Off-road	275	Moving a channel	
		To an off-road destination	2/4	Music and sport alerts function	
Route		Route-based speed adaptation		Overview	
Activating a commuter route		Displays in the Instrument Display	171	Pause and playback function	
	267	Function		Restrictions	
Displaying destination information		Route-based speed adjustment		Selecting a category	
External	276	Setting	167	Selecting a channel	
- 0	264	· ·	107	Setting music and sport alerts	
8 - 71 -	268	Run-flat characteristics	054	Setting the parental control	
	269	MOExtended tires	354	Storing a channel	
	269	0		Switching on	329
0 1	268	<b>S</b>		SD card	
Starting the automatic service sta-	070	Safety systems		Inserting/removing	314
	270	see Driving safety system		Seat	7
Switching the automatic gas station search on/off	270	Satellite map	284	Adjusting (electrically)	
, ,	270	Satellite radio		Adjusting the front passenger seat	
3	265	Activating/deactivating TuneStart	332	from the driver's seat	8:
		Adding a channel to Smart Favorites		Configuring the settings	
Route guidance		Deleting a channel		Correct driver's seat position	
Canceling	274	Displaying EPG information	331	Folding the backrest forwards/back	
		DEALER ePROCESS			

Side impact protection 183	SmartKey functions		Sound settings	33
Side windows         70           Closing         70           Closing using the SmartKey         72           Convenience closing feature         72           Convenience opening         71           Opening         70	Deactivating	56	Adjusting the balance/fader	333 333 333
Opening with the SmartKey 71	Snow chains	375	Special seat belt retractor	. 49
Problem         72           Size designation (tires)         389           Sliding sunroof         MAGIC SKY CONTROL (function)         76           MAGIC SKY CONTROL (operating)         76           SmartKey         55           Acoustic locking verification signal         56           Battery         57           Energy consumption         56           Features         55           Key ring attachment         57           Mechanical key         57           Overview         55           Panic alarm         56           Problem         58           Unlocking setting         56	Front center console Rear passenger compartment Trunk  Software update Important system updates Information Performing  Sound PRE-SAFE® Sound Wheels and tires  Sound see Burmester® surround sound system see Sound settings	100 100 101 255 256 255 256 43 374	Specialist workshop  Speech dialog system see Voice Control System  Speed index (tires)  Speedometer Digital  Spotlight function Switching on/off  Standby mode Activating/deactivating Function  Standing lights  Start/Stop button Parking the vehicle Starting the vehicle	386 216 203 156 144 106
	DEALER ePROCESS			

<b>Switching the surround sound on/off</b> Burmester® surround sound system	334	T		InformationInterchanging mobile phones	287 289
Synchronization function Activating/deactivating (multimedia system)		Tailpipes (Care)  Tank content  Fuel	410	Menu (on-board computer) Mobile phone voice recognition	219 291 285
System settings  Activating/deactivating PIN protection	252 247 247 248	Technical data Information Tire pressure monitor Vehicle identification plate  Telephone  Call and ringtone volume Calls with several participants Connecting a mobile phone (Near Field Communication (NFC)) Connecting a mobile phone (Passkey) Connecting a mobile phone (Secure Simple Pairing) De-authorizing a mobile phone Importing contacts Importing contacts Importing contacts (overview) Incoming call during an existing call	404 381 406 , 286 291 291 291 290 287 287 289 289 294 293	Reception and transmission volume Switching mobile phones (Near Field Communication (NFC)) Telephone menu overview Telephone operation Using Near Field Communication (NFC) Voice commands (Voice Control System) Wireless charging (mobile phone)  Telephone see Second telephone  Telephone number Dialing (on-board computer) Telephony operating modes Bluetooth® Telephony Telephony operating modes see Second telephone	290 290 286 291 290 229 104

DEALER EPROCESS

## 508 Index

Tire-change tool kit		Overview of tire labeling	. 386	Tool	
Overview	397	Removing	. 401	see Vehicle tool kit	
TIREFIT kit	355	Replacing	4, 398	Top Tether	. 51
Storage location		Restarting the tire pressure monitor-	201	Total distance	216
Using	355	ing system		Displaying	
Tires		Rotating Selection		Touch Control	
Changing hub caps	398	Snow chains		On-board computer	
Characteristics		Speed rating		Operating	
Checking	374	Storing		Setting the sensitivity	
Checking the tire pressure (man-		Temperature grade		Touchpad	
ually)	378	Tire and Loading Information placard		Activating/deactivating haptic oper-	239
Checking the tire pressure (tire pres-			. 382	ation feedback	2/11
sure monitoring system)		Tire pressure (notes)	. 375	Operating	
Definitions	392	Tire pressure monitoring system		Reading the handwriting recognition	207
DOT, Tire Identification Number (TIN)	207	(function)		aloud	240
		Tire pressure table	377	Selecting a station and track	
Flat tire		Tire Quality Grading	. 386	Setting the sensitivity	
Installing Load index	389	Tire size designation		Switching on/off	239
	389	TIREFIT kit		Tow-bar system	200
Load-bearing capacity  Maximum tire load	388	Traction grade			
Maximum tire pressure		Tread wear grade		Tow-starting	370
MOExtended tires		Unusual handling characteristics	. 374	Towing away	366
Noise		Toll system		Towing eye	
Notes on installing		Windshield	. 117	Installing	369
		DEALER ePROCESS			

Storage location		Transporting Loading guidelines Vehicle	92 367	Opening dimensions  Power closing function  Unlocking (mechanical key)	64
Track Selecting (audio mode)  Traction grade		Tread wear grade		Turn signal indicator see Turn signals	
Traffic information  Displaying the traffic map Displaying traffic incidents Extending a Live Traffic Information subscription Issuing hazard warnings Live Traffic Information Overview	276 277 278 277 278 277	Trip Menu (on-board computer)  Trip computer Displaying	216 216 217 216 216	Turn signals Switching on/off Two phone mode see Second telephone Two-way radios Frequencies Notes on installation Transmission output (maximum)	107 405 404
Traffic map see Map	2,0	Resetting  Trip odometer	21/	U	
Traffic Sign Assist  Function/notes  Setting  System limitations  Transferred vehicle data  Android Auto  Apple CarPlay™  Transmission position display	198 199 198 301 301	see Trip distance  Trunk lid  Activating/deactivating the tailgate opening height restriction  Closing	68 66 67	Units of measurement Setting Unlocking setting USB devices Connecting User profile Creating Importing/exporting	316 254 254
manismission position display	100	DEALER ePROCESS		importing/ caporting	204

## 510 Index

Options	255 254	RaisingStandby mode function		Event data recorders  Vehicle dimensions	
Ising the telephone see Calls		Starting (emergency operation mode)		Vehicle electronics	404
	128	Starting (start/stop button)	141 209	Vehicle identification number see VIN	404
Activating/deactivating standby mode  Correct use  Data acquisition	22	Unlocking (from the inside)	. 60	Vehicle identification plate Paint codeVIN	
Data storage Diagnostics connection	24 21	Voice commands (Voice Control System)	234	Vehicle identification plate see Model series	
Equipment  Limited Warranty  Locking (automatically)  Locking (from the inside)	23 . 61 60	Displaying (DYNAMIC SELECT)		Vehicle interior Cooling or heating (Remote Online) Vehicle key see SmartKey	128
Locking (KEYLESS-GO) Locking/unlocking (emergency key) Lowering Maintenance	62 402 19	Turning radius	414	Vehicle maintenance see ASSYST PLUS Vehicle operation	
Parking for an extended period	22 23	Vehicle width Wheelbase Vehicle data storage COMAND/mbrace	414	Outside the USA or Canada  Vehicle position Switching transmission on/off	

DEALER EPROCESS

Vehicle tool kit  TIREFIT kit Towing eye  Ventilating Convenience opening Vents see Air vents  Video mode Activating Activating/deactivating full-screen mode Overview Settings  VIN Identification plate Seat Windshield  Vision Removing condensation from the windows Windshield heater	355 369 . 71 319 317 319 318 319 406 406 406 406	Voice Control System  Application specific voice commands  Audible help functions Global voice commands Improving speech quality Language setting Media player voice commands Mussage voice commands Multifunction steering wheel (operating) Navigation voice commands Operable functions Operating safety Radio voice commands Switch voice commands Telephone voice controls Text message voice commands Types of voice commands Vehicle voice commands Voice prompting  Voice control system see Voice Control System	223 224 224 231 233 222 226 223 222 230 224 229 233 223 223	Warning lamps see Warning/indicator lamps Warning system see ATA (anti-theft alarm system) Warning/indicator lamp  ABS warning lamp Brake warning lamp (USA)  Brakes warning lamp (Canada)  Coolant warning lamp Electrical malfunction warning lamp Engine diagnosis warning lamp  ESP® OFF warning lamp  SFESP® warning lamp flashes  SESP® warning lamp lights up  Fuel reserve warning lamp  Power steering system warning	46 47 47 47 46 46 46 47
Voice command types (Voice Control System)		•		lamp	47

DEALER ePROCESS

## **512** Index

(P) Red indicator lamp, electric		Warranty	. 23	Mounting a new wheel	
parking brake applied (Canada only)	466	Washer fluid		Removing a wheel	
PARK Red indicator lamp, electric		see Windshield washer fluid		Removing/installing hub caps	
parking brake applied (USA only)	466	Washing by hand (care)	344	Wheel rotation	39
Restraint system warning lamp		Water tank		Wheels	
		see Air-water duct		Care	
★ Seat belt warning lamp flashes	409	Weather information	284	Changing hub caps	
Seat belt warning lamp lights		Web browser		Checking	3/4
up	469	Calling up a web page	309	ually)	378
§ Suspension warning lamp	470	Calling up options	310	Checking the tire pressure (tire pres-	
(!) Tire pressure monitoring sys-		Calling up the settings	310	sure monitoring system)	380
tem warning lamp flashes	474	Deleting a bookmark		Definitions	
(1) Tire pressure monitoring sys-		Deleting browser data		DOT, Tire Identification Number (TIN)	
tem warning lamp lights up	473	Ending Managing bookmarks	310	Flot tire	
Warning lamp for distance	47.0	Overview	309	Flat tireInstalling	
	470	Showing/hiding the menu	/	Load index	
warning function	4/0	Website		Load-bearing capacity	
Yellow electric parking brake		Calling up	309	Maximum tire load	
indicator lamp is malfunctioning	466	Showing/hiding the web browser	00,	Maximum tire pressure	
Warning/indicator lamps	462	menu	309	MOExtended tires	
Overview		Wheel change		Noise	
PASSENGER AIR BAG	40	Lowering the vehicle	402	Notes on installing  Overview of tire labeling	394
				Overview of the labelling	500

DEALER ePROCESS





